

Air Service Station

P/N 99700

Installation Instructions

1. Raise empty lift to full rise.
2. Determine if the back of the column has mounting holes provided per **Fig. 1**.
3. **If the four (4) holes have already been provided,** tap each hole 5/16"-18NC and mount Service Station with the provided hardware.
 - (4) 5/16" x 3/8" Lg. Phillips Pan Hd Screw
 - (4) 5/16 Split Lock Washer
4. **If the four (4) holes have not been provided,** Locate two (2) 17/64" diameter upper mounting holes centered on the back of the column per **Fig. 1**.
5. Tap the two (2) holes 5/16"-18NC and temporarily mount the Service Station with two (2) of the provided 5/16" Phillips Pan Hd Screw x 3/8" Lg. provided hardware.
6. Using the Service Station as a template locate two (2) 17/64" diameter lower mounting holes centered on the back of the column per **Fig. 1**.
7. Remove the Service Station, tap the two (2) lower holes 5/16"-18NC and remount the Service Station using the provide hardware.
 - (4) 5/16" x 3/8" Lg. Phillips Pan Hd Screw
 - (4) 5/16 Split Lock Washer

IMPORTANT: The hole locations are critical to avoid interference with the carriage slide blocks. Use hardware listed above to avoid interference with the back of the carriage.

