

Hybrid Inverter

Installation and Operation Manual



UGI New Energy Technology

T (042) 37456318 **F** +92 333 3120972, +92 317 4454362 **E** info: hassan@uniongroupindustries.com

Ad Building #287, AbPara Housing Society, Canal Road Lahore, Punjab, Pakistan.

UGI New Energy Technology

Contents

1. About This Manual	1
1.1 Scope of Validity	1
1.2 Target Group	1
2. Safety & Symbols	1
2.1 Safety Precautions	1
2.2 Explanations of Symbols	2
3. Introduction.	3
3.1 Basic Instruction	3
3.2 Operation Modes	3
3.2.1 Self-Use	3
3.2.2 Time of Use	4
3.2.3 Selling First	6
3.2.4 Back-Up	6
4. Installation.	7
4.1 Pre-installation	7
4.1.1 Unpacking & Package List	7
4.1.2 Product Overview	8
4.1.3 Mounting Location	9
4.2 Mounting	11
4.3 Electrical Connection	12
4.3.1 PV Connection	13
4.3.2 Battery Connection.	14
4.3.2.1 BAT-CAN/RS485	17
4.3.3 Multi Inverter Parallel	18
4.3.4 AC Connection	19
4.3.5 CT or Meter Connection	21
4.4 Communication Connection.	23
4.5 Earth Connection.	24

5. Operation	25
5.1 Control Panel	25
5.2 Menu Overview	26
5.3 Control Panel	26
5.3.1 Safety	27
5.3.2 Time & Date	27
5.3.3 PV Mode	28
5.3.4 Bat Setting	28
5.3.5 Inv Powere.	30
5.3.6 P Mode	30
5.3.7 Q Mode	31
5.3.8 CT/Meter	32
5.3.9 EPS	33
5.3.10 GEN.	33
5.3.11 Com Setting	33
5.3.12 Protection Parameters	35
5.3.13 EMS Parameterse	37
6. Power ON/OFF	42
6.1 Power ON	42
6.2 Power OFF	42
6.3 Restart	42
7. Maintenance & Trouble Shooting	42
7.1 Maintenance	42
7.2 Trouble Shooting	42
8. Specifications	53

1.About This Manual

1.1 Scope of Validity

This manual mainly describes the product information, guidelines for installation, operation, maintenance and troubleshooting. And this manual applies to UGI Single Phase Hybrid Inverter.

UGI7K-SLP UGI8K-SLP UGI9K-SLP UGI10K-SLP UGI11K-SLP UGI12k-SLP

Please keep this manual available all the time in case of any emergency.

1.2 Target Group

This manual is for qualified personnel. The tasks described in this manual must only be performed by qualified personnel.

2.Safety & Symbols

2.1 Safety Precautions

1. All work on the inverter must be carried out by qualified electricians.
2. The PV panels and inverter must be connected to the ground.
3. Do not touch the inverter cover until 5 minutes after disconnecting both DC and AC power supply.
4. Do not touch the inverter enclosure when operating, keep away from materials that may be affected by high temperatures.
5. Please ensure that the used device and any relevant accessories are disposed of in accordance with applicable regulations.
6. UGI inverter should be placed upwards and handled with care in delivery. Pay attention to waterproof. Do not expose the inverter directly to water, rain, snow or spray.
7. Alternative uses, modifications to the inverter not recommended. The warranty can become void if the inverter was tampered with or if the installation is not in accordance with the relevant installation instructions.

2.2 Explanations of Symbols

UGI inverter strictly comply with relevant safety standards. Please read and follow all the instructions and cautions during installation, operation and maintenance.



Danger of electric shock

The inverter contains fatal DC and AC power. All work on the inverter must be carried out by qualified personnel only.



Beware of hot surface

The inverter's housing may reach uncomfortably hot 60°C (140°F) under high power operation. Do not touch the inverter enclosure when operation.



Residual power discharge

Do not open the inverter cover until 5 minutes after disconnection both DC and AC power supply.



Important notes

Read all instructions carefully. Failure to follow these instructions, warnings and precautions may lead to device malfunction or damage.



Do not dispose of this device with the normal domestic waste.



Refer to manual before service.




CE mark

The inverter complies with the requirements of the applicable CE guidelines.

3. Introduction

3.1 Basic Instruction


The UGI UGI-SLP series hybrid inverters are designed to increase energy independence for homeowners. Energy management is based on time-of-use and demand charge rate structures, significantly reduce the amount of energy purchased from the public grid and optimize self-consumption.



3.2 Operation Modes

3.2.1 SelfUse

The SelfUse mode is for the regions with low feed-in tariff and high electricity prices. The energy produced by the PV system is used to optimize self-consumption needs. The excess energy is used to recharge the batteries, and any remaining excess is then exported to the grid.



Energy flow:

PV → Load → Battery → Grid


Note: Advance Setting

When select 0 W under P_Feed menu, the inverter will export zero energy to the grid.

When select xx W under P_Feed menu, the inverter will export customized energy to the grid.

3.2.2 ChgFst


When the grid fails, the system will automatically switch to ChgFst mode. The back-up loads can be supplied by both PV and battery energy.



Energy flow: PV → Battery → Load → Grid

3.2.3 SelfFst

The SelfFst mode is suitable for the regions with high feed-in tariff.




Energy flow:

PV → Load → Grid → Battery

3.2.4 Maintain

The Maintain mode is suitable for situations where the battery capacity is small, and the battery is charged and discharged at the specified power.



Energy flow:

PV → Load → Grid → Battery




Warning:

The Maintain mode is only available for some inverter.

3.2.5 cmdChg

In cmdChg mode, within the battery power range, the battery is charged and discharged at the specified power.



Energy flow:

Discharge: Battery and PV → Load → Grid

Charge: $P_{PV} > P_{Charge\ Set}$: PV → Battery → Load → Grid


$P_{PV} < P_{Charge\ Set}$: PV+Grid → Battery → Load

3.2.6 ExtEms

ExtEms mode requires customized external control accessories that can remotely control the operation of the inverter. It is not recommended to use it without professional personnel.

3.2.7 PeakShave

In PeakShave mode, the charging and discharging of the battery are controlled by setting the AC power to reduce the peak load of the power grid.



Energy flow: Grid power > P_Back : Battery and PV → Load
 Grid power < P_Back: Grid and PV → Battery


Note:  P_Back is set to Grid Ctr1 in the Run Param directory of the menu.

3.2.8 Time of Use

The Time of Use mode is designed to reward customers who do their part to reduce demand on the electric grid, particularly during peak usage periods. Use most of your electricity from PV energy and during off-peak time periods, and you could significantly lower your monthly bill.

A. Charge Setting

PV Charge Mode




4 periods of time charge setting.

Energy flow:

PV → Battery → Load → Grid

AC Charging



4 periods of time charge setting.

Energy flow:

PV and Grid → Battery → Load




Note:

After select AC charge, the AC will also charge the battery when the PV is low or no PV.

B. Forced Discharging


4 periods of time discharge setting



Energy flow: Battery and PV → Load → Grid

C. Forbidden Discharge

4 periods of time discharge setting, the battery will be charged firstly.



Energy flow:

PV → Battery → Load → Grid

4. Installation

4.1 Pre-installation


4.1.1 Unpacking & Package List

Unpacking

On receiving the inverter, please check to make sure the packing and all components are not missing or damaged. Please contact your dealer directly for supports if there is any damage or missing components.

Package List

Open the package, please check the packing list shown as below.




No.	Qty	Items	No.	Qty	Items
1	1	Hybrid Inverter	11	1	Battery Connector
2	1	Certificate Of Inspection	12	1	Monitor Module
3	1	Quick Installation Instructions	13	4	DC Connector
4	1	Warranty Card	14	3	Mounting Bracket Screw
5	1	Monitoring Quick Installation Instructions	15	3	Plastic Expansion Tube
6	1	CT	16	1	Smart Meter (Optional)
7	1	Battery wire	17	1	AC Waterproof Cover
8	1	Security Screw	18	1	Meter Connectors
9	2	Communication Connectors	19	2	Communication T568B
10	1	Wall Mounting Bracket	20	10	AC Wiring Terminal




Note:

Using the Communication Adapter when Multi Inverter Parallel.

4.1.2 Product Overview



Inverter Terminals




No.	Items	No.	Items
1	DC Switch 1	7	DC Connectors (+) For PV Strings
2	DC Connectors (+) For PV Strings	8	DC Connectors (-) For PV Strings
3	DC Connectors (-) For PV Strings	9	AC Port & EPS Port
4	Communication Port	10	DC Switch 2
5	Monitor Module Port	11	Battery Port -
6	Battery Port +		


4.1.3 Mounting Location

The inverters are designed for indoor and outdoor installation (IP66), to increase the sUGIety, performance and lifespan of the inverter, please select the mounting location carefully based on the following rules:


- The inverter should be installed on a solid surface, far from flammable or corrosion materials, where is suitable for inverter's weight and dimensions.
- The ambient temperature should be within -25 ℃ ~ 60 ℃ (between -13 °F and 140°F).
- The installation of inverter should be protected under shelter. Do not expose the inverter to direct sunlight, water, rain, snow, spray lightning, etc.



- The inverter should be installed vertically on the wall, or lean back on plane with a limited tilted angle.





- Leave the enough space around inverter, easy for accessing to the inverter, connection points and maintenance.




4.2 Mounting


Step 1




Step 2



Step 3



4.3 Electrical Connection



Communication Adapter pin assignment

No.	COM1	COM2	COM3
1	+3_3V	CT-U	SGND
2	DRM1/5	RS485-A	TEP
3	DRM2/6	CT-N	485-A2
4	DRM3/7	RS485-B	CANH_BAT1
5	DRM4/8		CANL_BAT1
6	DRM0		485-B2
7	SELV12		BAT-485-A
8	RPSD		BAT-485-B



Note:

For diesel generators or multi-machine parallel use, please contact the manufacturer, and provide installation and operation instructions separately.

4.3.1 PV Connection

The UGI-SLP series hybrid inverter has one/two MPPT channels, can be connected with one/two strings of PV panels. Please make sure below requirements are followed before connecting PV panels and strings to the inverter:


- The open-circuit voltage and short-circuit current of PV string should not exceed the reasonable range of the inverters.
- The isolation resistance between PV string and ground should exceed 300 kΩ.
- The polarity of PV strings are correct.
- Use the DC plugs in the accessory.
- The lightning protector should be equipped between PV string and inverter.
- Disconnect all of the PV (DC) switch during wiring.



Warning:

The fatal high voltage may on the DC side, please comply with electric safety when connecting. Please make sure the correct polarity of the cable connected with inverter, otherwise inverter could be damaged.


Step 1



Note:

PV cable suggestion
Cross-section
4mm²

Step 2



Note:


Please use PV connector crimper to pinch the point of the arrow.



Note:

You'll hear click sound when the connector assembly is correct.

Step 3



4.3.2 Battery Connection

UGI-SLP series hybrid inverters are compatible with lithium battery. For lead acid battery or batteries with other brands, please confirm with local distributor or UGI for technical support.




Note:

Set battery type and manufacturer, please refer to Chapter 5.3. BMS(Battery Management System)communication is needed between inverter and battery.

Step 1

The battery wires are threaded through waterproof sleeves and placed into the iron core according to the diagram.




Note:

Battery cable suggestion
Cross-section
1 AWG, 40-50mm.


Step 2

Use a hex wrench to lock the battery wire and ensure that the fastening screw locks the metal wire tightly. Do not lock the insulation layer of the wire.




Step 3

Insert the iron core into the battery port and tighten clockwise until it cannot rotate..




Step 4


Insert the waterproof adhesive sleeve into the battery terminals, pay attention to sealing to prevent water from entering and causing equipment damage.



4.3.2.1 BAT-CAN/RS485



4.3.3 Multi Inverter Parallel



Note:



The meter only communicates with the host and does not communicate with the machine. Refer to chapters 4.3.5.

4.3.4 AC Connection

The AC terminal contains “GRID” and “EPS”, GRID for load, and EPS for emergency load.

Before connecting, a separate AC breaker between individual inverter and AC input power is necessary. This will ensure the inverter be securely disconnected during maintenance and fully protected from current of AC input.

An extra AC breaker is needed for On-Grid connection to be isolated from grid when necessary. Below are requirements for the On-Grid AC-breaker.

Inverter Model	AC breaker specification
UGI7-12K-SLP	240A/200V/230V AC breaker



Note:


Qualified electrician will be required for the wiring.

Model	Wire Size	Cable (mm ²)	Torque value
7-12kW	6AWG	6-8	1.2N·m

Please follow steps for AC connection

- Connect breaker first before connecting.
- remove insulation sleeve 11mm(0.5 inch) length, unscrew the bolts, insert the AC input wires according to polarities indicated on the terminal block and tighten the terminal screws.

Step 1




Note: Cable suggestion Cross-section 6 AWG.

Note: The Max. power load connects to EPS port should not exceed the inverter's EPS Max. output power range.


Note: The wiring terminals should be wrapped with insulation tape, otherwise it will cause a short circuit and damage the inverter.

Note: UGiter tightening the nut, check again for any looseness.


Step 2



Step 3




Step 4



4.3.5 CT or Meter Connection


Meter and a current sensor (CT for short below) are used to detect current power direction of the local load and the grid. The output control function of the inverters will be activated based on the detected data.




Note:

In a pure off-grid system, electrical energy is mainly generated and used within the system, and there is no interaction with the external power grid. In this way, there is no situation of transmitting electrical energy to the power grid or obtaining electrical energy from the power grid, and there is no need to install electricity meters and current transformers.

Install the CT




Install the Meter



Note:

Please follow below pin order
 RS485A to single-phase meter (Pin 24)
 RS485B to single-phase meter (Pin 25)



Note:

Please follow below pin order
 RS485A to single-phase meter (Pin 24)
 RS485B to single-phase meter (Pin 25)


4.4 Communication Connection

The monitoring module could transmit the data to the cloud server, and display the data on the PC, tablet and smart-phone.



Install the WIFI / Ethernet / GPRS / RS485 Communication

WIFI / Ethernet / GPRS / RS485 communication is applicable to the inverter. Please refer to "Communication Configuration Instruction" for detailed instruction.

Step 1




Step 2



Turn on the DC switch and AC circuit breaker, and wait until the LED indicator on the monitoring module flashes, indicating that the monitoring module is successfully connected.

5. Operation

5.1 Control Panel



EPS Info

No.	Explanation	No.	Explanation
1	Time	8	Status ID
2	PV Info	9	Information
3	Inverter Info	10	GEN Info
4	BAT Info	11	Grid Info
5	EPS Info	12	Load Info
6	Operating Status	13	Setting
7	Inverter SN		



Note:

Status ID, when red, you can click to view the current fault.



: Back button, press Go Back One Level.




: OK button.



: Cancel button.

5.2 Menu Overview


UGI-SLP hybrid inverter has a LCD for clearly operating, and menu of the LCD can be presented as following:



5.3 Inverter Setting


The setting is for UGI-SLP Hybrid inverter. Any doubts, please contact distributor for more details.

5.3.1 Safety




Note:
Select the safety
according to the
requirements of
the installation site.

5.3.2 Time & Date




5.3.3 PV Mode



5.3.4 Bat Setting

5.3.4.1 Bat type



5.3.4.2 Lithium battery brand



Lithium



UGI	Talsu
Sunplus	Taico
Pylon	Rita
Dyness	CALB
.....	



Note:

Please select the right battery brand to your use.

5.3.4.3 Lead Acid

Setting



Bat Setting

→ Battery parameters setting



Lead-acid



NTCDisable	ON
Capacity:	0.0AH
ResComp:	0.0mΩ
TempComp:	0.0mv/°c
VConstVolt:	0.0V
VDischgEnd:	0.0V



- 1.ON:NTC Diasble,OFF:NTC Enable
- 2.Capacity 10-1000AH
- 3.ResComp:Resistance compensation
- 4.TempComp:temperature compensation
5. Constant voltage charging
voltage 35.0V-850.0V
6. End-of-discharge voltage,;35.0V-850.0V

5.3.4.4 Chg Range

Setting



Bat Setting

→ Battery parameters setting



ChgRange

→ Battery charge /discharge setting

SocMax:	0.0%
SocMin:	0.0%
VBatMax:	0.0V
VBatMin:	0.0V
IChgMax:	0.00A
IDChgMax:	0.00A
GridMinSoc:	0.0%

1. Upper state of charge.
2. Lower state of charge.
3. Battery Overvoltage Threshold.
4. Battery undervoltage threshold.
5. Maximum charging current.
6. Maximum discharge current.
7. Minimum SoC for grid-connected discharge.

5.3.5 Inv Powere

Setting



INV

→ Inverter power



P%-Feed:	0.0-00.0%
P-Feed:	xxW
P%-Back:	0.0-100.0%
P-Back:	xxW



1. The inverter sends electricity to the power grid percentage.
2. The inverter is sent to the power grid power.
3. The inverter draws electricity from the power grid percentage.
4. The inverter draws electricity from the grid.

5.3.6 P Mode

Setting



Grid control



P Mode

→ Active mode setting

DRMS	ON
Ripplectrl	ON
P:	0W
P%:	0.0%
P(V)	ON
P(F)	ON
P(V)	Setting
P(F)	Setting

1. DRMS Enable.
2. Ripple control
- 3.P:Maximum active output power.
4. P%: Active output limit.
5. Reduce power when the grid voltage is too high
6. Reduce power when the grid frequency is too high

P(V)	Setting
V1	0.0%
V2	0.0%
V3	0.0%
V4	0.0%
P1	0.0%
P2	0.0%
P3	0.0%
P4	0.0%

- 1.V1:Grid overvoltage, price adjustment
- 2.voltage 1,Range: 80.0%-150.0%
- 3.P1:Grid overvoltage, price adjustment
- 4.power1,Range: -100.0%-100.0%

P(F)	Setting
F1	0.00HZ
F2	0.00HZ
F3	0.00HZ
F4	0.00HZ
P1	0.0%
P2	0.0%
P3	0.0%
P4	0.0%


- 1.F1:Grid over-frequency, price adjustment
- 2.frequency1, Range: 50.00HZ-70.00HZ
- 3.P1:Grid Frequency, price adjustment
- 4.power1,Range: -100.0%-100.0%




Note:

It is not recommended to modify the DRMS Enable、Ripple ctrl Enable、P(V) parameters and P(F) parameters,Any doubts, please contact distributor for more details.

5.3.7 Q Mode




Reactive power mode setting


Note:

It is not recommended to modify the Q Mode、Q(V) parameters 、PF(P) parameters and Q(P) parameters,Any doubts, please contact distributor for more details.

5.3.8 CT/Meter



CT/Meter	None CT Meter
----------	---------------------

CT Ratio	0
----------	---

The CT Ratio ranges from 0-100.

Meter Type	UGI-Sp UGI-Tp Ukob418 Ukob115 Meter4 Meter5
------------	--

5.3.9 EPS

Setting



EpsEN

EpSEN ON:Eps Enable
EpSEN OFF:Eps Disable

5.3.10 GEN

Setting



GenEN

GenEN ON:Gen Enable
GenEN OFF:Gen Disable

5.3.11 Com Setting

5.3.11.1 Com1

Setting



Com Setting

Communication settings




Com 1



Port Addr Baud


1.Port:wifi
2.Address:1
3.Baud rate:115200/57600/56000
/38400/19200/9600

5.3.11.2 Com2-4



 **Note:**
When the port is selected as a Meter, the baud rate is 9600. When the port is selected as Parallel, the baud rate is recommended to be set to 9600.


5.3.11.3 Parallel




 **Note:**
The master address can only be set to 0, and the slave address cannot be greater than the Number.

5.3.12 Protection Parameters


5.3.12.1 Prot En




5.3.12.2 V Max




5.3.12.3 V Min




5.3.12.4 F Max




5.3.12.5 F Min






5.3.12.6 T Conn




Note:
 When modifying parameters, you need to pay attention to the unit.


5.3.13 EMS Parameterse

5.3.13.1 Mode






5.3.13.2 Cmd chg




5.3.13.3 AC chg




SocMax:	0.0%
ACChg	
P%:	0.0%
Time1:	00:00- 00:00
Time2:	00:00 - 00:00
Time3:	00:00-00:00

- 1.Acchg :Ac charging enable/disable.
- 2.SocMax:AC charging maximum Soc.
- 3.P%:AC charging Percentage.
- 4.Time1:Ac charging start time1-AC charging end time 1.
- 5.Time2:AC charging start time2-AC charging end time 2 .
- 6.Time3:AC charging start time3-AC charging end time 3 .

5.3.13.4 Force chg




5.3.13.5 Force DChg



SocMax:	0.0%
ForceDChg	
P%:	0.0%
Time1:	00:00- 00:00
Time2:	00:00 - 00:00
Time3:	00:00-00:00

1. Force Dchg : Forced discharging enable/disable.
2. SocMin: Forced discharging max Soc.
3. P%: Forced discharging power percentage.
4. Time1: Forced discharging start time1 - Forced discharging end time 1.
5. Time2: Forced discharging start time2 - Forced discharging end time 2.
6. Time3: Forced discharging start time3 - Forced discharging end time 3 .

5.3.13.6 Forbid DChg



Energy management system parameters setting

Forbid discharge


1. Forbid Dchg : Forbid discharging enable/disable
2. Time1: Forbid discharging start time1 - Forbid discharging end time 1.
3. Time2: Forbid discharging start time2- Forbid discharging end time 2 .
4. Time3: Forbid discharging start time3 - Forbid discharging end time 3 .



Note:

Timed charge and discharge need to complete the three settings of "Chg Cmd", "Chg Pwr" and "Chg Range", otherwise it will not work properly.

5.3.13.7 External loads



Energy management system parameters setting

SOC1:	0%
SOC2:	0%
SOC3:	0%
SOC4:	0%



1. When the current SOC is less than SOC1, stop supplying power to load 1.
2. Up to four loads can be connected

6.1 Power ON

- Turn on DC switch.
- After LCD lighting, hybrid inverter should be set following Chapter 5.3 at the first time.
- When inverter running under normal mode, Running indicator will light up(Ref. to Chapter 5.1).

6.2 Power OFF

- Turn off DC switch (in hybrid inverter) and all extra-breaker.

**Note:**

Hybrid inverter should be restarted UGiter 5 minutes.

6.3 Restart

Restart Hybrid inverter, please follow steps as below:

- Shutdown the inverter Ref. to Chapter 6.2.
- Start the inverter Ref. to Chapter 6.1.

7. Maintenance & Trouble Shooting

7.1 Maintenance

Periodically maintenance are necessary, please follow steps as below.

- PV connection: twice a year
- AC connection(Grid and EPS) : twice a year
- Battery connection: twice a year
- Earth connection: twice a year
- Heat sink: clean with dry towel once a year

7.2 Trouble Shooting

The fault messages are displayed when fault occurs, please check trouble shooting table and find related solutions.

Fault Code and Trouble Shooting

Type of Fault	Code	Name	Description	Recommend Solution
PV Fault	A01	PvConnectFault	PV connection type different from setup	• Check PV modules connection • Check PV Mode setup Ref. Chapter 5.3.
	A02	IsoFault	ISO check among PV panels/ wires and ground is abnormal.	• Check PV modules wires, those wires are soaked or damaged, and then carry out rectification. • If the fault occurs continuously and frequently, please ask help for local distributors.
	A03	PvUGIciFault	PV current arcing	• Check PV modules wires and connectors broken or loose connect, and then carry out rectification. • If the fault occurs continuously and frequently, please ask help for local distributors.
	A04	Pv1OverVoltFault	PV Voltage over	• Reconfiguration of PV strings, reduce the PV number of a PV string to reducing inverter PV input voltage. • Suggestion that contacting with local distributors.
	A05	Pv2OverVoltFault		
	A06	Pv3OverVoltFault		
	A07	Pv4OverVoltFault		
	A08	Pv5OverVoltFault		
	A09	Pv6OverVoltFault		
	A10	Pv7OverVoltFault		
	A11	Pv8OverVoltFault		
	A12	Pv9OverVoltFault		
	A13	Pv10OverVoltFault		
	A14	Pv11OverVoltFault		
	A15	Pv12OverVoltFault		
	A16	PV1ReverseFault	PV(+) and PV(-) reversed Connection	• Check PV(+) and PV(-) Connect whether reversed or not. • If reversed, make correction.
	A17	PV2ReverseFault		
	A18	PV3ReverseFault		
	A19	PV4ReverseFault		
	A20	PV5ReverseFault		
	A21	PV6ReverseFault		

Type of Fault	Code	Name	Description	Recommend Solution
PV Fault	A22	PV7ReverseFault		
	A23	PV8ReverseFault		
	A24	PV9ReverseFault		
	A25	PV10ReverseFault		
	A26	PV11ReverseFault		
	A27	PV12ReverseFault		
	A33	Pv1AbnormalFault	PV(+) and PV(-) reversed Connection	• Check PV modules partial occlusion or cells damaged. • Check PV module wires and connectors broken or loose connect, then repair it.
	A34	Pv2AbnormalFault		
	A35	Pv3AbnormalFault		
	A36	Pv4AbnormalFault		
	A37	Pv5AbnormalFault		
	A38	Pv6AbnormalFault		
	A39	Pv7AbnormalFault		
	A40	Pv8AbnormalFault		
	A41	Pv9AbnormalFault		
	A42	Pv10AbnormalFault		
	A43	Pv11AbnormalFault		
	A44	Pv12AbnormalFault		
	A45	Pv13AbnormalFault		
	A46	Pv14AbnormalFault		
	A47	Pv15AbnormalFault		
	A48	Pv16AbnormalFault		
	A49	Pv17AbnormalFault		
	A50	Pv18AbnormalFault		
	A51	Pv19AbnormalFault		
	A52	Pv20AbnormalFault		
	A53	Pv21AbnormalFault		
	A54	Pv22AbnormalFault		
	A55	Pv23AbnormalFault		
	A56	Pv24AbnormalFault		

Type of Fault	Code	Name	Description	Recommend Solution
Battery Fault	B01	PcsBatOverVoltFault	Battery voltage over or under	• Check inverters connected battery lines and connectors broken or loose connect. • Carry out rectification if broken or loose. • Checking battery voltage is abnormal or not, then maintenance or change new battery.
	B02	PcsBatUnderVoltFault		
	B03	PcsBatInsOverVoltFaul		
	B04	PcsBatReversedFault	Bat. (+) and Bat. (-) are reversed.	• Check Bat.(+) and Bat.(-)connect reversed or not. • Make correction If reversed.
	B05	PcsBatConnectFault	Battery wires loose	• Check battery wires and connectors damage or loose connect. • Carry out rectification if break.
	B06	PcsBatComFault	Battery communication abnormal	• Check battery side communication wires damage or loose connect, and then carry out rectification. • Check battery is off or other abnormal, then Mastertenance battery or change new battery.
	B07	PcsBatTempSensorOpen	Battery temperature sensor abnormal	• Check battery temperature sensor and connected wires damage or not , then rectification or change new one.
	B08	PcsBatTempSensorShort		
	B09	BmsBatSystemFault	All these faults will be detected or reported by battery BMS.	• If specific fault high temperature or low temperature, then should change battery installed environment temperature. • Restart battery, maybe can working as normal. • If this fault occurs continuously and frequently, please ask help for local distributors.
	B10	BmsBatVolOverFault		
	B11	BmsBatVolUnderFault		
	B12	BmsCellVolOverFault		
	B13	BmsCellVolUnderFault		
	B14	BmsCellVolUnbanceFau		
	B15	BatChgCurOverFault		
	B16	BatDChgCurOverFault		
	B17	BatTemperatureOverFa		
	B18	BatTemperatureUnderF		
	B19	CelTemperatureOverFa		
	B20	CelTemperatureUnderF		
	B21	BatIsoFault		
	B22	BatSocLowFault		
	B23	BmsInterComFault		
	B24	BatRelayFault		

Type of Fault	Code	Name	Description	Recommend Solution
Battery Fault	B25	BatPreChaFault		
	B26	BmsBatChgMosFault		
	B27	BmsBatDChgMosFault		
	B28	BMSVolOVFault		
	B29	BMSVolLFault		
	B30	VolLockOpenFault		
	B31	VolLockShortFault		
	B32	ChgRefOVFault		
	C01	GridLossFault	Grid lost (islanding)	• Inverter will restart automatically when the grid return to normal. • Check inverter connected with grid connectors and cable normal or not.
	C02	GridUnbalanVoltFault	Grid Voltage unbalanced.	• The inverter will restart automatically when the grid three phase return to normal. • Check inverter connected with the grid connectors and wires normal or not. connectors and cable normal or not.
	C03	GridInstOverVoltFault	Grid instantaneous voltage over	• The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust protection parameters.
	C04	Grid10MinOverVoltFault	Grid voltage Over by 10 Minutes	• The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust 10 minutes protection voltage parameters.
	C05	GridOverVoltFault	Grid voltage over	• The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust voltage protection parameters.
	C06	GridUnderVoltFault	Grid voltage under	
	C07	GridLineOverVoltFault	Grid line voltage over	
	C08	GridLineUnderVoltFault	Grid line voltage under	
	C09	GridOverFreqFault	Grid Frequency over	• The inverter will restart automatically when the grid three phase return to normal. • Contact with local distributor or required grid company adjust frequency protection parameters.
	C10	GridUnderFreqFault	Grid Frequency under	

Type of Fault	Code	Name	Description	Recommend Solution
Off-grid Fault	D01	UpsOverPowerFault	Off-grid load over	• Reduce loads. • If sometimes overload, it can be ignored, when generation power enough can be recovery. • If those faults occurs continuously and frequently, please ask help for local distributors.
	D02	GridConflictFault	Grid connected to Back-up terminal	• Check the off-grid port connection correct, disconnect both off-grid and grid ports.
	D03	GenOverVoltFault	GenOverVoltFault	• Adjust generator running parameters, make the output voltage, frequency in allowed range. • If this fault occurs continuously and frequently, please ask help for local distributors.
	D04	GenUnderVoltFault	GenUnderVoltFault	
	D05	GenOverFreqFault	GenOverFreqFault	
	D06	GenUnderFreqFault	GenUnderFreqFault	
DC Fault	E01	Pv1HwOverCurrFault	PV current over, triggered by hardware protection circuit	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	E02	Pv2HwOverCurrFault		
	E03	Pv3HwOverCurrFault		
	E04	Pv4HwOverCurrFault		
	E05	Pv5HwOverCurrFault		
	E06	Pv6HwOverCurrFault		
	E07	Pv7HwOverCurrFault		
	E08	Pv8HwOverCurrFault		
	E09	Pv9HwOverCurrFault		
	E10	Pv10HwOverCurrFault		
	E11	Pv11HwOverCurrFault		
	E12	Pv12HwOverCurrFault		
	E13	Pv1SwOverCurrFault	PV current over, triggered by Software logic.	• Power off, power on then restart. • If those faults occurs continuously and frequently, please ask help for local distributors.
	E14	Pv2SwOverCurrFault		
	E15	Pv3SwOverCurrFault		
	E16	Pv4SwOverCurrFault		
	E17	Pv5SwOverCurrFault		
	E18	Pv6SwOverCurrFault		
	E19	Pv7SwOverCurrFault		
	E20	Pv8SwOverCurrFault		

Type of Fault	Code	Name	Description	Recommend Solution
DC Fault	E21	Pv9SwOverCurrFault		
	E22	Pv10SwOverCurrFault		
	E23	Pv11SwOverCurrFault		
	E24	Pv12SwOverCurrFault		
	E33	Boost1SelfCheck(boost)Fault	PV boost circuit abnormal when self checking	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E34	Boost2SelfCheck(boost)Fault		
	E35	Boost3SelfCheck(boost)Fault		
	E36	Boost4SelfCheck(boost)Fault		
	E37	Boost5SelfCheck(boost)Fault		
	E38	Boost6SelfCheck(boost)Fault		
	E39	Boost7SelfCheck(boost)Fault		
	E40	Boost8SelfCheck(boost)Fault		
	E41	Boost9SelfCheck(boost)Fault		
	E42	Boost10SelfCheck(boost)Fault		
	E43	Boost11SelfCheck(boost)Fault		
	E44	Boost12SelfCheck(boost)Fault		
	E45	BusHwOverVoltFault	Bus voltage over	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E46	BusHwOverHalfVoltFault		
	E47	BusSwOverVoltFault		
	E48	BusSwOverHalfVoltFault		
	E49	BusSwUnderVoltFault	Bus voltage under as running	
	E50	BusUnbalancedFault	DC Bus voltage unbalanced	
	E51	BusBalBridgeHwOver-CurFault	Bus Controller current over	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E52	BusBalBridgeSwOver-CurFault		
	E53	BusBalBridgeSelf-CheckFault	Bus Controller abnormal when self checking	
	E54	BDCHwOverCurrFault	BiDC current over	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
	E55	BDCSwOverCurrFault		
	E56	BDCSelfCheckFault	BiDC abnormal as self checking	
	E57	BDCSwOverVoltFault	BiDC voltage over	
	E58	TransHwOverCurrFault	BiDC current over	

Type of Fault	Code	Name	Description	Recommend Solution
	E59	BDCFuseFault	BiDC fuse broken	• Change fuse.
	E60	BDCRelayFault	BiDC relay abnormal	• Power off, then restart (Ref. Chapter8). • If those faults continuously and frequently, please ask help for local distributors.
AC Fault	F01	HwOverFault	All over current/ voltage by protection hardware	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	F02	InvHwOverCurrFault	Ac over current by protection hardware	
	F03	InvROverCurrFault	R phase current over	
	F04	InvSOverCurrFault	S phase current over	
	F05	InvTOverCurrFault	T phase current over	
	F06	GridUnbalanCurrFault	On-grid current unbalanced	
	F07	DclnjOverCurrFault	DC injection current over	
	F08	AcOverLeakCurrFault	Ac side leakage current over	• Check AC insulation and ground wires connect ground is well or not, then repair it. • Power off, then restart (Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F09	PLLFault	PLL abnormal	• Power off, then restart (Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F10	GridRelayFault	Grid relay abnormal	
	F11	UpsRelayFault	Ups relay abnormal	
	F12	GenRelayFault	Generator relay abnormal	
	F13	Relay4Fault	Relay4 abnormal	
	F14	UpsROverCurrFault	Off-grid output current over	• When off-grid the load start impulse current is over, reduce the start impulse current load. • Power off, then restart (Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F15	UpsSOverCurrFault		
	F16	UpsTOverCurrFault		
	F17	GenROverCurrFault	Generator current over	• Check generator output voltage, frequency is stability, and adjust generator. • Power off, then restart(Ref. Chapter8). • If those fault occurs continuously and frequently, please ask help for local distributors.
	F18	GenSOverCurrFault		
	F19	GenTOverCurrFault		
	F20	GenReversePowerFault	Active power injected to generator	

Type of Fault	Code	Name	Description	Recommend Solution
AC Fault	F21	UpsOverVoltFault	Off-grid output voltage over or under	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	F22	UpsUnderVoltFault		
	F23	UpsOverFreqFault	Off-grid output frequency over or under	
	F24	UpsUnderFreqFault		
	F25	DcInjOverVoltFault	Off-grid DC injection voltage over	
System Fault	G01	PV1CurAdChanFault	Sampling hardware abnormal	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	G02	PV2CurAdChanFault		
	G03	PV3CurAdChanFault		
	G04	PV4CurAdChanFault		
	G05	PV5CurAdChanFault		
	G06	PV6CurAdChanFault		
	G07	PV7CurAdChanFault		
	G08	PV8CurAdChanFault		
	G09	PV9CurAdChanFault		
	G10	PV10CurAdChanFault		
	G11	PV11CurAdChanFault		
	G12	PV12CurAdChanFault		
	G13	BDCCurrAdChanFault		
	G14	TransCurAdChanFault		
	G15	BalBrigCurAdChanFault		
	G16	RInvCurAdChanFault		
	G17	SInvCurAdChanFault		
	G18	TInvCurAdChanFault		
	G19	RInvDciAdChanFault		
	G20	SInvDciAdChanFault		
	G21	TInvDciAdChanFault		
	G22	LeakCurAdChanFault		
	G23	VoltRefAdChanFault		
	G24	UpsRCurAdChanFault		



Type of Fault	Code	Name	Description	Recommend Solution
System Fault	G25	UpsSCurAdChanFault		
	G26	UpsTCurAdChanFault		
	G27	GenRCurAdChanFault		
	G28	GenSCurAdChanFault		
	G29	GenTCurAdChanFault		
	G30	UpsRDcvAdChanFault		
	G31	UpsSDcvAdChanFault		
	G32	UpsTDcvAdChanFault		
	G37	TempAdChanFault	All temperature sensors abnormal	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	G38	VoltAdConflictFault	The sample value of PV, battery and BUS voltage inconsistent	
	G39	CPUAdConflictFault	The sample value between master CPU and slaver CPU inconsistent	
	G40	PowerCalcConflictFault	Power value between PV, battery and AC output inconsistent	
	G41	EnvirOverTempFault	Installation environment temperature over or low	• Change or improve the installation environment temperature, make running temperature suitable. • Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.
	G42	EnvirLowTempFault		
	G43	CoolingOverTempFault	Cooling temperature over or low	
	G44	CoolingLowTempFault		
	G45	OverTemp3Fault	Temperature3 over or low	
	G46	LowTemp3Fault		
G47	CpuOverTempFault	CPU temperature over		
G48	ModelConflictFault	Version conflict with inverter	• Power off, then restart (Ref. Chapter8). • If those faults occurs continuously and frequently, please ask help for local distributors.	
Inner Warning	I01	InterFanWarning	Fan abnormal	• Remove foreign matter logged in fan. • If those faults occurs continuously and frequently, please ask help for local distributors.
	I02	ExterFanWarning		
	I03	Fan3Warning		

Type of Fault	Code	Name	Description	Recommend Solution
Inner Warning	I04	EnvirTempAdChan-Warning	Some temperature sensors abnormal	- The warnings are not matter influence. - Power off, then restart (Ref. Chapter8). - If those faults occurs continuously and frequently, please ask help for local distributors.
	I05	CoolingTempAdChan-Warning		
	I06	Temp3AdChanWarning		
	I07	ExtFlashComWarning	Flash abnormal	- Power off, then restart (Ref. Chapter8). - If this those faults continuously and frequently, please ask help for local distributors.
	I08	EepromComWarning	Eeprom abnormal	
	I09	SlaveComWarning	Communication between slaver CPU and master CPU abnormal	
	I10	HmiComWarning	HMI abnormal	
	I11	FreqCalcConflictWarning	Frequency value abnormal	
	I12	UnsetModel	Running model is not initial	Contact with local distributor.
Outside Warning	J01	MeterComWarning	Meter/CT abnormal	- Check the smart meter model, connection or connectors are correct, any loose. - if abnormal, repair or change. - Power off, then restart (Ref. Chapter8). - If those faults occurs continuously and frequently, please ask help for local distributors.
	J02	MeterConnectWarning	Wires connecting type of meter wrong	- Check Meter/CT connection, installed place, and installed direction. - if abnormal, re-installation. - Power off, then restart (Ref. Chapter8). - If this those faults continuously and frequently, please ask help for local distributors.
	J03	SohWarning	Battery SOH low	Contact with Battery manufacturer.
	J04	GndAbnormalWarning	Earth impedance over by cable loose and so on	- Check earth line connection or earth connecting impedance. - if abnormal, then adjust it. - Power off, then restart (Ref. Chapter8). - If this those faults continuously and frequently, please ask help for local distributors.
	J05	ParallelComWarning	Communication between master inverter and slaver ones abnormal in parallel mode	- Check parallel connect communication wires damage, connectors loose, connect port correct or not. - if not, then adjust it. - Power off, then restart (Ref. Chapter8). - If this those faults continuously and frequently, please ask help for local distributors.

8. Specifications

■ Technical Data	UGI7K-SLP	UGI8K-SLP	UGI9K-SLP	UGI10K-SLP	UGI11K-SLP	UGI12K-SLP
PV Input						
Max. Input Power (kW)	10.5	12	13.5	15	16.5	18
Max. PV Voltage (V)	550					
MPPT Range (V)	80 - 500					
Full MPPT Range (V)	130 - 500	150 - 500	160 - 500	130 - 500	150 - 500	160 - 500
Normal Voltage (V)	360					
Startup Voltage (V)	100					
Max. Input Current (A)	18.5 x 3					
Max. Short Current (A)	26 x 2					
No. of MPP Tracker / No. of PV String	1 / 1					
Battery Port						
Max. Charge/Discharge Power (kW)	7.0	8.0	9.0	10	11	12
Max. Charge/Discharge Current (A)	200	200	240	240	240	240
Battery Normal Voltage (V)	51.2					
Battery Voltage Range (V)	40 - 60					
Battery Type	Li-ion / Lead-acid etc.					
AC Grid & Diesel Gen (Optional)						
Max Continuous Current (A)	32	37	41	46	50	55
Max Continuous Power (kVA)	7.0	8.0	9.0	10	11	12
Nominal Grid Current (A)	32 / 31	37 / 35	41 / 39	46 / 44	50 / 48	55 / 52
Nominal Grid Voltage (V)	198 to 242 @ 220 / 207 to 253 @ 230					
Nominal Grid Frequency (Hz)	50 / 60					
Power Factor	0.999 (Adjustable from 0.8 overexcited to 0.8 underexcited)					
Current THD (%)	< 3					
AC Load Output						
Max Continuous Current (A)	32	37	41	46	50	55
Max Continuous Power (kVA)	7	8	9	10	11	12
Max Peak Current (A) (10min)	31.4 / 30	55.5 / 52.5	61.5 / 58.5	69 / 66	75 / 72	82.5 / 78
Max Peak Power (kVA) (10min)	10.5	12	13.5	15	16.5	18
Nominal AC Voltage L-N (V)	220 / 230					
Nominal AC Frequency (Hz)	50 / 60					
Switching Time (ms)	Seamless					
Voltage THD (%)	< 3					
Efficiency						
European Efficiency (%)	98.1					
Max. Efficiency (%)	96.8					
Protection						
PV Reverse Polarity Protection	Yes					
Bat. Reverse Polarity Protection	Yes					
Over Current/Voltage Protection	Yes					
Anti-Islanding Protection	Yes					
AC Short Circuit Protection	Yes					
Residual Current Detection	Yes					
Ground Fault Monitoring	Yes					
PV Arc Detection	Yes					
Enclosure Protect Level	IP66 / NEMA4X					
General Data						
Dimensions (W x H x D, mm)	785 x 614 x 258					
Weight (kg)	43					
Topology	Transformerless					
Cooling	Intelligent Fan					
Relative Humidity	0 - 100 %					
Operating Temperature Range (°C)	- 25 to 60 (Derating 45)					
Operating Altitude (m)	< 2000					
Noise Emission (dB)	< 40					
Standby Consumption (W)	< 30					
Mounting	Wall Bracket					
Communication with RSD	SUNSPEC					
Display & Communication Interfaces	LCD, LED, RS485, CAN, Wi-Fi, GPRS, 4G					
Certification & Approvals	NRS097, G98, EN50549-1, C10/C11, AS4777.2, VDE-AR-N4105, VDE0126, IEC62109-1, IEC62109-2					
EMC	EN61000-6-2, EN61000-6-3					