

Cable Wiring

Notes:

1. See Icom IC-A200 installation manual for proper instructions for attaching this cable.

2. DO NOT remove polarizing key from the Molex connector. Incorrectly mating this connector with the radio could cause damage to the radio.