

Kirsch® DH by Application



1. Start with Wood Trends Double bracket
2" part # = 5515xxx
1 3/8" part # = 5615xxx



2. Add Utility Rod
38" - 66" part # = L704025
66" - 120" part # = L706025

3. Note: treatments needing a center support will require the under-treatment to be pieced

Treatments over 48" wide typically require a center support

Ideal Solution for:

Decorative Valance with Wood Pole over a stationary sheer treatment

Side panel draperies over a stationary sheer treatment

Panels with tiebacks or holdbacks over a stationary sheer treatment

Using Pinch Pleat instead of Rod Pocket Under-treatment?

The instructions above works great for a Rod Pocketed under-treatment.

For a Pinch Pleated under-treatment, simply add Celcon Traverse Slides (part # L909E025) to the opening along the back of the Utility Rod.

