

1958-1964 Chevy 605 Style Steering Box Mounting Bracket Kit

Part Number: 40-142508-1

- Allows Bolt-On Installation Of A 605 Style Steering Box In Your 1958-64
- Hardware & Instructions Included

NOTE:

Additional Parts Changes Required with The 1958-1964 "605" Steering Box Conversion

A. If you have a 1958-1964 Chevy with standard steering,

You have a standard steering (1) pitman arm, (2) drag link, & (3) idler arm. You have the correct parts; you will not need to change any of the three.

B. If you have a 1958-1962 Chevy with power steering,

You have a power steering (1) pitman arm, (2) drag link, & (3) idler arm. You will need to change the center drag link to a 1958 -1962 standard steering drag link only.

C. If you have a 1963-1964 Chevy with power steering,

You have a power steering (1) pitman arm, (2) drag link, & (3) idler arm. You will need to change all three components.

You have two choices: you need a 1963-1964 standard steering pitman arm, standard steering drag link, and standard steering idler arm.

OR

You need a 1958-1962 standard steering pitman arm, standard steering drag link, and a standard steering idler arm.

