

DESC210R INSTRUCTIONS



1) Remove factory front body mount, factory front bumper and factory front bumper support. The 4 screws that secure the factory front bumper to the chassis will be reused to bolt the mod bumper to the chassis.



2) Secure the mod bumper support to the shock tower using the supplied hardware and the factory front body mount holes.



3) Remove the nut and bolt that secure the leading edge of the nerf bars to the chassis. Secure the mod front body post to the nerf bar mount hole using the supplied hardware.



Tip for mounting the body:

There should be between 1 and 1.5 inches of space between the front tire and the leading edge of the door panel.