## DRILL TEMPLATE

2019+ MERCEDES SPRINTER

**PASSENGER SIDE** 

FRONT CYLINDER **EDGE TO REAR CORNER OR BACK OF VERTICAL STEP WALL** PASSENGER SIDE FRONT CYLINDER **CUT OUTER SHAPE** IDENTIFICATION ONLY PASSENGER SIDE VERTICAL WALI P" SHAPE FOR STEP WELL, USE 9/16" DRILL BIT FOR VEHICLE FOUR HOLES PER FRONT JACK WITH KNIFE OR SCISSORS EDGE TO FLOOR OR BOTTOM OF STEP WELL MARK FOUR HOLES

CHECK SCALE: 4.5"