DRILL TEMPLATE

2019+ MERCEDES SPRINTER

DRIVER SIDE FRONT CYLINDER CHECK SCALE: 4.5"

USE 9/16" DRILL BIT FOR VEHICLE FOUR HOLES PER FRONT JACK MARK FOUR HOLES WITH KNIFE OR SCISSORS EDGE TO FLOOR OR BOTTOM OF STEP WELL DRIVER SIDE FRONT CYLINDER **IDENTIFICATION ONLY VERTICAL WALL** DRIVER SIDE STEP WELL, "D" SHAPE FOR

CUT OUTER SHAPE

EDGE TO REAR CORNER OR BACK OF VERTICAL STEP WALL

