

Disk Brake Pad Instructions

The brake pads in this kit are designed to be oversized on the outside pad.

When installing the outside pad:

If the 90 degree bent locator is too wide for your caliper simply lay the 90 degree locator on the vise and tap it with a hammer as shown in the picture below.

This will shrink the tab to fit different calipers that might be worn larger in the opening do to use. Only make the pad small enough to fit snug into the machined slot of your caliper.

****You do not have to hit the 90 degree flange very hard with a hammer.**

