

 **WARNING:** Cancer and reproductive harm
ADVERTENCIA: Cáncer y daño reproductivo
ATTENTION: Cancer et troubles de l'appareil reproducteur
WARNUNG: Krebs und reproduktiver schaden
www.P65warnings.ca.gov



Rear Tie Down Brackets
for Harley-Davidson
Touring Models

Part # 66051

Quantity:
1 Pair

Color : Black

*Patent Pending



66051

Fits: '10-up
Harley-Davidson Touring
models with OEM
passenger floorboard
mounts, '16-up
Harley-Davidson Touring
models with two bolt OEM
passenger footpeg mounts
(50500332A, 50500334A,
50500460A, 50500462A,
or 50500463A)
50500403A. Will not fit
trike models.

PART NO : 0502-0607

MADE IN TAIWAN

BRKT REAR TIE DOWN HD BLK

CIRO-P# 66051

U.O.F.M : PAIR

Supplied screws and washers will be used between spacers. The tie down loop motorcycle. Fig. 3.
180 in-lbs).

ring locks checking



Read
correct
heel s
help
ts st
re a
ont
ht. l
ar



Included Items:
2 - Rear tie down brackets for
1 - Hardware kit

Fig.1

Installation Instructions:

1. Park on a level surface and shut off motorcycle. Ensure that the engine has time to cool before installation.
2. Remove the top and bottom screw using a 5/16" Allen wrench for the top and 1/4" for the bottom. These screws will be replaced with included screws in hardware kit, Fig. 1.
3. With the floorboard removed Fig. 2 shows there are three

Fig

