

# *How to Use your* ***Xtreme ProMag Timer***

## ***Setting timing using a MSD 12LT Pro-Mag Magneto***

1. Set your crankshaft to the desired timing mark and on the compression stroke, 36 degrees as an example. Set the Magneto rotor to point to the number one cylinder.
2. Loosen the band clamp and find an area that is not affected by the magnets in the ProMag Magneto.
3. Plug the Xtreme ProMag Timer in to the Magneto and push the Start Button.
4. Turn magneto body to the Right (CCW) slowly in one fluid motion until you hear the Xtreme ProMag Timer chirp.
5. Now turn Magneto body slowly in one fluid motion to the Left (CW) till you hear the Xtreme ProMag Timer chirp.
6. Turn the Magneto body Right (CCW) until a steady Wail is heard. Lock the Magneto body at this spot.

Your engine is now ready to start. Warm engine up and check timing with a normal timing light.

03/01/15

***Safety First USA, Inc.***

3229 English Cove Ln, Marion, Iowa 52302-7608  
Phn 319-377-1129 • Fax 319-377-1539 • [Info@SafetyFirstUSAInc.com](mailto:Info@SafetyFirstUSAInc.com)