

# How to Build Your Custom Teardrop Camper

**5' x 10' Trailer**

**5' Tall Cabin**



**Contact:**

**[hennesseystealth@bigteardrop.com](mailto:hennesseystealth@bigteardrop.com)**

**<http://www.bigteardrop.com>**

**eBay Seller ID: hennesseystealth1957**

**United States Copyright TXu 1-963-321**

## Contents

<b>Introduction</b> .....	12
<b>License Agreement</b> .....	13
License .....	13
Restrictions .....	13
Limited Warranty.....	13
Limitations of Remedies .....	14
Government Licensee .....	14
Restricted Rights Legend.....	14
Export Law Assurances .....	14
General.....	15
<b>Trailer Construction (Phase 1)</b> .....	16
Materials List .....	16
Tool List.....	16
Process Steps.....	16
Figure 1: Using Magnetic Square and Welders Clamp.....	18
Figure 2: Frame Supported Level and Square .....	18
Figure 3: Finished Outside Frame .....	19
Figure 4: Cross Members in Place .....	19
Figure 5: A-Frame Coupler Welded to Channel Iron.....	20
Figure 6: Tongue Set Against First Cross Member .....	20
Figure 7: Weld Channel Iron to Frame and Cross Member .....	21
Figure 8: Completed Trailer Frame .....	21
Figure 9: Bolt Holes for Axle Placement.....	22
Figure 10: Completed Trailer .....	22
Figure 11: Safety Chains with Welded Clips.....	23
<b>Sealing Trailer Underside (Phase 2)</b> .....	24
Materials List .....	24
Tool List.....	24
Process Steps.....	24
Figure 12: Lower Outside of Sidewall with Dado Cut and Notches for Axle Bolt Access.....	25
Figure 13: Lower Outside of Sidewall ¼” Notch to Fit Trailer Frame Overlap .....	25
Figure 14: Sheet Metal Solder Joint .....	26

Figure 15: Sheet Metal Pan Placed in Frame .....	26
Figure 16: Sheet Metal Cut to Expose Axle Bolts .....	26
<b>Preparing Sidewalls and Subfloor (Phase 3)</b> .....	27
Materials List .....	27
Tool List.....	27
Process Steps.....	27
Figure 17: 6mm Baltic Birch Glued to Inside Surface of Sidewalls.....	28
Figure 18: Use Staples around Edges and Brad Nails in Visible Areas .....	28
Figure 19: Subfloor Frame Ready for Bottom Sheet of Plywood.....	29
Figure 20: Subfloor Frame Notched for Axle Bolt Access .....	29
Figure 21: Use Glue on Subfloor Frame before Attaching Plywood .....	30
Figure 22: Attach Plywood to Subfloor Frame.....	30
Figure 23: Use Screws to Attach Plywood to Subfloor Frame .....	31
<b>Finishing Sidewall Interiors (Phase 4)</b> .....	32
Materials List .....	32
Tool List.....	32
Process Steps.....	32
<b>Installing Subfloor, Sidewalls, and Flooring (Phase 5)</b> .....	33
Materials List .....	33
Tool List.....	33
Process Steps.....	33
Figure 24: Subfloor Centered on Trailer Frame .....	35
Figure 25: Subfloor Bolted to Trailer Frame .....	35
Figure 26: Using a Compass (Pencil on String), Mark and Cut 24" Front Radius .....	36
Figure 27: Using a Compass (Pencil on String), Mark and Cut 40" Rear Radius .....	37
Figure 28: Sidewall Profile.....	37
Figure 29: Door Opening Layout on Passenger Sidewall with 12" Radius .....	38
Figure 30: Sidewall with Door Opening Installed.....	39
Figure 31: Hole in Side Frame for Attaching Sidewalls .....	40
Figure 32: Hole in Subfloor Frame for Attaching Sidewalls .....	40
Figure 33: Sidewall Attached to Frame and Subfloor .....	41
Figure 34: Insulation Inserted into Subfloor Frame .....	41
Figure 35: Subfloor Top Glued and Screwed to Subfloor Frame and Spars Attached .....	42

Figure 36: Install Cedar Flooring with Glue and Brad Nails .....	43
Figure 37: Finished Cedar Flooring .....	44
<b>Spar Installation and Interior Wall Skin (Phase 6)</b> .....	<b>45</b>
Materials List .....	45
Tool List.....	45
Process Steps.....	45
Figure 38: Spars View from Back.....	46
Figure 39: Spars View from Front .....	47
Figure 40: Cross Members for Ceiling Vent .....	48
Figure 41: 3mm Baltic Birch Fit to Front Spars (Inside).....	48
Figure 42: 3mm Baltic Birch Fit to Front Spars (Outside).....	49
Figure 43: 3mm Baltic Birch Fit to Ceiling with Vent Opening (Inside).....	50
Figure 44: 3mm Baltic Birch Fit to Ceiling with Vent Opening (Outside).....	51
<b>Cabinet Shell Construction and Installation (Phase 7)</b> .....	<b>52</b>
Materials List .....	52
Tool List.....	52
Process Steps.....	52
Figure 45: 18mm Baltic Birch Cut to Fit and Sealed with Deft.....	54
Figure 46: Bottom of Front Cabinet Installed Using Jack Stand for Support .....	54
Figure 47: Interior Divider/Support with Pocket Screws .....	55
Figure 48: Front Cabinet Face Installed .....	55
Figure 49: Galley Wall Installed.....	56
Figure 50: Back Cabinet Bottom Installed and Attached to Galley Wall with Pocket Screws .....	57
Figure 51: Back Cabinet Interior Support/Divider.....	58
Figure 52: Back Cabinet Face Installed.....	59
Figure 53: Closet Shelves Installed.....	59
Figure 54: Using Pocket Screw Jig to Drill Holes in Closet Shelf .....	60
Figure 55: Pocket Screw Hole in Bottom of Closet Shelf .....	61
Figure 56: Pocket Screw in Bottom of Closet Shelf Attaching to Galley Wall.....	62
Figure 57: Furring Strip Attached to Galley Counter Top and Galley Wall .....	62
Figure 58: Lower Galley Cabinet and Counter Top Installed .....	63
Figure 59: Galley Shelf Installed.....	63

Figure 60: Closet Door Guides .....	64
Figure 61: 1x3 White Birch for Building Cabinet Doors .....	65
<b>Cabinet Doors, Drawers, and Closet Construction and Installation (Phase 8)</b> .....	<b>66</b>
Materials List .....	66
Tool List.....	66
Process Steps.....	66
Figure 62: Closet Door with Finger Hole .....	68
Figure 63: Closet Door Top Inside Guide .....	68
Figure 64: Closet Door Bottom Inside Guide .....	69
Figure 65: Closet Doors Installed with Outside Guides.....	69
Figure 66: Rails and Stiles for Cabinet Doors and Drawer Fronts .....	70
Figure 67: Layout of Door and Drawer Interior Panels .....	71
Figure 68: Door and Drawer Interior Panels .....	72
Figure 69: Rails and Stiles for Drawer Front .....	72
Figure 70: Routed Groove in Drawer Front Rails.....	73
Figure 71: Dry Fit Rails, Stiles, and Panel before Assembly .....	73
Figure 72: Pocket Screw Holes for Drawer Fronts .....	74
Figure 73: Drawer Front Assembled Using Glue and Pocket Screws .....	74
Figure 74: Jig to Position Hinge Cup.....	74
Figure 75: Hinge Cup Drilled 35mm Diameter and ½" Deep with Screw Holes Marked .....	75
Figure 76: Hinge with Plate Attached to Cabinet Door.....	76
Figure 77: Hinges and Plates Attached to Cabinet Door.....	77
Figure 78: Cut 4 Drawer Bottoms at 14 ¼" x 15 ¾" .....	78
Figure 79: If Scrap 18mm Baltic Birch is too Small, Use Pocket Screws to Increase Size.....	79
Figure 80: Attach Drawer Sides to Bottoms Using #6 ½" Wood Screws.....	79
Figure 81: Attach Drawer Backs Using #6 ½" Wood Screws .....	80
Figure 82: Attach Drawer Fronts Using #6 ½" Wood Screws.....	80
Figure 83: Finished Drawer .....	81
Figure 84: Top Hinge Plate Installed .....	81
Figure 85: Top and Bottom Hinge Plates Installed and Door Attached .....	82
Figure 86: Galley Cabinet Doors.....	82
Figure 87: Inside Rear Cabinet Doors.....	83

Figure 88: Inside Front Cabinet Doors .....	83
Figure 89: Drawer Slide Supports .....	84
Figure 90: Drawer Slide Supports Installed with Drawer Slides.....	85
Figure 91: Top Drawers Installed .....	85
Figure 92: All Galley Doors and Drawers Installed.....	86
<b>Sink Installation, Electrical and Light Wiring (Phase 9) .....</b>	<b>87</b>
Materials List .....	87
Tool List.....	87
Process Steps.....	87
Figure 93: Sink Opening .....	90
Figure 94: Faucet Installed (Bottom) .....	90
Figure 95: Faucet Installed (Top) .....	91
Figure 96: Water Pump Installed and Wired .....	92
Figure 97: Sink Drain Installed (Bottom).....	93
Figure 98: Sink Drain Installed (Top) .....	94
Figure 99: Drain Pass-Through Opening .....	94
Figure 100: Sink Installed .....	95
Figure 101: Water Container Lid Came Equipped with 3/4" Male Spigot.....	95
Figure 102: Using 3/4" Male to 1/2" Female Reducer, Connect 3/8" Barb with 1/2" Male Threads to Both Sides of Lid (One side goes to Pump Inlet and the Other is a Siphon Tube).....	96
Figure 103: Water Container Lid with 3/8" Hose Barb Fitting .....	96
Figure 104: Water Container Tie Down and Connection to Pump Inlet.....	97
Figure 105: Faucet Connection to Pump Outlet .....	98
Figure 106: Notch Spars for Wire Runs .....	99
Figure 107: Wire Run across Spars and Down into Rear Cabinets.....	99
Figure 108: Wire Run through Rear Cabinet.....	100
Figure 109: Wire Run through Closet and into Galley under Sink .....	101
Figure 110: Connect Faucet Switch Across 12v Positive Line .....	102
Figure 111: Leave Extra Wire Length at Front of Camper.....	103
Figure 112: Wiring for LED Galley Light inside Center Rear Cabinet .....	104
Figure 113: LED Galley Light Off.....	104
Figure 114: LED Galley Light On .....	105

Figure 115: LED Passenger Side Door Wiring.....	105
Figure 116: Dome Light Wiring .....	106
Figure 117: Dome Light.....	107
Figure 118: Hole in Galley Wall for 120v Duplex Box .....	107
Figure 119: Duplex Box for GFI Plug inside Closet .....	108
Figure 120: Run Romex across Spars and into Rear Cabinet .....	108
Figure 121: Hole in Rear Cabinet to run Romex to Duplex Boxes.....	109
Figure 122: GFI Plug Connected to Romex .....	109
Figure 123: Duplex Box with Standard 120v Outlet and Weather Resistant Cover .....	110
Figure 124: Duplex Box with GFI 120v Outlet and Standard Cover .....	110
Figure 125: 12v Outlet in Galley.....	111
Figure 126: Cabinet Door with Latch and Silicon Bumper .....	111
<b>Windows, Door, and Aluminum Sheet/Trim Installation (Phase 10) .....</b>	<b>112</b>
Materials List .....	112
Tool List.....	112
Process Steps.....	113
Figure 127: Driver’s Side Window Opening .....	116
Figure 128: Aluminum Sheet on Driver’s Sidewall.....	116
Figure 129: Window Layout on Aluminum Sheet .....	117
Figure 130: Butyl Tape on Backside of Window .....	117
Figure 131: Window Inserted and Screwed to Sidewall .....	118
Figure 132: Window Caulking .....	119
Figure 133: Window View from Inside.....	119
Figure 134: Window Drip Cap Using Butyl Tape and Screws.....	120
Figure 135: Drain Pass-Through with 1” Hose Barb x ½” MPT and ½” FPT Coupling .....	120
Figure 136: Drain Pass-Through Installed on Sidewall.....	121
Figure 137: Drain Pass-Through Inside View .....	122
Figure 138: Driver’s Side Top Edge Trimmed.....	122
Figure 139: Passenger Sidewall with Door Opening Cut in Aluminum .....	123
Figure 140: Door Trim Edging on Exterior Door Opening.....	123
Figure 141: Door Trim Edging Counter Sink Flat Head Screws .....	124
Figure 142: LED Light above Door Opening .....	124

Figure 143: Door Trim Edging on Interior Door Opening.....	125
Figure 144: Door Trim Edging on Interior Door Opening at Hinge .....	126
Figure 145: Trim Door Slab Edges 3/16" (Do Not Trim Hinge Side).....	127
Figure 146: Measure and Mark Opening for Window in Door .....	127
Figure 147: Window Cut Out in Door.....	128
Figure 148: Window Opening Marked on Aluminum Sheet.....	129
Figure 149: Dry Fit Door Window .....	129
Figure 150: "T" Door Moulding.....	130
Figure 151: "T" Door Moulding Counter Sink Flat Head Screws.....	131
Figure 152: Inside Door Trim (Top) .....	131
Figure 153: Inside Door Trim (Bottom) .....	132
Figure 154: Inside Door Trim Hinge Side.....	133
Figure 155: Trim Door Hinge where it Hits "T" Door Moulding.....	134
Figure 156: Hinge Attached to Door .....	135
Figure 157: Attach Door and Hinge to Sidewall.....	136
Figure 158: Install Window in Door .....	136
Figure 159: Drip Rail Forming Using 6mm Baltic Birch Scraps .....	137
Figure 160: Drip Rail Attached Using Pan Head screws and Butyl Tape .....	137
Figure 161: R-Tech Insulation with Reflector Side Outward.....	138
Figure 162: Cut R-Tech Insulation to Match Spar Channels for Electrical Wiring.....	139
Figure 163: Hinge Position on Last Spar before Galley.....	140
Figure 164: Galley Hinge over Aluminum Roof Secured with Top Edge Moulding.....	141
Figure 165: Galley Hinge in Open Position.....	142
Figure 166: Top Edge Moulding Secured with Aluminum Drive Screws.....	143
Figure 167: "T" Door Moulding Used as Seam Concealment .....	144
Figure 168: Grommet to Pass Wiring Out of Camper .....	145
Figure 169: Top Edge Moulding Attached to Galley Sidewall.....	146
Figure 170: Ceiling Vent Installed (Outside) .....	147
Figure 171: Ceiling Vent Installed (Inside) .....	147
Figure 172: Weather Stripping on "T" Door Moulding .....	148
Figure 173: Weather Stripping Behind Door Hinge .....	149
Figure 174: Sink Drain to Pass-Through Connection.....	150



<b>Galley Hatch and Locks (Phase 11)</b> .....	151
Materials List .....	151
Tool List.....	151
Process Steps.....	151
Figure 175: Optional Spar after Galley Wall .....	153
Figure 176: Galley Hatch Skeleton Dry Fit.....	153
Figure 177: Galley Hatch Interior Skin (Inside) .....	154
Figure 178: Galley Hatch Interior Skin (Outside) .....	154
Figure 179: Galley Hatch with Aluminum Skin.....	155
Figure 180: Hole for Galley Hatch Lock.....	155
Figure 181: Galley Lock Attached to Inside of Hatch .....	156
Figure 182: Galley Lock “T” Handle.....	156
Figure 183: Galley Lock Strike Location .....	157
Figure 184: Galley Hatch Weather Strip .....	158
Figure 185: Galley Hatch Hinge Caulking .....	159
Figure 186: Hole for Side Door Lock.....	160
Figure 187: Side Door Lock.....	161
Figure 188: Side Door Lock Handle .....	162
<b>Electrical and Storage Box Completion (Phase 12)</b> .....	163
Materials List .....	163
Tool List.....	163
Process Steps.....	163
Figure 189: Utility Box Hole Centered on Channel Iron.....	165
Figure 190: Utility Box Hole and Grommet.....	165
Figure 191: Electric Skid Image 1 .....	166
Figure 192: Electric Skid Image 2 .....	166
Figure 193: Quick Connect Fuse and Terminal Block.....	167
Figure 194: Toggle Switch for 12v, Off, and 120v .....	167
Figure 195: Toggle Switch Connections .....	168
Figure 196: Battery Charger Relay .....	169
Figure 197: Wireless Light Switch .....	170
Figure 198: Tail Light Bracket (Inside).....	170

Figure 199: Tail Light Bracket and Tail Light .....	171
Figure 200: Tail Light Wiring .....	172
Figure 201: Amber Side Light .....	172
Figure 202: Amber Side Light Wiring .....	173
Figure 203: Wire Loom on Tail Light .....	173
Figure 204: Wire Loom on Connection to Tow Vehicle .....	174
<b>Finishing Touches (Phase 13)</b> .....	175
Materials List .....	175
Tool List.....	175
Process Steps.....	175
Figure 205: Fender Aligned to Tire.....	177
Figure 206: Fender with Tire Removed.....	177
Figure 207: Door Hold Back .....	178
Figure 208: Stabilizer Jack (Up) .....	178
Figure 209: Stabilizer Jack (Down) .....	179
Figure 210: Measure and Cut Interior Window Trim.....	179
Figure 211: Window Trim Installed.....	180
Figure 212: Wood Putty in Seams and Holes.....	180
Figure 213: Interior Caulking.....	181
Figure 214: Spring Sash Rod.....	182
Figure 215: Curtain Installed on Door.....	182
Figure 216: Curtain Installed on Wall.....	183
Figure 217: Aluminum Kick Plate .....	184
Figure 218: Foam Mattress .....	185
Figure 219: Aluminum Skin Cut over Frame Bolt.....	186
Figure 220: Amber Reflector Bolt Hole .....	186
Figure 221: Amber Reflector Covering Bolt Hole.....	187
Figure 222: Mask Off Before Caulking Front Seam .....	187
Figure 223: Front Seam Caulking .....	188
Figure 224: Galley Hatch Edge Trim .....	189
Figure 225: Trailer Lock Set.....	190
Figure 226: Galley Hatch Support .....	191

Figure 227: Optional Stainless Steel Galley Counter Top..... 192  
**Material Supply Sources** ..... 193