



## Winterization

- Drain Water from tank and lines
- Remove water filter if equipped
- Remove drain plug or anode rod from the water heater
- Bypass water heater
- Fill water system with RV antifreeze
- Add antifreeze to all p-traps and toilet bowl
- Add antifreeze to grey and black tanks\*

\*Note: Grey and Black tanks need to be empty and are the responsibility of the coach owner.