



## How to use C-Rings and Batons for Wide Windows



## DH Solution Goal:

By using this guide you will be able to offer fully functioning pleated draperies over large windows (96" +) without needing to use a traversing rod system.

## Tools Needed

1. Tape Measure
2. Level
3. Ladder
4. Drywall/Wall Anchors
5. Wood Pencil
6. Power Drill
7. Appropriate Size Drill bits for anchor & screws

## » Benefits of Using C-Rings on Wide Windows

- Available in Kirsch Wrought Iron & Designer Metals Stationary Collections.
- Ideal for stationary light weight draperies that get traversed occasionally
- Provides an option to pull by hand or make use of a Decorative Baton if you don't want to touch draperies.
- Used to traverse pass a center support bracket
- Allows for easy operation across the entire window expanse when using the baton
- Lower Price Point option than ordering a custom Traverse Rod



## Parts Needed

1. Designer Metals/Wrought Iron Brochure
2. Designer Metals/Wrought Iron Swatch Page
3. Fixed Width Rod
4. Splice (x1)-for applications wider than 8'
5. C-Rings (7x per pack)
6. Baton w/ C-Ring (x1 for one way draw; 2x for 2-Way draw)
7. Standard Bracket (x2)
8. Center Bypass Brackets; to be placed no greater than 48" apart



# C-Rings and Batons for large Windows



1. Using the Standard Bracket; mark where you want the side brackets placed for each side of the window. These brackets will be the main supports of the entire rod.
2. Mounting Brackets to Wall:
  - Measure from Ceiling to desired height of rod.
  - Mark Proposed bracket locations
  - Make sure these marks are level with each other
  - Ensure spacing between Center Bypass bracket is no greater than 48'
  - Ensure that you use the proper screw when installing (wood screw for studs, hollow-wall anchor for drywall, etc).
3. Attach Rings and Hang Drapery. Place Baton at leading end of fabric.



# C-Rings and Batons for large Windows



Download the PDF "1 - Pager" of this training

**kirsch** **Drapery Hardware Solutions**  
How to use C-Rings & Batons for Wide Windows

**Kirsch, DH by Application**

**1. Mount your Standard & Center Bypass Brackets. Ensure spacing between bracket is no greater than 48".**

**2. Install Fixed Width Pole onto brackets. (When using splice, make sure to support with center bypass bracket at the joint)**

**3. Attach C-Rings and Baton to rod; hang draperies onto rod. (1x baton for 1-way draw, 2x for two-way)**

**Benefits of using C-Rings on Wide Windows**

- Available in Kirsch Wrought Iron & Designer Metals Stationary Collections.
- Ideal for stationary light weight draperies that get traversed occasionally
- Provides an option to pull by hand or make use of a Decorative Baton if you don't want to touch draperies.
- Used to traverse pass a center support bracket
- Allows for easy operation across the entire window expanse when using the baton
- Lower Price Point option than ordering a custom Traverse Rod

**Download a More Detailed Product Guide/Installation Instructions!**

**Additional Sales Tools Are Also Available!**

- A summary of this training is available in a 1-page PDF
- To Download the PDF, visit your Kirsch Master Distributor's website
- Also see other great *Kirsch Drapery Hardware Solutions* training shorts





# Thank You!

