

# 1020 Divider Installation Instructions



Above picture shows properly installed poly-tipped crop dividers. The original spring assembly has been removed. Re-use bolts. Picture below shows the hole in the end plate on the right side of header in which the carabineer clip hooks into.



*Arrow points to the hole in which carabineer clip is hooked into.*

The chain is then hooked into carabineer clip for desired height of crop divider tip. Hole placement is the same on the left side as well.

***Included: 2 Springs & 2 Chains with Carabineer Clip***

Once crop divider is installed and the carabineer clip is hooked into the end plate, hook the spring in middle of chain with slack between the hooks as shown in picture. The spring helps take the weight off of the divider tip.

