



## Cradle installation H-16

1. Mark and drill 5/8 inch holes in the Cradle...Make sure not to drill in the wrong direction. "Mark twice...Drill once"
  2. Mark and drill three (3) holes in 5/8 inch Flat Washers (x4)
  3. Screw Flat Washer to Cradle aligning hole in cradle with hole in the washer.
  4. Remove keeper pin and remove inside bracket from Trailer.
  5. Slide Rubber Roller off Dowel and save for later.
  6. Slide Cradle onto dowel. Mark and cut two (2) Spacers from the Rubber Roller with 4" grinder using a cut-off wheel. I used the tapered ends of the Roller.
  7. Pull Cradle off dowel and reload with spacers on each side.
  8. Replace the keeper pin.
- \*Repeat for the opposite side. With the proper tools time to complete should be about one hour.







