

Be sure to grease the pivot bolt bushing before installation!

Right(exhaust) side of frame only

Lower engine mount hole

Front of frame

Drill 7/16" hole on both sides of frame

1/8" hole only needed on the right(exhaust) side of frame

Brake drum cover bolt hole

Lower exhaust bolt hole

Skid plate bolt hole

