How to measure two piece replacement sling.

Before you start measuring for your replacement sling here are a few things to keep in mind. All replacement slings are cut to the customer's specifications. It is important to provide us with the most accurate measurement possible. Measuring the existing sling will not provide an accurate measurement, so you will be measuring the frame. All replacement sling come with new spline installed.

6 measurements are required for two piece sling.

Back Section:

Before measuring make sure all bolts are tight on the back and seat of the chair.

Measuring the Width. When measuring the frame for width two measurements should be taken. Take one measurement about 3" inches from the top of the chair and one about 3" inches from the bottom of the chair. Measure the seat from the outside of the groove on the left sling rail to the outside of the groove on the right sling rail. (See image A)

Top Width: Start at the rail on one side and measure in a straight line across the chair to the rail on the other side about 3" from the top

Bottom Width: Start at the rail on one side and measure in a straight line across the chair to the rail on the other side about 3" inches from the bottom.

Measuring the Length, Measure the chair from top to bottom of the sling rail following the contour of the chair.

Seat Section:

Measuring the Width. When measuring the frame for width two measurements should be taken. Take one measurement about 3" inches from the top of the chair and one about 3" inches from the bottom of the chair. Measure the seat from the outside of the groove on the left sling rail to the outside of the groove on the right sling rail. (See image A)

Top Width: Start at the rail on one side and measure in a straight line across the chair to the rail on the other side about 3" from the top

Bottom Width: Start at the rail on one side and measure in a straight line across the chair to the rail on the other side about 3" inches from the bottom.

Measuring the Length, Measure the chair from top to bottom of the sling rail following the contour of the chair.



