

CUT ALONG THIS LINE

PASSENGER SIDE SEAT BASE

DRIVER SIDE SEAT BASE

CUT SMALL HOLES OUT WITH KNIFE,  
WITH TEMPLATE IN PLACE, MARK HOLES WITH MARKER.

4.63

2.38

PASSENGER SIDE STEP PLASTIC TRIM

DRIVER SIDE STEP PLASTIC TRIM



DRIVER SIDE REAR HOLE



PASSENGER SIDE REAR HOLE

## DRILL TEMPLATE

### SPRINTER 3500 CHASSIS CAB

### FRONT BOLT-ON APPLICATION

4.50

STEP 1. REMOVE TOP PLASTIC TRIM PIECE OVER STEP & RUBBER FLOOR MATERIAL  
(THREE TORX SCREWS PER SIDE).

STEP 2. REMOVE OR PULL OUT OF PLACE THE RUBBER FLOOR MATERIAL.

STEP 3. USE TEMPLATE TO DRILL TWO HOLES PER SIDE WITH 1/2" DRILL BIT.

DO NOT RE-INSTALL FLOOR MATERIAL UNTIL INSTALLATION IS FINISHED.

4.63

CUT ALONG THIS LINE

CUT ALONG THIS LINE



DRIVER SIDE FRONT HOLE



PASSENGER SIDE FRONT HOLE

CHECK SCALE OF PRINT WITH MEASUREMENTS SHOWN  
IF MEASUREMENTS ARE OFF, USE MEASUREMENTS SHOWN