<u>Ray's Leather Repair & Restoration</u> <u>Cleaning & Conditioning Instructions</u>

NOTE: PLEASE DETERMINE WHAT TYPE OF LEATHER YOU OWN BEFORE YOU BEGIN CLEANING OR CONDITIONING. CONTACT A PROFESSIONAL LEATHER TECHNICIAN PRIOR TO APPLICATION.

Cleaning : Ray's Cleaner comes in a clear bottle and is concentrated. Dilute 50% with water (one part water to one part cleaner). **Only on protected leathers** soap up and lather. Scrub the surface with a mild sponge or rag. A little soap goes a long way so use it sparingly. Let sit for a few minutes then wipe dry with a non-fibered rag or towel. (i.e. terrycloth, blue shop rags or sham-wow) May need to be repeated until the leather is clean. Work on one panel at a time, making sure it is evenly absorbing. This is very important with natural, or semi-aniline leathers. If **not** applied evenly it can cause spots or stains. Please consult a professional leather technician **"prior to application"** if you have any questions or concerns.

NOTE: OIL DAMAGE, BODILY FLUIDS, INK STAINS, NU-BUCK & SUEDE LEATHERS, CAN NOT BE TREATED THIS WAY. THIS APPLICATION MAY MAKE THE PROBLEM WORSE. PLEASE CONTACT A PROFESSIONAL LEATHER TECHNICIAN PRIOR TO APPLICATION.

Conditioning/Protecting : Ray's conditioner comes in a clear bottle and is **not** concentrated. It is yellow in color and has a slight odor. Saturate a non-fibered small rag or towel (i.e. terrycloth, blue shop rags or shamwow) and ring out slightly. Keep in mind a little conditioner goes a long way. Lightly wipe down the entire leather evenly. Work on one panel at a time, making sure it is evenly absorbing. This is very important with natural, or semi-aniline leathers. If **not** applied evenly it can cause spots or stains. Please consult a professional leather technician "**prior to application**" if you have any questions or concerns. The conditioning process can take between 8 to 14 hours at room temperature. We recommend conditioning your leather before you go to bed at night. In the morning, wipe the leather down with warm water well rung out on a non-fibered rag. Let air dry for another 2 to 4 hours. If the leather still feels slightly sticky, give it a few days. It may have been too cold during application or your leather just needs more time to dry.

NOTE: STILL UNCERTAIN? DON'T HAVE THE TIME OR THE ENERGY TO DO THIS YOURSELF? CONTACT RAY'S LEATHER REPAIR & RESTORATION FOR AN ESTIMATE TO HAVE YOUR LEATHER PROFESSIONALLY CLEANED & CONDITIONED!