

TMP, LLC.- Knoxville, TN 37932 - (701)361-9128 - www.tmpllc.net

Installation/Instructions: Tuff Deck

Installation Steps

Step 1:

Look over the area where the Tuff Deck should be mounted to make sure that there is enough room to install.

Step 2:

Remove all components from package and carefully move Tuff Deck to the frame where it will be mounted to assure Tuff Deck is mountable at that area. Holes are molded on Tuff Deck for easy and fast mounting.

Step 3:

Insert all four bolts in top mounting holes and attach a mounting clamp to each bolt; keep mounting clamp loose so that mounting clamps can freely be turned to dismounted position or to one side.

Step 4:

Rotate all four mounting clamps so that clamps are in mounting position under frame. Lightly tighten all four mounting clamps and make sure that the Tuff Deck is perfectly secured, level and tight with frame. Tighten all bolts tightly and secure to complete installation. Re-torque periodically or as needed. Note: Use only ratchet and hand wrench to install/re-torque. DO NOT use air/impact wrenches.

This product, when used as recommended or under any ordinary conditions, should not present a health and safety hazard. However, use or processing of this product not in accordance with the product's recommendations or not under ordinary conditions may affect the performance of the product and may present potential health and safety hazards.

Copyright 2017 TMP, LLC. 12-17