








Santa Fe Landscapes & Water Gardens

PondGard Installation Detail

Install a Repair Patch Using a PondGard EPDM Liner Repair Kit

	<p>Step 1- Ensure the liner is dry and free of mud or other contaminants.</p>
	<p>Step 2- Apply the QuickPrime Plus primer by pouring a small amount onto the scrubber pad and applying it to the surface of the PondGard beyond the perimeter of the area to be repaired with a patch.</p>
	<p>Step 3- Test the primer flash-off by touching the primed area with your finger and pushing forward at an angle. The primer should not string as your finger is moved up and away.</p>
	<p>Step 4- Install the QuickSeam patch by peeling away the release paper and placing the patch over the damaged area of the liner.</p>
	<p>Step 5- Roll the patch evenly over the area to be repaired in order to properly mate the patch and liner together.</p>