

# **McGAUGHY'S Bump Stop Instructions**

1. The stock bump stop assembly needs to be cut off from your frame. You can cut it with a die grinder or sawzall.
2. The rear-end housing has a flat saddle welded to the top on each side that the original bump stop would make contact with. At the rear most point drill a 3/8" hole and install the hexagon shaped bump stop and tighten nut down (supplied with kit).
3. Check that no brake lines or wires may interfere with any part of the rear-end housing, if so, move them accordingly.