



HEZE XINGLIN WOOD INDUSTRY CO., LTD

INSTALLATION OF EXTERIOR TRIM BOARDS

When using Heze Xinglin Wood Industry Co., LTD products as an exterior trim or siding, always design and install in accordance with generally accepted “best practices” for wood construction and moisture management. Always follow local building codes.

To insure proper installation:

Keep product clean and dry at the jobsite and prior to installation. Product must be stored off the ground, flat and protected from the elements. Inside storage is recommended.

Insure that product is dry, less than 19% prior to installation.

Use proper flashing techniques for all wall penetrations. Do not allow moisture to be trapped behind the exterior envelope of the structures. Do not allow direct contact with concrete, asphalt, brick or any exterior floor surface.

Use high grade exterior caulking and sealants. Do not caulk areas that will prevent moisture from escaping, such as under windows.

Fasteners should be driven flush if possible, if countersunk, fill with exterior grade wood putty, allow to dry, then sand smooth and prime prior to finish.

Any exposed or unfinished cuts should be primed immediately.

Paint the products as soon as they are hung, insuring that product is clean and dry before painting.