



## Simmons Mounting Bracket Chart - YAMAHA





	Stamp	Yamaha	Installation Description
	AC-12	2015-2018 4-Stroke models that have Arctic Cat Front Ends: Viper, SideWinder,	Use with Sleeves, Spacers, Angles, Rubber Bumpers Provided. Thick end of bumper goes to the rear.
	YAM-V4	1997-2018 Models	Use OEM rubber bumper. Sleeves and spindle bolts provided.
	YAM-V4	ALL YAMAHA XTX CHASSIS	Use OEM rubber bumper. Spindle bolts, sleeves, spacers and angles provided. May need to cut rubber bumper around rear nuts to fit.
	YAM-MT	2007-2018 Nytro MTX, Phazer MTX	Use OEM rubber bumpers.
	W-YAM	1996-Older Models	Use rubber bumpers, angles, spindle bolts and spacers provided.

\*All VK 540 models use the Wide Yamaha set up.

## Simmons Mounting Bracket Chart - POLARIS

	Stamp	Polaris	Installation Description
	POL-IQ	2006-2018 Polaris Chassis with A-Arms	Use rubber bumpers, angles, spindle bolt and sleeves provided. Thick end of rubber bumper goes to the rear.
	POL	2005-older Chassis with trailing arms	Use rubber bumpers, angles and spindle bolts provided. Thick end of rubber goes to the front.





## Simmons Mounting Bracket Chart - SKI-DOO

	Stamp	Ski-Doo	Installation Description
	SD	2017-2018 <b>850</b> Models take "SD-17" welded mounting bracket	Use OEM rubber bumpers. Spindle bolts and spacers provided.
	SD	2000-2018 Regular Ski-Doo Chassis: Summit, REV, MXZ, Expedition, Renegade	Use OEM rubber bumpers. Angles, spindle bolts and spacers provided. Use spacers; one on each side of spindle to center the spindle over the ski.
	SD-SK	All Ski-Doo Skandic Models	Use OEM rubber bumper. Angles, spacer block, bolts, nuts and spacers provided.
	OLD SD	All 1999 and Older models. Except for the 1999 600 & 700 models which take the SD setup	Use rubber bumpers, angles, spindle bolts and spacers provided.

\*The Ski-Doo Expedition models take the "SD" set up. Not the Skandic!

\*There is a special mounting bracket for the Ski-Doo Tundras around the year 2000. Val welds these shoes together.

## Simmons Mounting Bracket Chart - ARCTIC CAT

	Stamp	Arctic Cat	Installation Description
	AC-16	2012-current Arctic Cat Models	Use rubber bumpers, angles, spindle bolts, sleeves, and spacers provided. Thick end of rubber bumper goes to the rear.
	AC-10	2010-2011 Arctic Cat Models	Use OEM rubber bumper. Angle and spindle bolt provided.
	A-C	1997-2009 Arctic Cat Models	Use OEM rubber bumper. Angle and spindle bolt provided.
	WIDE AC	1996 and Earlier models	Use OEM bumper by drilling out rivets then insert OEM rubber bumper. Make sure "front" is to the front. Use OEM spindle bolt & nut.