

Bayou Goat Mounts LLC

Installation Instructions for BGM003

- Locate and remove rubber mat in tray above radio.
- Using a torx #20 bit and screwdriver, remove the two screws that hold the tray in place, making sure to leave the tray in place.
- Place the rubber mat on the BACK side of the diagram using the placement holes in the diagram. Make sure the shape of the mat matches the shape of the diagram.
- Using a razor knife or scissors cut thru the diagram into the rubber mat to form the slots.
- Slide mount thru the cut slots in the rubber mat, NOTE! There's a half circle on the mount base that should be facing the driver. Place back on to the dash, lifting the sides of the rubber mat and reinstall the screws and tighten.

BAYOU GOAT MOUNTS LLC. P.O. BOX 2796 OPLEOUSAS, LA. 70571 (337)-945-7771

bayougoatmounts@yahoo.com

Contact Info: www.bayougoatmounts.com

