

Setting optimum height of heavy bag:

Outstretch arm horizontally when in fight stance. Your arm should impact the bag no more than $\frac{1}{3}$ from the top of the bag. Remove chain links accordingly.

