



Cold Starting Tip Choke Jet

It has been proven that drilling the choke jet in the float bowl out to around 1.00mm for 2200 engines or 1.20mm for 3300 engines will help with cold starting. Enlarging the choke jet enables more fuel to be pulled up when starting on the choke circuit. Carefully remove the jet from the bowl with a flat blade screw driver. Carefully drill by hand after removal from the carburetor bowl. Clean up any drill debris and carefully reinstall using a blade screw driver.

