

DETENTION STRUCTURE

Conventional dry detention practices are used to reduce the peak discharge and detain runoff for a specified short period of time. Detention volumes are designed to completely drain after the design storm has passed. Detention is used to meet overbank flood protection criteria, and extreme flood criteria where required