

Frozen Right - Tray Divider Instructions



1. Place divider into tray, and use a long box cutter blade to gently cut upwards; keep the blade against the tray.

2. Test the fit in tray. If needed you can always trim more off, so make your initial cut longer.



3. Bring 4" of water to a rolling boil. Then boil dividers for 5 min to sterilize and clean them. Do not add dividers until water is boiling.