



One – Line up side with base, use slot and holes to assist



Two – Mount/place RPiB+ on base/side



Three – Add the second side, line up slots with inputs/outputs



Four – Add the logo lid, orient whichever way you like



Five – Attach USB/Ethernet end plate, start by placing slots over top lugs - note slots are different length at top compared to bottom



Six – Compress the bottom lugs gently and ease end plate into position. Be careful parts are delicate



Seven – Repeat with opposite end plate – Job done.

Please Note:

1. These notes apply to the wood or acrylic case variants.
2. Please remove protective film or paper from acrylic pieces before assembling.
3. The laser cut pieces of this wood or acrylic case are designed to be handled carefully when assembling the case. Take care to ease parts together, do not force fit.
4. If it does not seem to be fitting properly, stop and try again.
5. Electro-Resales is not responsible for parts broken during assembly.

Any questions please email me at: resalese@gmail.com