



## Kit Installation Directions

### UNDERGROUND:

- 1) Dig a post hole 30" deep, 25' apart, located where you would like the barrier net to be positioned.
- 2) Place the PVC sleeves in the hole, allow a few inches to stick up above the grade.
- 3) Using one of the bottom sections of the 2 piece pole, slide it into the PVC sleeve and use a level to make sure the PVC sleeve is plumb while you pour the concrete around the outside of the PVC sleeve. (I included a letter with your order that specifies which concrete to buy and how much for each pole)
- 4) Remove the pole used for leveling and repeat 1-3 for the second hole 25' away.
- 5) Remove the leveling pole from the second PVC sleeve and let the concrete set-up over night.

### ABOVE GROUND:

- 1) Place the two top pole pieces in the 2 PVC sleeves. (these have a small hole drilled through the top)
- 2) Slide one bug nut onto the cable.
- 3) Take one end of the wire rope and feed it through the small hole at the top of the pole while it is standing up in the PVC sleeve.
- 4) Double back the wire rope and slide the bug nut over the end of the cable and tighten the bug nut squeezing the wire rope on its self.
- 5) Repeat #4 at the other pole. It's a good idea to have 2 people at the second pole. One person to tighten down on the bug nut, while the other person pushes the pole toward the middle to take up slack in the cable.
- 6) Place the two blue caps on the top of the poles.
- 7) Roll out the netting on the ground, and place a snap clip every 2' along the top of the net.
- 8) Pick up the netting at one end and begin clipping it to the cable one after another, without crossing the clips.
- 9) Remove the two poles from the PVC sleeves and lay on the ground.
- 10) Take the bottom pole sections and insert them into the top sections.
- 11) One end at a time, slide the assembled pole into the PVC sleeve.
- 12) Use the provided Velcro to hold the netting to the poles at each end.
- 13) Please note, that if the net does not lay on the ground, it will. Over time it will stretch. You can stretch it by hand or put some weights at the bottom, to speed up the process.

Congratulations you have completed the barrier net installation.

ENJOY and TELL YOUR FRIENDS ABOUT ALL SPORT NETTING!!!