

International Roofing Expo

February 1-3, 2022 New Orleans, Louisiana

Fundamentals of insulation, vapor retarders, air barriers and attic ventilation



Mark S. Graham

Vice President, Technical Services National Roofing Contractors Association Rosemont, Illinois

1

Topics

- Some fundamentals
- Insulation
- Vapor retarders
- Air retarders
- Attic ventilation
- Questions... and other related topics

Some fundamentals

3

Phases of moisture

- Gas phase -- moisture vapor
 - Above 212 F
- Liquid phase -- water
 - 32 F to 212 F
- Solid phase -- frost or ice
 - Below 32 F



Humidity

The amount of water vapor in the air.

Relative humidity

Relative humidity is defined as the ratio of the partial pressure of water vapor in a parcel of air to the saturated vapor pressure of water vapor at a prescribed temperature.

5

Dew point

Condensation temperature

The temperature at which the air can now longer hold all of its water vapor, and some of the water vapor must condense into liquid water.


At 100% relative humidity, the dew point temperature and real temperature are the same, and condensation begins to form.

Psychrometrics

The field of engineering concerned with the determination of physical and thermodynamic properties of gas-vapor mixtures.

Derived from the Greek *psuchron* meaning "cold" and *metron* meaning "means of measurement".

7



Thermodynamics

In physics, the study of energy conversion between heat and mechanical work, and subsequently the macroscopic variables such as temperature, volume and pressure.

Derived from the Greek *therme* meaning "heat" and *dynamis* meaning "power".

9

First law of thermodynamics

Energy can be transformed (changed from one form to another), but cannot be created or destroyed.

Law of conservation of energy

 $Solid \rightarrow Liquid \rightarrow Gas \rightarrow Liquid \rightarrow Solid...$

Second law of thermodynamics

The entropy of an isolated system which is not in equilibrium will tend to increase over time, approaching a maximum value at equilibrium.

 $Heat \rightarrow Cold$

11

A practical application...



Is the glass "leaking"?

No... but we are studying thermodynamics

Diffusion OIRRO OI AND SHEET OF GYPSUM DIFFUSION DIFFUSION 1/3 QUART OF WATER OVER A PERIOD OF ONE MONTH

13

Diffusion terminology

Permeability: the time rate of vapor transmission through a flat material of a unit thickness induced by vapor pressure difference between two specific surfaces under specified temperature and humidity.

Diffusion terminology

Permeability: the time rate of vapor transmission through a flat material of a <u>unit thickness</u> induced by vapor pressure difference between two specific surfaces under specified temperature and humidity.

Expressed as "perm-inch" units

15

Diffusion terminology

Permeance: the time rate of vapor transmission through a flat material or construction assembly induced by vapor pressure difference between two specific surfaces under specified temperature and humidity.

Expressed as "perm" units


Material ³	Permeance	<u>Permeability</u>
	(perm) ¹	(perm•inch)1
Construction materials:		
Concrete (1:2:4 mix)		3.2
Brick masonry (4 inches thick)	0.8	
Concrete block (8 inches thick, cored)	2.4	
Plaster on metal lath (3/4 of an inch thick)	15	
Plaster on wood lath	11	
Gypsum wall board (3/8 of an inch thick, plain)	50	
Hardboard (1/8 of an inch thick, standard)	11	
Built-up roof membrane (hot applied)	0.0	
Plywood (1/4 of an inch thick, Douglas fir, exterior glue)	0.7	
Plywood (44 of an inch thick, Douglas fir, interior glue)	1.9	
	1.9	
Thermal insulation materials:		
Air (still)		120
Cellular glass		0
Expanded polystyrene		2.0-5.8
Extruded polystyrene		1.2
Mineral wool (unprotected)		116
Polyisocyanurate ⁴		
Unfaced	2.77-4.49	
Foil-faced	.03	
Glass fiber-faced	<1.0	
Plastic and metal foils and films:		
Aluminum foil (0.001 inches thick)	0.0	
Polyethylene (0.004 inches thick)	0.08	
Polyethylene (0.006 inches thick)	0.06	
Building paper, felts, roofing papers:		
Saturated and coated roll roofing (65 lbs./100 ft.²)	0.05	
Kraft paper and asphalt laminated, reinforced (6.8 lbs./100 ft.2)	0.3	
15-lb. asphalt felt	1.0	
15-lb. tar felt	4.0	
Asphalt (2 oz./ft.²)	0.5	
Asphalt (3.5 oz./ft.2)	0.1	
$Self-adhering\ polymer-modified\ bitumen\ membrane\ (0.040\ inches\ thick)$	0.12	
Roof membranes		
Built-up roofing	<0.1	
Polymer-modified bitumen	<0.1	
EPDM	< 0.1	
Thermoplastic	< 0.1	
The NRCA Roofing Manual: Architectural Metal Flashing and Condensat	ion and Air Leakage Cont	rol-2022
	Condensation and Air Lo	akago Control
Condensation and Air Leakage Control Chapter 1—Fundamentals of		akage Control


Vapor retarders

Classification	<u>Permeance</u>							
Class I vapor retarder	0.1 per or less							
Class II vapor retarder	1.0 perm or less, and greater than 0.1 perm							
Class III vapor retarder	10 perm or less, and greater than 1.0 perm							
Permeance determined according to ASTM E96, Test Method A (desiccant method								

NRCA recommends effective vapor retarders have perm-ratings of 0.5 or less

or dry cup method)







Air leakage, not vapor diffusion, can and does cause most of the moisture problems building envelopes suffer.

21


Now, pulling all these principles and fundamentals together into a roofing-specific example....






Historically, most roof systems have effectively performed as "self-drying roofs"...

25






Unintended consequences

Unintended consequences are outcomes that are not the results originally intended by a particular action.

The unintended results may be foreseen or unforeseen, but they should be the logical or likely results of the action



NRCA's recommendations specific to "cool" roofs

- Adhered roof covering (membrane)
- 2 or more layers of insulation
- Off-set board joints on insulation

--or--

- Don't rely on the "self-drying" concept:
 - Consider providing for a properly-placed vapor retarder

Thermal insulation

31

Principles of thermal insulation

British thermal unit (Btu): the energy required to raise the temperature of 1 pound of water 1 degree Fahrenheit (F).

Principles of thermal insulation

Thermal resistance (R): a relative measure of a material's or an assembly's resistance to heat flow; the reciprocal of the material's thermal conductance (C) or an assembly's thermal transmittance (U).

$$R = 1/C$$
 or $R = 1/U$

R-values are readily additive (unlike k-values and C-values). Therefore $R_T = R_1 + R_2 + R_3 = ...$

33

Long-term thermal resistance (LTTR)

Determined using ASTM C1303 or CAN/ULC-S770


R-value estimate based upon a 15-year time-weighted average, corresponding to the product's estimated R-value 5-years after manufacturing


Long-term thermal resistance (LTTR)

Determined using ASTM C1303 or CAN/ULC-S770

R-value estimate based upon a 15-year time-weighted average, corresponding to the product's estimated R-value 5-years after manufacturing

35







The Energy Code dictates minimum levels of thermal insulation for building energy efficiency


 The Building Code dictates minimal levels of insulation for fire classification purposes

37











	0.4	ND 1		E THERMAL ENVELOP						4 EXCEPT MARINE						6				7	8		
CLIMATE ZONE	All other Group R		All other Group R		R All			\rightarrow			roup R	All other				All other	-		All othe	er Group R			
Roofs														,									
Insulation entirely above roof deck	R-20ci	R-25ci	R-25ci	R-25ci	R	-25ci	R-2	5ci	R-30	ei I	R-30ci	R-	30ci	R-30	ci	R-30ci	R-	30ci	R-35c	i R-35ci	R-35ci	R-35ci	
Metal buildings ^b	R-19 + R-11 LS	R-19 + R-11 LS	R-19 + R11 LS	R-19 + R-11 LS	1	-19 + 11 LS	R-19 R-11		R-19 R-11 I	1 -	R-19 + R-11 LS		19 + 1 LS	R-19 R-11	- 1	R-25 + R-11 LS		R-30 + R-30 + R-11 LS			R-25 + R-11 + R-11 LS	R-25 + R-11 + R-11 LS	
Attic and other	R-38	R-38	R-38	R-38	I	R-38	R-3	38	R-49)	R-49	R	-49	R-4	9	R-49	R	-49	R-60	R-60	R-60	R-60	
	n letter oppsånden bj mythol tid bleefal comerciet act	ATION CODE®	Motal framed Wood framed and other	R-5ci 4 R-13 + R-3.8ci	R-13 + R-5ci R-13 + R-3.8ci or R-20	R-13 + R-5ci R-13 + R-3.8ci or R-20	R-7.5ci R-13 + R-3.8ci	R-13 + R-7.5ci R-13 + R-3.8ci or R-20	R-13 + R-7.5ci R-13 + R-3.8ci or R-20		R-7.5ci R-13+ R-3.8ci or R-20	R-13+ R-10ci R-13+ R-7.5ci or R20+ R3.8ci		R-13 + R-12.5ci R-13 + R-7.5ci or R-20 + R-3.8ci	R-12.5 R-13 - R-7.5	rei R-12.5ci + R-13 + ci R-7.5ci 0+ or R-20 +	R-13 + R-15.6ci R-13 + R-7.5ci or R-20+ R-3.8ci	R-13 +	R-13 + R-18.8ci R-13 + R-18.8ci				
	Wells, below grade Wells,																						
	debulke sufts SCRNSI AGE		Mass ^e Joist/framing	NR R-13	NR R-13	R-63ci R-30	R-83ci R-30	R-10ci R-30	R-10ci R-30		R-16.7ci R-30	R-14.6ci R-30	R-16.7ci R-30	R-16.7ci R-38	R-16.7 R-38		R-20.9ci R-38	R-23ci R-38	R-23ci R-38	:			
	find. Style user on SMINT, AND S. R		Unheated slabs	NR	NR	NR	NR	NR	R-10 for 24" below	R-15 for 24" below	R-15 for 24" below	R-15 for 24" below	R-20 for 24" below	R-20 for 24" below	R-20 f 24" below	48°	R-20 for 48" below	R-20 for 48" below	R-25 for 48" below				
	gici to dvil and d		He ated slabs ^e	12" below+	R-7.5 for 12" below+ R-5 full slab	R-7.5 for 12" below+ R-5 full slab	12* below+	R-10 for 24" below+ R-5 full slab	24" below+	R-15 for 24" below+ R-5 full slab	24* below+	R-15 for 36" below+ R-5 full slab	R-15 for 36" below+ R-5 full slab	R-15 for 36" below+ R-5 full slab	R-20 f 48" below R-5 fu slab	for R-20 for 48" below+ all R-5 full	R-20 for 48" below+ R-5 full slab	R-20 for 48" below+ R-5 full slab	R-20 for 48" below+ R-5 full slab	СОМИ			
	THE PROPERTY OF THE PROPERTY O	C4-3	For SI: 1 inch = 2: ci = Continuous In a. Assembly decic b. Where using R c. R-5.7ci is allow zonally, with u d. Where heated si e. "Mass floors" si f. "Mass walls" si g. The first value i	isulation, NR = riptions can be to value complian- red to be substitu- ingrouted cores. labs are below a shall be in accordall be in accordall.	No Requi lound in A ce method ated with filled with grade, bek dance with lance with	rement, LS ANSI/ASHB d, a thermal concrete bl- h materials low-grade w h Section C h Section C	E Liner Sy: R AE/IESN A I spacer bloc ook walls oo having a ma ralls shall oo (402.2.3.	stem. A 90.1 App ik shall be complying eximum the comply with	pendix A. e provided, o with ASTM hermal cond th the exterio	otherwise a C90, ungr activity of or insulatio	use the U-fac routed or par f 0.44 Btu-in. on requireme	ially grounds of F. its for hea	ted at 32 in ted slabs.	ches or less	on cente	er vertically and		or less on	center hori-	MERCIAL ENERGY EFFICIENCY			





Vapor retarders

45




Vapor retarders should be considered

NRCA guidelines -- Low-slope roof assemblies

- Climate Zones 6A, 7 or 8
- High interior humidity occupancies (swimming pools)
- Coldest month < 40 F, interior RH ≥ 45%
 - US Army CRREL method enhancement
- Where there is a vapor retarder in the wall assembly

47



US Army CRREL method

Vapor retarder determination (CRREL: Cold Regions Research and Engineering Laboratory)


Enhances the "Coldest month < 40 F, interior RH ≥ 45%" guideline:

- Applies to adhered roof coverings (only)
- Provides interior RH thresholds for throughout the U.S. (68 F design interior temperature)
- Provides RH threshold corrections for design interior temperatures other than 68 F

49

US Army CRREL method


Vapor retarder determination



Maximum allowable design interior humidity (before use of a vapor retarder is suggested)

US Army CRREL method

Vapor retarder determination




Temperature correction (other than 68 F)


51

Vapor retarder fundamentals

- Evaluate the dew point temperature during winter design conditions (in North America)
- To prevent the formation of condensation on the interior side of a vapor retarder, the temperature at the vapor retarder level must be warmer than the dew point temperature.


Position the vapor retarder as close to the "warm side" as possible.







Air retarders


55





The Energy Code dictates minimum air retarder requirements

















Roof system manufacturers should be providing air retarder information, including construction details specific to their products functioning as an air retarder.

63








Attic ventilation

67



Research has shown there is little or no technical basis for these historic attic ventilation guidelines

69







Static ventilation configuration

APPROX, 50%, OF TOTAL VENTILATION AREA AT RIDGE

• Balanced


• 1:150 ratio


• Jan. ≤ 30 F:


— Vapor retarder

• Slope 8:12:

— Increase ventilation







CHAPTER 12

INTERIOR ENVIRONMENT

| The content of the departs Capater 12 provides minimum provisions for the heater of haddings—the recognise emissions of violation, lighting, and space heating are devely regulated in this chapter and is compared with the intermitonal Methoderical Cool* and the Intermitonal Energy Consensation Cool* and the Intermitonal Energy Consensation Cool* Allerium room size, maximum rooms-room seared transmission and transmission and transmission security and the Intermitorial Energy Consensation Cool* and transmission, recognisms cannot be added to the Intermitorial Energy Consensation Content (Lighting, yourd and country, sound transmission, recognisms). The provisions of this chapter shall govern ventilation, temperature, cannot distinguish the lighting point of the space, and the lighting point of the space and the lighting point of the space, and the lighting point of the space and

2021 INTERNATIONAL BUILDII
INTERNATIONAL CODE COUNCIL

ce with the Aboranteeral Mechanical Cade
has in difflations ten in A shelling unit i less
thanges per hour where tested with a blower door
use O 2 inch w. CO 90 pin a secondance with the State of the International Energy ConcernLocalization Proteins, the desiling unit shall be protected to prevent the entry of briefs, is
consistent for the International Energy ConcernLocalization Proteins, the desiling unit shall be
hormatical Mechanical Code. Abundancy care
and Group 1-2 occupantees shall be vomilated
to the Concerning the Code of the State Code of the State

120.3 Unvented attic and unvented enclosed rafter assemblies. Unvented attics and unvented enclosed roof framing assemblies created by ceilings applied directly to the underside of the roof framing members/rafters and the structural roof sheathing at the top of the roof framing members shall be permitted where all of the following conditions are most.


- The unvented attic space is completely within the building thermal envelope.
- No interior Class I vapor retarders are installed on the ceiling side (attic floor) of the unvented attic assembly or on the ceiling side of the unvented enclosed coefficients recombly indeed.
- Where wood shingles or shakes are used, not less than a 'i_-inch (6.4 mm) vented airspace separates the thingles or thakes and the roofing underlayment above the structural sheathing.

f. namenna.nel. (-) code Number autoranor en jaz 14. 3m; co. 17 PM (1977) puntant si liteme agre

75

The conditioned, unvented attic is considered a viable alternative to attic ventilation

77



Questions...

79

Mark S. Graham



Vice President, Technical Services National Roofing Contractors Association 10255 West Higgins Road, 600 Rosemont, Illinois 60018-5607

(847) 299-9070 mgraham@nrca.net www.nrca.net

Twitter: @MarkGrahamNRCA

Personal website: www.MarkGrahamNRCA.com LinkedIn: linkedin.com/in/MarkGrahamNRCA