

How to Build Your Custom Teardrop Camper

5' x 10' Trailer

5' Tall Cabin



Contact:

hennesseystealth@bigteardrop.com

Big Teardrop Campers

United States Copyright TXu 1-963-321

Contents

Introduction	12
License Agreement	13
License	13
Restrictions	13
Limited Warranty	13
Limitations of Remedies	14
Government Licensee	14
Restricted Rights Legend	14
Export Law Assurances	14
General	15
Trailer Construction (Phase 1)	16
Materials List	16
Tool List	16
Process Steps	16
Figure 1: Using Magnetic Square and Welders Clamp	18
Figure 2: Frame Supported Level and Square	18
Figure 3: Finished Outside Frame	19
Figure 4: Cross Members in Place	19
Figure 5: A-Frame Coupler Welded to Channel Iron	20
Figure 6: Tongue Set Against First Cross Member	20
Figure 7: Weld Channel Iron to Frame and Cross Member	21
Figure 8: Completed Trailer Frame	21
Figure 9: Bolt Holes for Axle Placement	22
Figure 10: Completed Trailer	22
Figure 11: Safety Chains with Welded Clips	23
Sealing Trailer Underside (Phase 2)	24
Materials List	24
Tool List	24
Process Steps	24
Figure 12: Lower Outside of Sidewall with Dado Cut and Notches for Axle Bolt Access	25
Figure 13: Lower Outside of Sidewall ¼" Notch to Fit Trailer Frame Overlap	25
Figure 14: Sheet Metal Solder Joint	26

Figure 15: Sheet Metal Pan Placed in Frame	26
Figure 16: Sheet Metal Cut to Expose Axle Bolts.....	26
Preparing Sidewalls and Subfloor (Phase 3)	27
Materials List	27
Tool List.....	27
Process Steps.....	27
Figure 17: 6mm Baltic Birch Glued to Inside Surface of Sidewalls.....	28
Figure 18: Use Staples around Edges and Brad Nails in Visible Areas	28
Figure 19: Subfloor Frame Ready for Bottom Sheet of Plywood.....	29
Figure 20: Subfloor Frame Notched for Axle Bolt Access	29
Figure 21: Use Glue on Subfloor Frame before Attaching Plywood	30
Figure 22: Attach Plywood to Subfloor Frame.....	30
Figure 23: Use Screws to Attach Plywood to Subfloor Frame	31
Finishing Sidewall Interiors (Phase 4)	32
Materials List	32
Tool List.....	32
Process Steps.....	32
Installing Subfloor, Sidewalls, and Flooring (Phase 5).....	33
Materials List	33
Tool List.....	33
Process Steps.....	33
Figure 24: Subfloor Centered on Trailer Frame	35
Figure 25: Subfloor Bolted to Trailer Frame	35
Figure 26: Using a Compass (Pencil on String), Mark and Cut 24" Front Radius	36
Figure 27: Using a Compass (Pencil on String), Mark and Cut 40" Rear Radius	37
Figure 28: Sidewall Profile.....	37
Figure 29: Door Opening Layout on Passenger Sidewall with 12" Radius.....	38
Figure 30: Sidewall with Door Opening Installed.....	39
Figure 31: Hole in Side Frame for Attaching Sidewalls	40
Figure 32: Hole in Subfloor Frame for Attaching Sidewalls	40
Figure 33: Sidewall Attached to Frame and Subfloor	41
Figure 34: Insulation Inserted into Subfloor Frame	41
Figure 35: Subfloor Top Glued and Screwed to Subfloor Frame and Spars Attached.....	42

Figure 36: Install Cedar Flooring with Glue and Brad Nails	43
Figure 37: Finished Cedar Flooring	44
Spar Installation and Interior Wall Skin (Phase 6)	45
Materials List	45
Tool List.....	45
Process Steps.....	45
Figure 38: Spars View from Back.....	46
Figure 39: Spars View from Front	47
Figure 40: Cross Members for Ceiling Vent	48
Figure 41: 3mm Baltic Birch Fit to Front Spars (Inside).....	48
Figure 42: 3mm Baltic Birch Fit to Front Spars (Outside).....	49
Figure 43: 3mm Baltic Birch Fit to Ceiling with Vent Opening (Inside).....	50
Figure 44: 3mm Baltic Birch Fit to Ceiling with Vent Opening (Outside).....	51
Cabinet Shell Construction and Installation (Phase 7)	52
Materials List	52
Tool List.....	52
Process Steps.....	52
Figure 45: 18mm Baltic Birch Cut to Fit and Sealed with Deft.....	54
Figure 46: Bottom of Front Cabinet Installed Using Jack Stand for Support	54
Figure 47: Interior Divider/Support with Pocket Screws	55
Figure 48: Front Cabinet Face Installed	55
Figure 49: Galley Wall Installed.....	56
Figure 50: Back Cabinet Bottom Installed and Attached to Galley Wall with Pocket Screws	57
Figure 51: Back Cabinet Interior Support/Divider.....	58
Figure 52: Back Cabinet Face Installed.....	59
Figure 53: Closet Shelves Installed.....	59
Figure 54: Using Pocket Screw Jig to Drill Holes in Closet Shelf	60
Figure 55: Pocket Screw Hole in Bottom of Closet Shelf	61
Figure 56: Pocket Screw in Bottom of Closet Shelf Attaching to Galley Wall.....	62
Figure 57: Furring Strip Attached to Galley Counter Top and Galley Wall	62
Figure 58: Lower Galley Cabinet and Counter Top Installed	63
Figure 59: Galley Shelf Installed.....	63

Figure 60: Closet Door Guides	64
Figure 61: 1x3 White Birch for Building Cabinet Doors	65
Cabinet Doors, Drawers, and Closet Construction and Installation (Phase 8)	66
Materials List	66
Tool List.....	66
Process Steps.....	66
Figure 62: Closet Door with Finger Hole	68
Figure 63: Closet Door Top Inside Guide	68
Figure 64: Closet Door Bottom Inside Guide	69
Figure 65: Closet Doors Installed with Outside Guides.....	69
Figure 66: Rails and Stiles for Cabinet Doors and Drawer Fronts	70
Figure 67: Layout of Door and Drawer Interior Panels	71
Figure 68: Door and Drawer Interior Panels	72
Figure 69: Rails and Stiles for Drawer Front	72
Figure 70: Routed Groove in Drawer Front Rails.....	73
Figure 71: Dry Fit Rails, Stiles, and Panel before Assembly	73
Figure 72: Pocket Screw Holes for Drawer Fronts	74
Figure 73: Drawer Front Assembled Using Glue and Pocket Screws	74
Figure 74: Jig to Position Hinge Cup.....	74
Figure 75: Hinge Cup Drilled 35mm Diameter and ½” Deep with Screw Holes Marked	75
Figure 76: Hinge with Plate Attached to Cabinet Door.....	76
Figure 77: Hinges and Plates Attached to Cabinet Door.....	77
Figure 78: Cut 4 Drawer Bottoms at 14 ¼” x 15 ¾”	78
Figure 79: If Scrap 18mm Baltic Birch is too Small, Use Pocket Screws to Increase Size.....	79
Figure 80: Attach Drawer Sides to Bottoms Using #6 ½” Wood Screws.....	79
Figure 81: Attach Drawer Backs Using #6 ½” Wood Screws	80
Figure 82: Attach Drawer Fronts Using #6 ½” Wood Screws.....	80
Figure 83: Finished Drawer	81
Figure 84: Top Hinge Plate Installed	81
Figure 85: Top and Bottom Hinge Plates Installed and Door Attached.....	82
Figure 86: Galley Cabinet Doors.....	82
Figure 87: Inside Rear Cabinet Doors.....	83

Figure 88: Inside Front Cabinet Doors	83
Figure 89: Drawer Slide Supports	84
Figure 90: Drawer Slide Supports Installed with Drawer Slides.....	85
Figure 91: Top Drawers Installed	85
Figure 92: All Galley Doors and Drawers Installed.....	86
Sink Installation, Electrical and Light Wiring (Phase 9)	87
Materials List	87
Tool List.....	87
Process Steps.....	87
Figure 93: Sink Opening	90
Figure 94: Faucet Installed (Bottom)	90
Figure 95: Faucet Installed (Top)	91
Figure 96: Water Pump Installed and Wired	92
Figure 97: Sink Drain Installed (Bottom).....	93
Figure 98: Sink Drain Installed (Top)	94
Figure 99: Drain Pass-Through Opening	94
Figure 100: Sink Installed	95
Figure 101: Water Container Lid Came Equipped with ¾" Male Spigot	95
Figure 102: Using ¾" Male to ½" Female Reducer, Connect 3/8" Barb with ½" Male Threads to Both Sides of Lid (One side goes to Pump Inlet and the Other is a Siphon Tube).....	96
Figure 103: Water Container Lid with 3/8" Hose Barb Fitting	96
Figure 104: Water Container Tie Down and Connection to Pump Inlet	97
Figure 105: Faucet Connection to Pump Outlet	98
Figure 106: Notch Spars for Wire Runs	99
Figure 107: Wire Run across Spars and Down into Rear Cabinets.....	99
Figure 108: Wire Run through Rear Cabinet.....	100
Figure 109: Wire Run through Closet and into Galley under Sink	101
Figure 110: Connect Faucet Switch Across 12v Positive Line	102
Figure 111: Leave Extra Wire Length at Front of Camper.....	103
Figure 112: Wiring for LED Galley Light inside Center Rear Cabinet	104
Figure 113: LED Galley Light Off.....	104
Figure 114: LED Galley Light On	105

Figure 115: LED Passenger Side Door Wiring.....	105
Figure 116: Dome Light Wiring	106
Figure 117: Dome Light	107
Figure 118: Hole in Galley Wall for 120v Duplex Box	107
Figure 119: Duplex Box for GFI Plug inside Closet	108
Figure 120: Run Romex across Spars and into Read Cabinet.....	108
Figure 121: Hole in Rear Cabinet to run Romex to Duplex Boxes.....	109
Figure 122: GFI Plug Connected to Romex	109
Figure 123: Duplex Box with Standard 120v Outlet and Weather Resistant Cover	110
Figure 124: Duplex Box with GFI 120v Outlet and Standard Cover	110
Figure 125: 12v Outlet in Galley.....	111
Figure 126: Cabinet Door with Latch and Silicon Bumper	111
Windows, Door, and Aluminum Sheet/Trim Installation (Phase 10)	112
Materials List	112
Tool List.....	112
Process Steps.....	113
Figure 127: Driver's Side Window Opening	116
Figure 128: Aluminum Sheet on Driver's Sidewall.....	116
Figure 129: Window Layout on Aluminum Sheet	117
Figure 130: Butyl Tape on Backside of Window	117
Figure 131: Window Inserted and Screwed to Sidewall	118
Figure 132: Window Caulking	119
Figure 133: Window View from Inside.....	119
Figure 134: Window Drip Cap Using Butyl Tape and Screws.....	120
Figure 135: Drain Pass-Through with 1" Hose Barb x ½" MPT and ½" FPT Coupling	120
Figure 136: Drain Pass-Through Installed on Sidewall.....	121
Figure 137: Drain Pass-Through Inside View	122
Figure 138: Driver's Side Top Edge Trimmed.....	122
Figure 139: Passenger Sidewall with Door Opening Cut in Aluminum	123
Figure 140: Door Trim Edging on Exterior Door Opening	123
Figure 141: Door Trim Edging Counter Sink Flat Head Screws	124
Figure 142: LED Light above Door Opening	124

Figure 143: Door Trim Edging on Interior Door Opening.....	125
Figure 144: Door Trim Edging on Interior Door Opening at Hinge	126
Figure 145: Trim Door Slab Edges 3/16" (Do Not Trim Hinge Side).....	127
Figure 146: Measure and Mark Opening for Window in Door	127
Figure 147: Window Cut Out in Door.....	128
Figure 148: Window Opening Marked on Aluminum Sheet.....	129
Figure 149: Dry Fit Door Window	129
Figure 150: "T" Door Moulding.....	130
Figure 151: "T" Door Moulding Counter Sink Flat Head Screws.....	131
Figure 152: Inside Door Trim (Top)	131
Figure 153: Inside Door Trim (Bottom)	132
Figure 154: Inside Door Trim Hinge Side.....	133
Figure 155: Trim Door Hinge where it Hits "T" Door Moulding.....	134
Figure 156: Hinge Attached to Door	135
Figure 157: Attach Door and Hinge to Sidewall	136
Figure 158: Install Window in Door	136
Figure 159: Drip Rail Forming Using 6mm Baltic Birch Scraps	137
Figure 160: Drip Rail Attached Using Pan Head screws and Butyl Tape	137
Figure 161: R-Tech Insulation with Reflector Side Outward.....	138
Figure 162: Cut R-Tech Insulation to Match Spar Channels for Electrical Wiring.....	139
Figure 163: Hinge Position on Last Spar before Galley.....	140
Figure 164: Galley Hinge over Aluminum Roof Secured with Top Edge Moulding.....	141
Figure 165: Galley Hinge in Open Position.....	142
Figure 166: Top Edge Moulding Secured with Aluminum Drive Screws.....	143
Figure 167: "T" Door Moulding Used as Seam Concealment	144
Figure 168: Grommet to Pass Wiring Out of Camper	145
Figure 169: Top Edge Moulding Attached to Galley Sidewall.....	146
Figure 170: Ceiling Vent Installed (Outside)	147
Figure 171: Ceiling Vent Installed (Inside)	147
Figure 172: Weather Stripping on "T" Door Moulding	148
Figure 173: Weather Stripping Behind Door Hinge	149
Figure 174: Sink Drain to Pass-Through Connection.....	150

Galley Hatch and Locks (Phase 11)	151
Materials List	151
Tool List.....	151
Process Steps.....	151
Figure 175: Optional Spar after Galley Wall	153
Figure 176: Galley Hatch Skeleton Dry Fit.....	153
Figure 177: Galley Hatch Interior Skin (Inside)	154
Figure 178: Galley Hatch Interior Skin (Outside)	154
Figure 179: Galley Hatch with Aluminum Skin.....	155
Figure 180: Hole for Galley Hatch Lock.....	155
Figure 181: Galley Lock Attached to Inside of Hatch	156
Figure 182: Galley Lock “T” Handle.....	156
Figure 183: Galley Lock Strike Location	157
Figure 184: Galley Hatch Weather Strip	158
Figure 185: Galley Hatch Hinge Caulking	159
Figure 186: Hole for Side Door Lock.....	160
Figure 187: Side Door Lock.....	161
Figure 188: Side Door Lock Handle	162
Electrical and Storage Box Completion (Phase 12)	163
Materials List	163
Tool List.....	163
Process Steps.....	163
Figure 189: Utility Box Hole Centered on Channel Iron.....	165
Figure 190: Utility Box Hole and Grommet.....	165
Figure 191: Electric Skid Image 1	166
Figure 192: Electric Skid Image 2	166
Figure 193: Quick Connect Fuse and Terminal Block.....	167
Figure 194: Toggle Switch for 12v, Off, and 120v	167
Figure 195: Toggle Switch Connections	168
Figure 196: Battery Charger Relay	169
Figure 197: Wireless Light Switch	170
Figure 198: Tail Light Bracket (Inside).....	170

Figure 199: Tail Light Bracket and Tail Light	171
Figure 200: Tail Light Wiring	172
Figure 201: Amber Side Light	172
Figure 202: Amber Side Light Wiring	173
Figure 203: Wire Loom on Tail Light	173
Figure 204: Wire Loom on Connection to Tow Vehicle	174
Finishing Touches (Phase 13)	175
Materials List	175
Tool List	175
Process Steps	175
Figure 205: Fender Aligned to Tire	177
Figure 206: Fender with Tire Removed	177
Figure 207: Door Hold Back	178
Figure 208: Stabilizer Jack (Up)	178
Figure 209: Stabilizer Jack (Down)	179
Figure 210: Measure and Cut Interior Window Trim	179
Figure 211: Window Trim Installed	180
Figure 212: Window Trim Installed	180
Figure 213: Interior Caulking	181
Figure 214: Spring Sash Rod	182
Figure 215: Curtain Installed on Door	182
Figure 216: Curtain Installed on Wall	183
Figure 217: Aluminum Kick Plate	184
Figure 218: Foam Mattress	185
Figure 219: Aluminum Skin Cut over Frame Bolt	186
Figure 220: Amber Reflector Bolt Hole	186
Figure 221: Amber Reflector Covering Bolt Hole	187
Figure 222: Mask Off Before Caulking Front Seam	187
Figure 223: Front Seam Caulking	188
Figure 224: Galley Hatch Edge Trim	189
Figure 225: Trailer Lock Set	190
Figure 226: Galley Hatch Support	191

Figure 227: Optional Stainless Steel Galley Counter Top.....	192
Material Supply Sources	193