



Installation Instructions for Indian Scout Footpegs



1. Remove the Footpegs

Remove the footpegs. Be sure to keep the pin and "C" clip or wire that keeps the pin secure. You will use these to install the new footpegs.



3b. Install the Footpegs

Note the spring in the picture to the left. To preload the spring you will need to press it down while rotating the footpeg up. This will allow you to start pressing the pin through the spring.



2. Spring Installation

Install the spring into your new OTB footpegs. Notice the back of the spring will catch on the bolt hole, as shown, when installing the footpeg.



3c. Install the Footpegs

With the footpeg rotated up press/pull the spring to align it with the hole and push the pin through the rest of the way. Make sure the last hole is lined up so the pin can go all the way through.



3a. Install the Footpegs

With the back of the spring in the bolt hole and the front of the spring on the footpeg as shown, start the pin in the hole so that it holds the footpeg in place.



4. Install the Retainer

After the pin is installed install the "C" clip or wire retainer to keep the pin from coming out.