



Scanner user manual



Power connection



Remote control



press turbine 1 time= on/off turbine
hold turbine 2 sec.= on/off scanner sound
press voice 1 to 10 times= play one of 10 voices
hold voice 2 sec.= on/off demo voices
press program 1 time = change light joke
hold program 2 sec. = activate PIR

If the PIR is activated while the scanner is on, when a person is detected, it start one random sentence.
If the PIR is activated while the scanner is on, when a person is detected, it start one random sentence and the scanner will light up until the the sentence is end

SD-Card

