

WT600 1st floor Garage chart
For concrete and waterproofing repair


SW corner

WEST side of the garage - 1st level

NW corner

1 line between lots - no columns, 2 lines between lots - 1 column, 3 lines between lots - 2 columns

145	144	143	142	141	140	139	138	137	136	609	134	133	132	610	611
need to update were the columns are in this row										A				A	A



(EAST side of the garage - 1st floor continues on the separate page)

SE corner

E A S T S I D E

NE corner