



CommConnect

TO PROGRAM a DRE RC-70 REMOTE CONTROL:

- 1) Press and hold the **MUTE & ENTER** simultaneously until the LED blinks 2 times
- 2) Enter the programming code for the TV

Most LG TV's: the code is 11423

Most Phillips Tvs: the code is 11454

A full list of all television manufacturer's setup codes follows:

3M	10724, 10737, 11616, 11655, 12508, 12838, 12974	Brockwood	10019
A-Mark	10003	Broksonic	10236, 10463, 10003, 10426, 11905, 11911, 11929, 11935, 11938
Accurian	11803	Byd:sign	11309
Action	10873	C & M	10700
Admiral	10093, 10463, 10179	Cadia	11283
Advent ..	10761, 10782, 10784, 10807, 10815, 10817, 10842, 11528, 11570	Candle	10030, 10046, 10056, 10186
Adventura	10046	Canon	10793, 11396, 12590, 12610, 12743
Aiko	10092	Carnivale	10030
Aiwa	10701, 11362, 11916, 11955	Carver	10054, 10170
Akai	10812, 11675, 10702, 10765, 10030, 12232, 11935, 11903, 11692, 11689, 11688, 11676, 11385, 11207, 10745, 10672, 10591	Casio	10611, 11205, 13059
Alaron	10179	CCE	10217, 10329, 10623
Albatron	10700, 10843	Celebrity	10000
Ambassador	10177	Celera	10765
America Action	10180	Champion	11362
Anam	10180, 10068	Changhong	10765
AOC	10030, 10003, 10019, 10052, 10185, 11089, 11365, 11589, 11590, 12014, 12087, 12402, 12621	Cinego	11986
Aomni	11623	Citizen	10060, 10030, 10092, 10039, 10046, 10056, 10186, 10280, 10561, 11669, 11671, 11672, 11928, 11935
Apex Digital	10748, 10879, 10765, 10890, 11217, 12397	Clairtone	10185
AquaVision	11861	Clarion	10180
Archer	10003	Classic	11984
Archos	12503	Coby	11538, 11634, 11680, 12017, 12306, 12314, 12315, 12326, 12338, 12340, 12344, 12345, 12347, 12348, 12560
Astar	11531, 11738	Cocom	11611
Audiovox	10003, 11564, 10451, 10180, 10092, 13065, 12513, 11952, 11951, 11937, 11868, 11865, 11803, 11769, 11766, 11284, 10875, 10846, 10802, 10713, 10623,	Commercial Solutions	11447, 10047, 11126
Aurora Systems	10801	Compaq	10749, 10750
Aventura	10171	Concerto	10056
Axion	11827, 11937, 13050	Contec	10180, 10185
Bang & Olufsen	10620, 11620	Craig	10180
Belcor	10019	Crosley	10000, 10054
Bell & Howell	10154, 10016	Crown	10180, 10039
BenQ	11032, 11212, 11315, 11562, 12807	CTX	10700
Bradford	10180	Curtis ..	11200, 11326, 12352, 12397, 12855, 12859
Brilliant	11007, 11255, 11257	Curtis Mathes	10047, 10054, 10154, 10451, 10093, 10060, 10702, 10030, 10145, 10166, 11661, 11959, 11919, 11347, 10747, 10466, 10068, 10056, 10039, 10016
		CXC	10180
		CyberHome	10794

Cytron..... 11326, 12003
Daewoo 10154, 10451,
10092, 11661, 10019, 10039, 10066, 10067, 10402,
10623, 10672, 11909, 11921, 11928
Daytron 10019
Dell 11264, 11178, 11403, 11863
Delta 11369
Denon..... 10145
Denstar 10628
Diamond Vision 11996, 11997
Digistar 11565
Digital Lifestyles 11765, 11822
Digital Projection Inc. 11725, 11750
DirecTV 11501
Disney 11665, 12152
Dream Vision 11164, 11297
Dumont 10017, 10019
Durabrand 10463, 10180, 10178,
10171, 11034, 10003, 11665
Dwin 10720, 10747, 10774
Dynatech 10049
Dynex 11463, 11785, 12049
Eiki 10735, 12455, 12600
Electric Mirror 13166
Electroband 10000, 10185
Electrograph 11755, 11623
Electrohome 10463, 10381, 10389,
11570, 11670, 11672
Element 11687, 11886, 12183
Emerson 11864, 10154, 10451, 10236, 10463,
10180, 10178, 10171, 11661, 11886, 11905, 11909,
11911, 11913, 11928, 11929, 11944, 11963, 11997,
12776, 12828, 11665, 11394, 10623, 10282, 10280,
10270, 10185, 10181, 10179, 10177, 10039, 10038,
10019, 10002
Emprex 11422, 11546, 11765
Encross 10876, 11474
Envision 10030, 10813,
11365, 11506, 11589, 12014, 12087
Epson 10831, 10881,
11122, 11290, 11379, 11735, 12520, 12550
Erae 11222
ESA 10812, 10171, 11944, 11963
Fisher 10154, 10159, 11362
FlexVision 10713
Fluid 12964
Fujitsu..... 10809, 10179, 10186,
10683, 10853, 12008
Funai 10000, 10180,
10171, 10179, 11904, 11963
Futuretech 10180
Gateway 11755, 11756
GE 11447, 10047, 10051, 10451,
10765, 10178, 11922, 11919, 11917, 11907, 11347,
10747, 10282, 10279, 10251, 10027, 10021
GFM 11864, 10171, 11665, 11886, 11963
Gibraltar 10017, 10030, 10019
Go Video 10886, 11823, 11831
GoldStar 10178, 10030, 10002, 10019,
10039, 10056, 11926
GPX 10179, 12693
Grundig 10683
Grunpy 10180, 10179
H & B 11366
Haier 11034, 10768, 11009, 11570, 11753,
12293, 12494, 12690, 13204
Hallmark 10178
Hanns.G 11783
Hannspree .. 11348, 11351, 11352, 11745, 11783
Harley Davidson 10043, 10179, 11904
Harman/Kardon 10054
Harsper 11206
Harvard 10180, 10068
Havermy 10093
Helios 10865
Hello Kitty 10451, 12776
Hewlett Packard . 11494, 11088, 11089, 11101,
12540
Hisense 10748, 11314, 11660, 12098, 12355
Hitachi 11643, 11145, 10145, 10723, 10724,
10737, 10770, 10777, 10797, 11345, 11484, 11500,
11576, 11904, 12679, 12838, 13007, 10016, 10036,
10038, 10039, 10043, 10056, 10095, 10096, 10151,
10163, 10217, 10227, 10279, 10413, 10583, 10600,
10679
HP 11494, 11088, 11089, 11101, 12540
Humax 11501
Hyundai 10849, 11219, 11294
I-Inc 11746
iLo ... 11463, 11286, 11394, 11603, 11665, 11684,
11990
Infinity 10054
InFocus 10736, 10738, 10741, 10781, 11164,
11430, 11516, 12199
Initial 11603, 11990
Insignia 11423, 11564, 10463, 10171, 12751,
12417, 12049, 12002, 11963, 11785, 11710, 11660,
11641, 11517, 11385, 11326, 11204, 10842
Inteq 10017
iRIS 12189
iView 12842
IX 10877
Janeil 10046
JBL 10054
JCB 10000
JCM 12189, 12256
Jensen.... 10761, 10050, 10807, 10815, 10817,
11299, 11326
JVC ... 10463, 10053, 10036, 10069, 10160, 10371,
10731, 11253, 11302, 11352, 11357, 11818, 11923,
12264, 12321
Kaypani 10052
KDS 11498, 11687
KEC 10180
Kenwood 10030, 10019
KLH 10765, 11962
Kloss 10024, 10046

KMDS 12278
Knoll Systems 10781
Konka10628, 10632, 10638, 10703,
10707, 11385, 11831, 11939
Kost 11262, 11483
Kreisen 10876, 11474
KTV 10180, 10030, 10039, 10185, 10217, 10280
Lasonic 13198
LG ..11423, 11447, 10017, 11265, 10178, 10823,
10829, 10856, 11178, 10700, 10442, 11530, 11637,
11768, 11934, 12864, 12867
LiteOn..... 11088
Lloyd's 11904
LodgingStar 13147
Logik 10016
Luce 10837, 11031
Luxman 10056
LXI 10047, 10054, 10154, 10156, 10178, 10747
MAG 11498, 11687
Magnasonic 11713, 11913, 11928
Magnavox 11454, 11755, 10054, 10051,
10030, 10171, 10706, 11525, 11867, 11904, 11913,
11931, 11944, 11963, 11990, 12492, 12552, 12597,
12655, 11506, 11365, 11198, 11154, 10802, 10435,
10386, 10187, 10186,
10179, 10096, 10036, 10024, 10020
Magnin 11907
Majestic 10016
Marantz 11454, 10054, 10030, 10704, 10854,
10855, 11154, 11398, 11714, 12447
Matsushita 10250
Maxent 11755, 11211, 11714, 11757
MB Quart 11868
Megapower 10700
Megatron 10178, 10145, 10003
MEI 10185
Memorex 10154, 10463, 10150, 10178,
12739, 11938, 11927, 11926, 11924, 11920, 11911,
11903, 11785, 11670, 11665, 11570, 10877, 10179,
10016
MGA 10150, 10178, 10030, 10019, 11907
Micro 11436
Midland .. 10047, 10017, 10051, 10039, 10747
Mintek..... 11603, 11990
Minutz..... 10021
Mitsubishi11250, 10093, 10150, 10178, 12624,
12576, 11917, 11797, 11350, 11278, 10868, 10836,
10358, 10331, 10036, 10019, 10014
Monivision 10700, 10843
Motorola 10093, 10835
Moxell 10835
MTC ..10060, 10030, 10019, 10049, 10056, 10185
Multitech 10180, 10049, 10217
NAD 10156, 10178, 10056, 10866, 11156
Nakamichi 11493
Naxa 11998, 12104, 12735
NEC 10030, 10019, 10036, 10056, 10170, 10704,
10876, 10882, 11398, 11704, 11797, 12026, 12199
NetTV 11755, 12753
Nexus Electronics 12183
Nikko 10178, 10030, 10092
Niko 11618
Norcent10748, 10824, 11089, 11365, 11589,
11590, 11591, 11745
Norwood Micro 11286, 11296
Noshi 10018
NTC 10092
NuVision 11657, 12158
Olevia 11610, 11144, 11240
Onwa 10180
Optimus 10250, 10154, 10166, 11913,
11924, 11927
Optoma 10887, 11348,
11622, 12161, 12514, 12593, 13062
Optonica 10093, 10165
Orion 10236, 10463, 11463, 10179, 10443,
10655, 11905, 11911, 11929, 11938, 12108
Panasonic 10250, 11480, 10051, 11290, 11335,
11410, 11919, 11924, 11927, 11946, 11947, 12080,
12240, 12264
PARK 11376, 12104, 12194, 12202
PDI 11474
Penney10047, 10156, 10051, 10060, 10178, 10030,
11926, 11919, 11907, 11347, 10747, 10309, 10149,
10039, 10027, 10021, 10019, 10018, 10003, 10002
Philco .10054, 10030, 10171, 10019, 10020, 10024,
10096, 10179, 10187, 10381, 11394, 11665, 11963
Philips..... 11454, 10054, 10171, 10690, 10899,
11154, 11394, 11483, 11506, 11867, 12492, 12501,
12552, 12597, 12622, 12992
Pilot 10030, 10019, 10039
Pioneer 11457, 10166, 10038, 10172, 10608,
10679, 10776, 10866, 11398, 12240, 12286, 12458
Planar 11288, 11496, 11589, 13019, 13224
Polaroid ..10765, 12120, 12117, 12063, 12002,
11962, 11769, 11767, 11766, 11763, 11762, 11687,
11565, 11538, 11498, 11385, 11328, 11327, 11326,
11316, 11314, 11286, 11276, 11262, 10865
Portland 10451, 10092, 11661, 10019, 10039
Prima 10761, 10807, 10815, 10817, 11389,
11753, 11785
Princeton 10685, 10700, 10717
Prism 10051
Projectiondesign 11750, 11752
Proscan 11447, 10047, 10030, 10466, 10747,
11347, 11922, 12147, 12183, 12256
Proton..... 10178, 10003, 10031, 10052, 10466
Protron 11320, 11323
Proview 10835, 11498, 11687
Proxima .. 10735, 10737, 10742, 10758, 11430
Pulsar 10017, 10019
Puneet 11546
Pvision..... 11222
Pye 10412
Pyle 11200, 12196, 12641
Quasar 10250, 10051, 10165, 11919,
11924, 11927

RadioShack 10047, 10154, 10180, 10178,
 10030, 10019, 10039, 10056, 10165, 10747, 11827,
 11904, 11920
RCA ...11447, 10047, 10051, 10093, 11661, 12932,
 12746, 12434, 12002, 11959, 11958, 11922, 11919,
 11917, 11907, 11347, 11126, 10899, 10774, 10747,
 10679, 10278, 10254, 10090, 10038, 10019, 10018
Realistic 10154, 10180, 10178,
 10030, 10019, 10039, 10056, 10165
Reoc 10714
RevolutionHD 11623
Rhapsody 10185
Runco 10017, 10030,
 10251, 11398, 11629, 11679
Sampo 11755, 10030, 10039, 10052
Samsung 12051, 10812, 10060, 10702,
 10178, 10030, 12733, 12596, 12557, 11959, 11903,
 11618, 10814, 10766, 10587, 10482, 10427, 10329,
 10217, 10056, 10039, 10019
Samsux 10039
Sansui 10463, 10171, 11463, 10165, 10371,
 11670, 11904, 11911, 11929, 11935, 11938
Sanyo 10054, 10154, 12990, 12600, 12455,
 12452, 11974, 11907, 11649, 11648, 11647, 11362,
 11216, 11142, 10799, 10798, 10735, 10484, 10208,
 10159, 10146, 10107, 10088, 10036
Sceptre 10878, 11217, 11360, 11599, 12337,
 12506, 12528
Scimitsu 10019
Scotch 10178
Scott 10236, 10180,
 10178, 10019, 10179, 10309, 11711
Sears 10047, 10054, 10154, 10156, 10178,
 10171, 10056, 10146, 10149, 10159, 10179, 10747,
 11007, 11904, 11926
Seleco 10737, 11297, 11351
Sense 11865
Sharp 10818, 10093, 10039, 10153, 10165,
 10386, 10491, 10608, 10720, 10854, 11407, 11917,
 12402, 12495, 12603
Sharper Image 11950
Sheng Chia 10093
Sherwood 11399
Shogun 10019
Signature 10054, 10016
Signet 10800, 10844, 11262
SIM2 Multimedia 11297
Simpson 10186, 10187
Sinudyne 10347
Skyworth 11799
Solarism 11220
Sole 11031, 11366, 11377, 11483, 11530,
 11623, 12076
Sony 10000, 10810, 10011, 10080, 10353,
 10834, 11317, 11400, 11685, 11786, 11904, 11925,
 12736
Soundesign 10180, 10178, 10179, 10186
Sova 11320, 11952
Soyo 11546, 11746, 11824, 11826, 11828,
 11830, 11831
Spectricon 10003
Spectroniq 11498, 11687
Squareview 10171
SSS 10180, 10019
Starlite 10180
Studio Experience 10843
SunBriteTV 11610, 11420, 11435, 12337,
 12528
Superscan 10093, 10864, 11944
Supersonic 11753, 12104, 12516,
 12784, 13154, 13204
Supre-Macy 10046
Supreme 10000
SVA 10748, 10587,
 10768, 10865, 10871, 10872, 11963
Sylvania ... 11864, 10054, 10030, 10171, 11963,
 11944, 11931, 11913, 11886, 11665, 11394, 11314,
 10587, 10381, 10187, 10096, 10065, 10024, 10020
Symphonic 10180, 10171, 10068, 11394,
 11904, 11913, 11944
Syntax 11610, 11144, 11240
Tandy 10093
Tatung 10003, 10049, 11101, 11286, 11287,
 11288, 11361, 11503, 11756, 12496
TCL 12434
Teac 11248
Technics 10250, 10051
Technol Ace 10179
Techview 10847, 12004
Techwood 10051, 10003, 10056
Teknika 10054, 10180, 10150, 10060, 10092,
 10016, 10019, 10039, 10056, 10179, 10186, 10312
Telefunken 10702, 10056
Telemagic 10735
Tera 10031
Thomas 11904
TMK 10178, 10056, 10177
TNCi 10017
Toshiba ..11524, 10154, 10156, 11265, 10060,
 12802, 12684, 11959, 11935, 11918, 11716, 11704,
 11369, 11343, 11164, 11156, 11155, 10832, 10736,
 10243, 10241, 10149, 10036, 10003
Tosonic 10185
Totevision 10039
TruTech 11665, 11723, 12066
TVS 10463
Ultra 10391, 11323
Universal 10027
US Logic 11286
UTI Technology 12244
Vector Research 10030
Venturer727, 11865, 11868
VEOS 11007
Victor 10053
Vidikron 10054, 11302, 11398, 11629
Vidtech 10178, 10019, 10036

Viewsonic11755, 11564, 12839, 12510, 12504,
12277, 12111, 12087, 12049, 12014, 11742, 11627,
11578, 11542, 11511, 11365, 11330, 10885, 10864,
10857, 10797, 10777, 10775, 10724
Viking 10046, 10312
Viore 11207, 11684, 11811, 12104, 12352,
13094, 13118
Visart 11336
Visco 11967
Vistron 12142
Vito 11320
Vizio 11758, 10864, 10885, 11756
Wards.10000, 10047, 10054, 10017, 10154, 10156,
10051, 10180, 10060, 10178, 10030, 11347, 11156,
10866, 10187, 10186, 10016, 10179, 10165, 10018,
10019, 10096, 10080, 10020, 10056, 10021, 10024,
10027
Waycon 10156
Westinghouse 10451, 10885, 10890, 11217,
11282, 12195, 12293, 12499
White Westinghouse 10463, 11661, 10623, 11909
WinBook 11381, 11503
Wyse 11365
Xoceco 11469
Yamaha 10030, 10019, 10769, 10797, 11407
Zenith 10000, 11423, 10047, 10017, 10463,
11265, 10178, 10030, 11145, 10145, 10092, 11661,
10160, 11365, 10016, 11904, 11909, 11911, 11929,
12616, 12950
Zonda10003