



# Frequently asked questions; SF-25 Paper Feeder



Is the delivery table adjustable on this feeder?  
-Yes it is

What is the maximum size of this feeder?  
-Maximum size is 25.5" wide x 31.5" long

Can I move this feeder to use on another machine?  
-Yes, it is equipped with heavy duty casters so that you can move it around your shop and also built in breaks to keep it in place.

What is the minimum size I can feed with this feeder?  
-Minimum size is 8.25 wide x 6" long

Is this an air feeder?  
-Yes it is

What stock paper can I use?  
-The SF-25 has been tested with 150 to 400 GSM

Can I use this feeder with my current creaser or UV Coater?  
-Absolutely, with the heavy-duty casters, this feeder can easily roll up to your current machines and with its adjustable table, it can be quickly adjusted to fit any height.

What is the smallest size paper I can feed?  
-Minimum paper size is 8.25" wide x 6" long.

Is there a way I can regulate the speed on the SF-25?  
-Yes, this feeder does have a speed control

Does this feeder feed from the top or bottom?  
-This is a top feeding paper feeder

What power do I need to operate this machine?  
-The SF-25 requires 220 volts

Feel free to contact us if  
you should have any  
further questions.

**Shark Finishing Machinery**

info@SharkMachinery.com

SharkMachinery@gmail.com

www.SharkMachinery.com

Ph. 619.797.6278

**"Finish Smart with Shark"**