

ATTENTION INSTALLER

To initiate AUTO-START feature you must first make sure the compactor safety features are working and the conditions are safe for unit to auto start including 42" minimum load height and E-Stop within 3' of point of operation, and all other access doors are interlocked. Also make sure to train operators and add decals.

Then locate the control buttons on the front of the controller.

Press button **ESC 0** – Screen should be blank

Press buttons **DEL 6** and **ALT 7** together

Screen should say "Auto-Count" at the top.

Then set **C0** to your desired count.

If power is lost to the compactor for more than 2 days this step will have to be repeated.

For more help go to www.versa-pak.net

or call 352-742-4774 Ext 4