



**WINGS AEROSPACE, LLC**  
**S-70 REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
13137	4810-01-096-1054	VALVE HYD
129060	6610-01-155-8315	VERTICAL SITUATION INDICATOR
400240	6645-00-076-3050	CLOCK,PANEL
0202HRA/1		AN/APN-198 RADAR ALT
101450-31243	6610-01-176-9314	PRESSURE ALTIMETER
10450-31875	6610-01-296-0880	BAROMETRIC ALTIMETER
106107-400	2835-01-106-9132	CONTROL ASSY
1105123-1	1680-01-254-6893	ACTUATOR
126300-17	6610-01-246-4164	ATTITUDE INDICATOR
141852-3211		AHRU,LCR-92S
145974-01-03	6615-00-453-5670	GYRO
163290-100	2995-01-169-5291	CONTROL UNIT,APU
20025-1115-1		AIRSPEED INDICATOR
20025-2173	6610-01-098-8363	INDICATOR
21B17-55-BM	6110-01-117-1220	CONTROL UNIT
21B17-55-C	6110-01-224-6954	CONTROL UNIT
2587451-3	6615-00-167-9757	GYRO
28B262-35-B	6115-01-084-5229	AC GENERATOR
28B262-35-C	6115-01-252-0367	GENERATOR,ALTERNATING CURRENT
28B262-35-C	6115-01-252-0367	AC GENERATOR
28B302-8-DM	6115-01-114-9696	GENERATOR
30260-1164	6610-01-164-4329	VERTICAL VELOCITY INDICATOR
3252010-0101	6610-01-005-9151	ALTIMETER
3252011-0101	6610-01-055-0468	ENCODER ALTIMETER
388071-9	1620-00-784-5553	LANDING GEAR
4001670-2513	5841-01-544-8436	INDICATOR,RADAR TARGET
45-0189-7	6230-01-105-6580	SEARCHLIGHT
45-0241-1	6230-01-244-5055	SEARCHLIGHT
53023-05	4320-01-136-2118	UTILITY PUMP MODULE ASSY
53023-06	4320-01-207-7228	HYD.PUMP
60-2977-3	6130-01-115-9237	POWER SUPPLY
60-2977-5	6130-01-211-6790	POWER SUPPLY
622-0507-001	5826-01-012-1938	RECEIVER-TRANSMITTER, RADIO
622-8129-002	5821-01-396-5650	RECEIVER-TRANSMITTER,RADIO
70101-31000-046	1615-01-158-9678	BLADE,ROTARY RUDDER
70102-08200-069	1615-01-442-6926	SPINDLE,HEAD,ROTARY WING
70103-08112-041	1615-01-096-5427	HUB. ASSY
70103-28041-042	1650-01-158-9683	HYDRAULIC ACCUMULATOR
70104-08000-047	1615-01-221-2615	SWASHPLATE ASSY
70104-08020-045	1615-01-105-8716	SHAFT ASSY
70107-08400-044	1615-01-085-5315	BIFILAR ASSY MAIN ROTOR
70107-08400-046	1615-01-127-7388	BIFILAR ASSY
70250-12051-044	1620-01-181-8288	MLG SHOCK STRUT ASSY
70250-12051-045	1620-01-231-1831	MLG SHOCK STRUT ASSY
70250-12057-049	1620-01-148-8972	DRAG BEAM/AXLE ASSY,MAIN LANDING GEAR
70250-13101-042	1620-01-096-5573	TAIL LG SHOCK STRUT ASSY
70250-13101-043	1620-01-205-6136	STRUT ASSY



**WINGS AEROSPACE, LLC**  
**S-70 REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
70250-13103-041	1620-01-095-6992	FORK ASSY, L/G
70306-10000	2995-01-286-1498	STARTER,ENGINE,GAS TURBINE
70307-03005-105	4320-01-231-1367	ELECTRIC PRIME PUMP
70351-08001-046	1615-01-230-6218	GEARBOX ASSY
70351-08080-043	1615-01-078-5718	TRANSMISSION
70357-06300-042	1615-01-074-5152	IGB
70358-26600-045	1615-01-372-5467	TAIL GEARBOX ASSY
70361-03001-045	1615-01-081-2775	SHAFT ASSY
70361-03009-047	1615-01-158-9517	DRIVE SHAFT
70361-05001-045	1615-01-082-6500	SHAFT ASSY
70361-05001-051	1615-01-158-9522	SHAFT ASSY
70361-05002-045	3040-01-083-2953	SHAFT ASSY
70361-06002-045	1615-01-082-9254	SHAFT ASSY
70361-06002-047	1615-01-158-5788	SHAFT ASSY
70361-08004-042	2835-01-093-4763	DRIVE SHAFT
70361-08004-043	2835-01-123-7648	SHAFT ASSY
70400-01201-043	1680-01-092-7981	YOKE & HOUSING
70400-06100-042	1615-01-141-7532	COUPLING ASSY
70400-06641-114	1680-01-211-2856	ACTUATOR,ELECTRO-ME
70400-06641-115	1680-01-228-1199	LINEAR ACTUATOR
70410-02450-047	1560-01-128-1759	ROLL SAS ASSY
70410-02760-047	1680-01-137-3533	PITCH TRIM SERVO ASSY
70450-01801-103	5895-01-568-9185	CONVERTER,SIGNAL DATA
70450-21942-101	6610-01-164-4328	INDICATOR AIR SPEED
70450-21988-101	6610-01-164-4329	VERTICAL VELOCITY INDICATOR
70450-81109-041	1680-01-328-9156	SONOBUOY/CHAFF CONTROL PANEL UNIT ASSEMBLY
70500-05541-117	1680-01-261-2044	ACTUATOR, ELECTRO MECHANICAL
70550-01107-106	1680-01-185-0957	PANEL FAULT
70550-01107-107	1680-01-214-0193	PANEL,ASSY,CAUTION ADVISORY
70550-02031-111	6115-01-114-9696	OIL-COOLED AC GENERATOR
70550-02031-112	6110-01-202-7174	CONTROL UNIT
70550-02032-103	6115-01-084-5229	AC GENERATOR
70550-02032-104		APU
70550-02046-106	1650-01-224-6682	MOTOR-PUMP,HYDRAULIC
70550-02102-047	5945-01-139-1126	RELAY ASSY
70550-02102-049	5945-01-224-2864	PANEL RELAY RH
70550-02102-051	5945-01-289-2696	PANEL RELAY RH
70550-02105-047		RELAY PANEL
70550-02105-048	5945-01-129-7331	PANEL RELAY LH
70550-02105-050	5945-01-129-7331	PANEL RELAY LH
70550-02105-051	5945-01-221-0478	RELAY ASSY
70550-02105-057	5945-01-332-9907	PANEL RELAY LH
70553-05002-105	6220-01-321-2985	ANTI COLLISION LIGHT ASSY
70553-05002-110	6130-01-211-6790	ANTI COLLISION FLASHER UNIT
70600-81863-103		FREQUENCY MEASUREMENT UNIT
70600-81863-118		INTERFACE PROCESSOR
70651-03201-104	1650-01-250-3767	ACCUMULATOR, HYDRAULIC



**WINGS AEROSPACE, LLC**  
**S-70 REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
70652-02300-050	4320-01-207-7228	HYDRAULIC PUMP MODULE
70800-02503-105	4030-01-271-6239	HOOK CARGO
70902-01070-045	1680-01-138-3395	FLIGHT CONTROL PANEL
70902-21000-049	1680-01-380-2209	DIGITAL AFCS CONTROL PANEL ASSEMBLY
787200-5		FUEL CONTROL UNIT HYDROMECHANICAL
843420-5	1680-01-214-0193	PANEL FAULT
871FF2	6340-01-117-1222	ICE DETECTOR
8900740-507		DATA CONTROL PANEL
8901200-529	6605-01-366-7955	DATA CONVERTER NAVIGATION SET
8KD9AF6	6615-00-159-2298	DISPLACEMENT GYRO
A1605	6610-00-625-6035	TURN AND SLIP INDICATOR
AAU24A	6610-00-106-7552	ALTIMETER,PRESSURE
AAU31/A	6610-00-110-3368	ALTIMETER
AAU-31/A-2	6610-01-296-0880	BAROMETRIC ALTIMETER
AAU32A	6610-00-115-2405	ALTIMETER
AAU32A	6610-00-134-5625	ENCODER ALTIMETER
AQU-13A/A	6605-01-119-0832	INDICATOR HORIZONTAL
B4420210002	6610-01-091-3701	PRESSURE ALTIMETER
B4515210002	6610-00-134-5625	ENCODER ALTIMETER
C-10909A/A	1680-01-138-3395	FLIGHT CONTROL PANEL
DCU-263/A	1680-01-328-9156	SONOBUOY/CHAFF CONTROL PANEL UNIT ASSEMBLY
DL2155M13	1680-01-228-1199	ACTUATOR
DL2155M20	1680-01-261-2044	ACTUATOR STAB
FE7590-120	4030-01-271-6239	HOOK CARGO
FE7590-120A	4030-01-176-9353	HOOK CARGO
FE7590-145	4030-01-238-4394	HOOK CARGO
ID-2277A/A	6610-01-155-8315	INDICATOR,VERTICAL SITUATION
JG1091DD01	5841-01-232-3104	INDICATOR,HEIGHT
MS28041-1A	6610-00-912-3572	TURN AND SLIP INDICATOR
N335-046		AUDIO CONTROL UNIT, PILOT
S6115-20520-001	1560-00-869-5987	INDICATOR,BIM,BLADE