



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
6.14E-21		FLIGHT MODE SEL
26501		COMPRESSOR DRIVE MOTOR
200102		STATIC INVERTER
200129		STATIC INVERTER
200131		STATIC INVERTER
5000172		BRAKE ASSY
5002256		BRAKE ASSY
5002257		BRAKE ASSY
5002258		BRAKE ASSY
5002259		BRAKE ASSY
5002260		BRAKE ASSY
5002261		BRAKE ASSY
5002262		BRAKE ASSY
5002263		BRAKE ASSY
5002289		BRAKE ASSY
5002460		MAIN WHEEL ASSY
5002461		MAIN WHEEL ASSY
5002464		MAIN WHEEL ASSY
9543463		BRAKE ASSY
9544396		BRAKE ASSY
9544397		BRAKE ASSY
100-380011-1		MLG BRAKE ASSY
100-384072-5		COMPRESSOR DRIVE MOTOR
100-524073-1		GEARBOX
100-524074-1		GEARBOX
100-810013-1		LANDING GEARBOX & MOTOR ASSYS
100-820022-9		NW STEERING LINK ASSY
101-361161-1		PCB ASSY
101-364328-7		PCB ASSY
101-364578-1		PCB ASSY
101-364578-11		PCB ASSY
101-364578-13		PCB ASSY
101-364578-7		PCB ASSY
101-364578-9		PCB ASSY
101-364580-1		PCB ASSY
101-364580-11		PCB ASSY
101-364580-13		PCB ASSY
101-364580-5		PCB ASSY
101-364580-9		PCB ASSY
101-364582-1		PCB ASSY
101-364582-11		PCB ASSY
101-364582-13		PCB ASSY
101-364582-15		PCB ASSY
101-364582-17		PCB ASSY
101-364582-19		PCB ASSY



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
101-364582-21		PCB ASSY
101-364582-23		PCB ASSY
101-364582-25		PCB ASSY
101-364582-27		PCB ASSY
101-364582-29		PCB ASSY
101-364582-5		PCB ASSY
101-364582-7		PCB ASSY
101-364584-1		PCB ASSY
101-364584-11		PCB ASSY
101-364584-13		PCB ASSY
101-364584-5		PCB ASSY
101-364584-7		PCB ASSY
101-364584-9		PCB ASSY
101-364668-1		PCB ASSY
101-364668-5		PCB ASSY
101-364674-1		PCB ASSY
101-364712-1		PCB ASSY
101-364715-1		PCB ASSY
101-380096-1		MAIN BRAKE ASSY
101-384004-1		BLOWER ASSY
101-384004-13		BLOWER ASSY
101-384004-5		BLOWER ASSY
101-384004-9		BLOWER ASSY
101-384100-1		CENTRIFUGAL BLOWER ASSY
101-384135-1		BLOWER ASSY
101-384135-3		BLOWER ASSY
101-384144-1		DEICER DISTRIBUTING VALVE
101-384144-3		DEICER DISTRIBUTING VALVE
101-384176-1		BLOWER ASSY
101-384176-3		CENTRIFUGAL BLOWER ASSY
101-388014-17		MLG ACT ASSY
101-388014-19		MLG ACT ASSY
101-389025-1		FUEL SHUTOFF VALVE
101-389025-3		FUEL SHUTOFF VALVE
101-389025-5		FUEL SHUTOFF VALVE
101-521039-1		AILERON TRIM TAB ACT
101-524072-1		ELEVATOR TRIM TAB ACTUATOR
101-524079-1		RUDDER TRIM TAB ACTUATOR
101-524079-3		RUDDER TRIM TAB ACTUATOR
101-524887-1		ELEC ELEV TRIM TAB ACT ASSY
101-8001-23		MAIN BRAKE ASSY
101-8001-231		MAIN BRAKE ASSY
101-8001-31		MLG WHEEL ASSY
101-8001-47		MLG WHEEL ASSY
101-8001-9		MAIN BRAKE ASSY



**WINGS AEROSPACE, LLC**  
**KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
101-8001-91		MAIN BRAKE ASSY
101-8002-11		BRAKE ASSY
101-8002-13		BRAKE ASSY
101-8002-15		BRAKE ASSY
101-8002-17		BRAKE ASSY
101-8002-19		BRAKE ASSY
101-8002-3		BRAKE ASSY
101-8002-5		MAIN WHEEL ASSY
101-8002-51		MAIN WHEEL ASSY
101-8002-53		MAIN WHEEL ASSY
101-8002-55		MAIN WHEEL ASSY
101-8002-57		MAIN WHEEL ASSY
101-8002-61		MAIN WHEEL ASSY
101-8002-7		MAIN WHEEL ASSY
101-8002-9		MAIN WHEEL ASSY
101-8015-3		NLG WHEEL ASSY-MAGNESIUM
101-8015-7		NLG WHEEL ASSY-MAGNESIUM
101-8026-5		NLG WHEEL ASSY-ALUMINUM
101-8030-1		NOSE LANDING GEAR ASSY
101-8030-1S		NOSE LANDING GEAR ASSY
101-810000-1		MAIN LANDING GEAR ASSY
101-810000-10		MAIN LANDING GEAR ASSY
101-810000-11		MAIN LANDING GEAR ASSY
101-810000-12		MAIN LANDING GEAR ASSY
101-810000-2		MAIN LANDING GEAR ASSY
101-810000-3		MAIN LANDING GEAR ASSY
101-810000-4		MAIN LANDING GEAR ASSY
101-810000-601		MAIN LANDING GEAR ASSY
101-810000-602		MAIN LANDING GEAR ASSY
101-810000-605		MAIN LANDING GEAR ASSY
101-810000-606		MAIN LANDING GEAR ASSY
101-810000-607		MAIN LANDING GEAR ASSY
101-810000-608		MAIN LANDING GEAR ASSY
101-810000-651		MAIN LANDING GEAR ASSY
101-810000-652		MAIN LANDING GEAR ASSY
101-810000-9		MAIN LANDING GEAR ASSY
101-810002-1		MAIN LANDING GEAR ASSY
101-810002-2		MAIN LANDING GEAR ASSY
101-810002-601		MAIN LANDING GEAR ASSY
101-810002-602		MAIN LANDING GEAR ASSY
101-810002-605		MAIN LANDING GEAR ASSY
101-810002-606		MAIN LANDING GEAR ASSY
101-810002-607		MAIN LANDING GEAR ASSY
101-810002-608		MAIN LANDING GEAR ASSY
101-810002-651		MAIN LANDING GEAR ASSY



**WINGS AEROSPACE, LLC**  
**KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
101-810002-652		MAIN LANDING GEAR ASSY
101-810002-7		MAIN LANDING GEAR ASSY
101-810002-8		MAIN LANDING GEAR ASSY
101-810003-601		MAIN LANDING GEAR ASSY
101-810003-602		MAIN LANDING GEAR ASSY
101-810006-1		MAIN LANDING GEAR ASSY
101-810006-2		MAIN LANDING GEAR ASSY
101-810006-3		MAIN LANDING GEAR ASSY
101-810006-4		MAIN LANDING GEAR ASSY
101-810007-1		MAIN LANDING GEAR ASSY
101-810007-2		MAIN LANDING GEAR ASSY
101-810009-1		MAIN LANDING GEAR ASSY
101-810009-13		MAIN LANDING GEAR ASSY
101-810009-5		MAIN LANDING GEAR ASSY
101-810009-9		MAIN LANDING GEAR ASSY
101-810010-11		MAIN LANDING GEAR ASSY
101-810010-5		MAIN LANDING GEAR ASSY
101-810011-1		MAIN LANDING GEAR ASSY
101-810011-601		MAIN LANDING GEAR ASSY
101-810012-1		MAIN LANDING GEAR ASSY
101-810023-1		MAIN LANDING GEAR ASSY
101-810023-3		MAIN LANDING GEAR ASSY
101-810023-5		MAIN LANDING GEAR ASSY
101-810023-7		MAIN LANDING GEAR ASSY
101-810030-1		MLG ASSY
101-810031-3		MAIN LANDING GEAR ASSY
101-810032-1		MAIN LANDING GEAR ASSY
101-810032-3		MAIN LANDING GEAR ASSY
101-810033-1		MAIN LANDING GEAR ASSY
101-810033-13		MAIN LANDING GEAR ASSY
101-810033-3		MAIN LANDING GEAR ASSY
101-810033-5		MAIN LANDING GEAR ASSY
101-810033-7		MAIN LANDING GEAR ASSY
101-810036-1		MAIN LANDING GEAR ASSY
101-810045-0009		MLG ASSY
101-810045-1		MAIN LANDING GEAR ASSY
101-810045-3		MLG ASSY
101-810045-601		MLG ASSY
101-810057-1		MAIN LANDING GEAR ASSY
101-810081-1		MLG ASSY
101-810081-3		MLG ASSY
101-810082-1		MLG ASSY
101-810082-3		MLG ASSY
101-810091-7		MAIN LANDING GEAR DRAG BRACE
101-810091-9		MAIN LANDING GEAR DRAG BRACE



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
101-810101-1		MAIN LANDING GEAR DRAG BRACE
101-810133-11		DRAG LEG ASSY
101-810133-15		DRAG LEG ASSY
101-810133-5		DRAG LEG ASSY
101-810133-7		DRAG LEG ASSY
101-810133-9		DRAG LEG ASSY
101-810134-11		DRAG LEG ASSY
101-810134-13		DRAG LEG ASSY
101-810134-15		DRAG LEG ASSY
101-810134-9		DRAG LEG ASSY
101-810135-17		DRAG LEG ASSY
101-810135-19		DRAG LEG ASSY
101-810157-1		DRAG LEG ASSY
101-810157-13		DRAG LEG ASSY
101-810157-15		DRAG LEG ASSY
101-810157-3		DRAG LEG ASSY
101-810157-5		DRAG LEG ASSY
101-810157-7		DRAG LEG ASSY
101-810157-9		DRAG LEG ASSY
101-810158-1		MLG ASSY
101-810158-651		MLG ASSY
101-810171-1		MAIN LANDING GEAR ASSY
101-810171-3		MAIN LANDING GEAR ASSY
101-810171-651		MAIN LANDING GEAR ASSY
101-810172-1		MAIN LANDING GEAR ASSY
101-810172-601		MAIN LANDING GEAR ASSY
101-810175-3		DRAG LEG ASSY
101-810175-5		DRAG LEG ASSY
101-810176-3		DRAG LEG ASSY
101-810213-0001		MAIN LANDING GEAR ASSY
101-820000-1		NOSE LANDING GEAR ASSY
101-820000-7		NOSE LANDING GEAR ASSY
101-820001-1		NOSE LANDING GEAR ASSY
101-820020-11		NOSE LANDING GEAR ASSY
101-820020-15		NOSE LANDING GEAR ASSY
101-820020-19		NOSE LANDING GEAR ASSY
101-820020-3		NOSE LANDING GEAR ASSY
101-820020-603		NOSE LANDING GEAR ASSY
101-820020-615		NOSE LANDING GEAR ASSY
101-820020-7015		NOSE LANDING GEAR ASSY
101-820021-3		NOSE LANDING GEAR ASSY
101-820024-13		NOSE LANDING GEAR ASSY
101-820024-15		NOSE LANDING GEAR ASSY
101-820024-5		NOSE LANDING GEAR ASSY
101-820025-5		NOSE LANDING GEAR ASSY



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
101-820029-11		NOSE LANDING GEAR ASSY
101-820029-23		NOSE LANDING GEAR ASSY
101-820029-27		NOSE LANDING GEAR ASSY
101-820029-29		NOSE LANDING GEAR ASSY
101-820029-31		NOSE LANDING GEAR ASSY
101-820029-5		NOSE LANDING GEAR ASSY
101-820034-1		NOSE GEAR DRAG BRACE ASSY
101-820034-5		NOSE GEAR DRAG BRACE ASSY
101-820034-7		NOSE GEAR DRAG BRACE ASSY
101-820035-1		NOSE GEAR DRAG BRACE ASSY
101-820035-3		NOSE GEAR DRAG BRACE ASSY
101-820064-1		NW STEERING LINK ASSY
101-820064-5		NW STEERING LINK ASSY
101-820064-7		NW STEERING LINK ASSY
101-820074-1		NOSE LANDING GEAR ASSY
101-820074-601		NOSE LANDING GEAR ASSY
101-820074-607		NOSE LANDING GEAR ASSY
102-364059-1		PCB ASSY
102-364059-3		PCB ASSY
103648-1		OUTFLOW VALVE
103648-10		OUTFLOW VALVE
103648-2		OUTFLOW VALVE
103648-3		OUTFLOW VALVE
103648-4		OUTFLOW VALVE
103648-5		OUTFLOW VALVE
103648-6		OUTFLOW VALVE
103648-7		OUTFLOW VALVE
103648-8		OUTFLOW VALVE
103648-9		OUTFLOW VALVE
109-389002-5		FUEL SHUTOFF VALVE
109-389002-7		FUEL SHUTOFF VALVE
109-389002-9		FUEL SHUTOFF VALVE
109-524329-1		ELEC ELEV TRIM TAB ACT ASSY
114-380028-1		BLOWER ASSY
114-380028-5		BLOWER ASSY
114-389039-11		ACTUATOR
114-389039-21		ACTUATOR
114-389039-23		ACTUATOR
114-389039-25		ACTUATOR
114-389039-3		ACTUATOR
114-389039-9		ACTUATOR
114-810022-7		MLG ASSY
114-820069-1		NOSE LANDING GEAR ASSY
115-380002		LANDING GEAR MOTOR
115-380002-3		MOTOR



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
115-380002-5		MOTOR
115-380113		MAIN LANDING GEAR ASSY
115-384007		CENTRIFUGAL FAN
115-810000-619		MLG ASSY
115-810000-620		MLG ASSY
115-810000-623		MLG ASSY
115-810000-624		MLG ASSY
115-810000-627		MLG ASSY
115-810000-628		MLG ASSY
115-810000-629		MLG ASSY
115-810000-630		MLG ASSY
115-810000-653		MLG ASSY
115-810000-654		MLG ASSY
115-810000-655		MLG ASSY
115-810000-656		MLG ASSY
115-811020-11		LANDING GEARBOX & MOTOR ASSYS
115-811020-13		LANDING GEARBOX & MOTOR ASSYS
115-811020-3		LANDING GEARBOX & MOTOR ASSYS
115-811020-5		LANDING GEARBOX & MOTOR ASSYS
115-811020-611		LANDING GEARBOX & MOTOR ASSYS
115-811020-613		LANDING GEARBOX & MOTOR ASSYS
115-811020-615		LANDING GEARBOX & MOTOR ASSYS
115-811020-651		LANDING GEARBOX & MOTOR ASSYS
115-811020-653		LANDING GEARBOX & MOTOR ASSYS
115-811020-671		LANDING GEARBOX & MOTOR ASSYS
115-811020-673		LANDING GEARBOX & MOTOR ASSYS
115-811020-675		LANDING GEARBOX & MOTOR ASSYS
115-811020-7		LANDING GEARBOX & MOTOR ASSYS
115-811020-9		LANDING GEARBOX & MOTOR ASSYS
115-811039		LANDING GEARBOX & MOTOR ASSYS
115-820034-11		NLG DRAG BRACE ASY
115-820034-13		NLG DRAG BRACE ASY
115-820034-17		NLG DRAG BRACE ASY
115-820066-3		NOSE LANDING GEAR ASSY
115-820068-21		NOSE LANDING GEAR ASSY
115-820068-5		NOSE LANDING GEAR ASSY
130346-1		PRESSURE CONTROLLER
130346-11		PRESSURE CONTROLLER
130346-12		PRESSURE CONTROLLER
130346-4		PRESSURE CONTROLLER



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
130346-6		PRESSURE CONTROLLER
130346-7		PRESSURE CONTROLLER
130-364048-11		PCB ASSY
130-364048-13		PCB ASSY
130-364048-15		PCB ASSY
130-364048-17		PCB ASSY
130-364048-19		PCB ASSY
130-364048-21		PCB ASSY
130-364048-23		PCB ASSY
130-364048-25		PCB ASSY
130-364048-27		PCB ASSY
130-364048-5		PCB ASSY
130-364048-9		PCB ASSY
130-364078-1		PCB ASSY
130-364078-11		PCB ASSY
130-364078-13		PCB ASSY
130-364078-3		PCB ASSY
130-364078-7		PCB ASSY
130-364078-9		PCB ASSY
130-364090-1		PCB ASSY
130-524051-11		RUDDER TRIM TAB ACT
130-810021-0001		MLG ASSY
130-810021-6001		MLG ASSY
130-810023-0001		MLG ASSY
130-810172-601		MLG ASSY
1532-10A		DEICER DISTRIBUTING VALVE
1532-10C		DEICER DISTRIBUTING VALVE
1532-11A		DEICER DISTRIBUTING VALVE
1532-11B		DEICER DISTRIBUTING VALVE
1532-11C		DEICER DISTRIBUTING VALVE
1532-11D		DEICER DISTRIBUTING VALVE
1532-2A		DEICER DIST VALVE
1532-3A		DEICER DIST VALVE
1532-3B		DEICER DIST VALVE
1532-6A		DEICER DIST VALVE
1532-6C		DEICER DIST VALVE
1532-8A		DEICER DISTRIBUTING VALVE
1532-8C		DEICER DISTRIBUTING VALVE





**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
161-17301		WHEEL & BRAKE ASSY
161-18000		WHEEL & BRAKE ASSY
162-18000		WHEEL & BRAKE ASSY
184-218		MLG BRAKE ASSY
200102-1		STATIC INVERTER
200102-2		STATIC INVERTER
200107-1		STATIC INVERTER
200129-1		STATIC INVERTER
200131-1		STATIC INVERTER
200-9000-001		ACTUATOR
2-1301		MAIN BRAKE ASSY
2-1301-1		MAIN BRAKE ASSY
2-1573		MLG BRAKE ASSY
2-1574		MLG BRAKE ASSY
2-1576		MAIN BRAKE ASSY
24002-2		CENTRIFUGAL BLOWER ASSY
26501-1		COMPRESSOR DRIVE MOTOR
26501-2		COMPRESSOR DRIVE MOTOR
26501-3		COMPRESSOR DRIVE MOTOR
266-178		MAIN BRAKE ASSY
266-178-1		MAIN BRAKE ASSY
2-7796-1		MLG D/L RELEASE CYLINDER
2-7796-2		MLG D/L RELEASE CYLINDER
2-7796-3		MLG D/L RELEASE CYLINDER
2-7796-4		MLG D/L RELEASE CYLINDER
300-282-1		NLG WHEEL ASSY-MAGNESIUM
300-465-1		MLG WHEEL ASSY
300-466		MLG WHEEL ASSY
300-712		NLG WHEEL ASSY-ALUMINUM
30-146		WHEEL & BRAKE ASSY
3-1208-1		MLG WHEEL ASSY
3-1209-2		NLG WHEEL ASSY-MAGNESIUM
3-1283		MLG WHEEL
3-1341-1		MLG WHEEL ASSY
3-1481		NLG WHEEL ASSY-ALUMINUM
331A-3G		COURSE IND
331A-6P		COURSE IND
331A-6R		COURSE IND



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
33-524023-23		ELEC ELEV TRIM TAB ACT
33-524023-27		ELEC ELEV TRIM TAB ACT
33-524023-41		ELEC ELEV TRIM TAB ACT
33-524023-51		ELEC ELEV TRIM TAB ACT
33-524023-55		ELEC ELEV TRIM TAB ACT
33-524023-67		ELEC ELEV TRIM TAB ACT
33-524023-73		ELEC ELEV TRIM TAB ACT
33-524023-75		ELEC ELEV TRIM TAB ACT
33-524023-79		ELEC ELEV TRIM TAB ACT
339F-12		RECEIVER TRANSMITTER
339F-12A		RECEIVER TRANSMITTER
339F-12B		RECEIVER TRANSMITTER
339F-12C		RECEIVER TRANSMITTER
339F-12D		RECEIVER TRANSMITTER
339F-12E		RECEIVER TRANSMITTER
35-815196-612		MLG ASSY
35-815196-613		MLG ASSY
35-815254-655		MLG ASSY
35-815254-656		MLG ASSY
35-825001-2		NLG ASSY
35-825001-8		NLG ASSY
35-825090		NLG ASSY
35-825110-4		NLG ASSY
35-825125		NLG ASSY
35-825196-615		NLG ASSY
35-825196-616		NLG ASSY
35-825196-620		NLG ASSY
35-825196-691		NLG ASSY
35-825196-695		NLG ASSY
36-820020-1		NLG ASSY
38E85-5C		REGULATING & RELIEF VALVE
40-1		LANDING GEAR MOTOR
4016341-901		BAROMETRIC ALT IND
4016341-902		BAROMETRIC ALT IND
4016341-903		BAROMETRIC ALT IND
4016341-904		BAROMETRIC ALT IND
4016341-905		BAROMETRIC ALT IND
4016341-906		BAROMETRIC ALT IND



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
4016341-907		BAROMETRIC ALT IND
40-170A		WHEEL ASSY
40-2		MOTOR
40-204		NOSE WHEEL ASSY
40-289		WHEEL & BRAKE ASSY
40-3		LANDING GEAR MOTOR
40-6		MOTOR
45A65575-11		MLG D/L RELEASE CYLINDER
45A65575-12		MLG D/L RELEASE CYLINDER
45AS38510-007		MLG D/L RELEASE CYLINDER
45AS38510-5		MLG D/L RELEASE CYLINDER
45AS38510-6		MLG D/L RELEASE CYLINDER
45AS38510-7		MLG D/L RELEASE CYLINDER
45AS38510-8		MLG D/L RELEASE CYLINDER
4A196-17		MLG ACT ASSY
4A196-19		MLG ACT ASSY
5002460-1		MAIN WHEEL ASSY
5002460-2		MAIN WHEEL ASSY
5002464-1		MAIN WHEEL ASSY
5004-1		CENTRIFUGAL BLOWER ASSY
50-300010-109		MLG WHEEL ASSY
50-300010-119		MLG BRAKE ASSY
50-300010-133		MLG WHEEL ASSY
50-300010-87		MLG WHEEL ASSY
50-300010-95		MLG BRAKE ASSY
50-380114-5		LANDING GEAR MOTOR
50-380116		CENTRIFUGAL FAN
50-521152-1		FLAP ACTUATOR ASSY
50-521152-2		FLAP ACTUATOR ASSY
50-521198-3		FLAP ACTUATOR ASSY
50-521198-4		FLAP ACTUATOR ASSY
50-521223-3		FLAP ACTUATOR ASSY
50-521223-4		FLAP ACTUATOR ASSY
50-524161-11		ELEVATOR TAB ACT ASSY
50-524161-604		ELEVATOR TAB ACT ASSY
50-524161-605		ELEVATOR TAB ACT ASSY
50-524161-606		ELEVATOR TAB ACT ASSY
50-524161-607		ELEVATOR TAB ACT ASSY



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
50-810032-12		MAIN LANDING GEAR ASSY
50-810032-4		MLG ASSY
50-810032-8		NOSE LANDING GEAR ASSY
50-810037		MLG DRAG BRACE ASSY
50-810037-613		MAIN GEAR DRAG BRACE ASSY
50-810037-614		MAIN GEAR DRAG BRACE ASSY
50-810037-615		MAIN GEAR DRAG BRACE ASSY
50-810037-616		MAIN GEAR DRAG BRACE ASSY
50-810039-10		MAIN GEAR DRAG BRACE ASSY
50-810039-8		MAIN GEAR DRAG BRACE ASSY
50-810040-4		MLG DRAG BRACE ASY
50-810040-6		MAIN LANDING GEAR ASSY
50-810164-13		MLG ACT
50-810164-14		MLG ACT
50-810164-15		MLG ACT
50-810164-16		MLG ACT
50-810164-17		MLG ACT
50-810164-18		MLG ACT
50-810164-19		MLG ACT
50-810164-20		MLG ACT
50-810164-3		MLG ACT
50-810164-4		MLG ACT
50-810168-5		NLG ACTUATOR
50-810200-5		LG RETRACT BOX ASSY
50-810200-630		GEARBOX
50-810200-660		GEARBOX
50-810200-662		GEARBOX
50-810200-7		GEARBOX
50-810244-3		NLG ACTUATOR
50-810244-6003		NLG ACTUATOR
50-810250		MLG ASSY
50-810250-1		MAIN LANDING GEAR ASSY
50-810250-3		MAIN LANDING GEAR ASSY
50-810250-6001		MAIN LANDING GEAR ASSY
50-810286-21		MAIN LANDING GEAR ASSY
50-810286-22		MAIN LANDING GEAR ASSY
50-810288-7		NOSE LANDING GEAR ASSY
50-810290-5		MAIN LANDING GEAR ASSY



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
50-810292-1		MAIN LANDING GEAR ASSY
50-810295-11		NOSE GEAR ASSY
50-810295-17		MLG ASSY
50-810295-21		MLG ASSY
50-810295-25		MAIN LANDING GEAR ASSY
50-810295-29		NOSE LANDING GEAR ASSY
50-810304-621		MLG ASSY
50-810304-622		MLG ASSY
50-810304-651		MAIN LANDING GEAR ASSY
50-810304-652		MAIN LANDING GEAR ASSY
50-810304-659		MLG ASSY
50-810304-660		MLG ASSY
50-810304-679		MAIN LANDING GEAR ASSY
50-810304-680		MAIN LANDING GEAR ASSY
50-810310-1		MAIN LANDING GEAR ASSY
50-810318-5		MLG ASSY
50-810318-603		MLG ASSY
50-810318-607		MLG ASSY
50-810318-655		MLG ASSY
50-810320-27		MAIN LANDING GEAR ASSY
50-810320-3		MAIN LANDING GEAR ASSY
50-810323		MLG ASSY
50-810323-7		MLG ASSY
50-810323-9		MLG ASSY
50-810330-5		MAIN LANDING GEAR ASSY
50-810332-7		MLG ASSY
50-810335		MAIN LANDING GEAR DRAG BRACE
50-810335-13		MAIN LANDING GEAR DRAG BRACE
50-810335-15		MAIN LANDING GEAR DRAG BRACE
50-810335-17		MAIN LANDING GEAR DRAG BRACE
50-810335-19		MAIN LANDING GEAR DRAG BRACE
50-810335-5		MAIN LANDING GEAR DRAG BRACE
50-810335-7		MAIN LANDING GEAR DRAG BRACE
50-810336		MAIN LANDING GEAR ASSY
50-810337-10		MAIN LANDING GEAR DRAG BRACE
50-810337-13		MAIN LANDING GEAR DRAG BRACE
50-810337-14		MAIN LANDING GEAR DRAG BRACE
50-810337-9		MAIN LANDING GEAR DRAG BRACE



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
50-810370		MAIN LANDING GEAR ASSY
50-810370-1		MAIN LANDING GEAR ASSY
50-810370-3		MAIN LANDING GEAR ASSY
50-810370-4		MAIN LANDING GEAR ASSY
50-820004		SHIMMY DAMPENER
50-820010-29		NOSE LANDING GEAR ASSY
50-820010-605		DRAG BRACE ASSY
50-820010-609		NLG DRAG BRACE ASSY
50-820023-8		NOSE LANDING GEAR ASSY
50-820034-19		NW STEERING LINK ASSY
50-820035-8		NW STEERING LINK ASSY
50-820176		NLG ASSY
50-820176-3		NLG ASSY
50-820196-651		NOSE GEAR ASSY
50-820196-652		NOSE GEAR ASSY
50-820196-655		NLG ASSY
50-820197-3		NOSE GEAR ASSY
50-820197-5		NOSE GEAR ASSY
50-820197-602		NLG ASSY
50-820197-604		NOSE GEAR ASSY
50-820201-613		NW STEERING LINKAGE ASSY
50-820204-17		NOSE LANDING GEAR ASSY
50-820204-21		NOSE LANDING GEAR ASSY
50-820204-25		NOSE LANDING GEAR ASSY
50-820204-27		NOSE GEAR ASSY
50-820204-3		NOSE GEAR ASSY
50-820204-41		NOSE LANDING GEAR ASSY
50-820204-43		NOSE LANDING GEAR ASSY
50-820204-45		NOSE LANDING GEAR ASSY
50-820204-47		NOSE LANDING GEAR ASSY
50-820205-13		DRAG BRACE ASSY
50-820205-19		NOSE DRAG BRACE ASSY
50-820205-21		NOSE DRAG BRACE ASSY
50-820205-23		NOSE DRAG BRACE ASSY
50-820205-25		NOSE DRAG BRACE ASSY
50-820208		NLG ACTUATOR
50-820208-1		NLG ACTUATOR
50-820208-3		NLG ACTUATOR



**WINGS AEROSPACE, LLC**  
**KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
50-820208-5		NLG ACTUATOR
50-820229-1		NOSE LANDING GEAR ASSY
522-2638-000		COURSE IND
522-2638-001		COURSE IND
522-2638-002		COURSE IND
522-2638-003		COURSE IND
522-2638-005		COURSE IND
522-2638-006		COURSE IND
522-2638-007		COURSE IND
522-2638-008		COURSE IND
522-2638-009		COURSE IND
522-2638-010		COURSE IND
614E-23C		FLIGHT MODE SEL
614E-23E		FLIGHT MODE SEL
614E-23G		FLIGHT MODE SEL
622-0210-001		FLIGHT MODE SEL
622-0210-002		FLIGHT MODE SEL
622-0210-003		FLIGHT MODE SEL
622-0210-004		FLIGHT MODE SEL
622-1233-001		RECEIVER TRANSMITTER
622-1233-003		RECEIVER TRANSMITTER
622-1234-002		RECEIVER TRANSMITTER
622-1234-003		RECEIVER TRANSMITTER
622-1234-004		RECEIVER TRANSMITTER
622-1234-005		RECEIVER TRANSMITTER
622-1234-007		RECEIVER TRANSMITTER
622-1234-012		RECEIVER TRANSMITTER
622-1234-013		RECEIVER TRANSMITTER
622-1234-016		RECEIVER TRANSMITTER
622-1234-017		RECEIVER TRANSMITTER
622-1234-113		RECEIVER TRANSMITTER
622-1234-207		RECEIVER TRANSMITTER
622-1234-313		RECEIVER TRANSMITTER
622-1334-001		VHF TRANSCEIVER
622-1334-002		VHF TRANSCEIVER
622-1879-001		VHF TRANSCEIVER
622-1879-002		VHF TRANSCEIVER
622-2012-011		RECEIVER TRANSMITTER



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
622-2012-012		RECEIVER TRANSMITTER
622-2012-013		RECEIVER TRANSMITTER
622-2012-014		RECEIVER TRANSMITTER
622-2012-201		RECEIVER TRANSMITTER
622-2175-001		RECEIVER TRANSMITTER
622-2175-002		RECEIVER TRANSMITTER
622-2175-003		RECEIVER TRANSMITTER
622-2175-004		RECEIVER TRANSMITTER
622-2175-201		RECEIVER TRANSMITTER
622-2176-001		RECEIVER TRANSMITTER
622-2176-002		RECEIVER TRANSMITTER
622-2176-201		RECEIVER TRANSMITTER
622-2177-001		RECEIVER TRANSMITTER
622-3001-001		RECEIVER TRANSMITTER
622-3881-001		RECEIVER TRANSMITTER
622-3881-002		RECEIVER TRANSMITTER
622-3915-001		RECEIVER TRANSMITTER
622-3915-002		RECEIVER TRANSMITTER
622-3916-001		RECEIVER TRANSMITTER
622-3916-002		RECEIVER TRANSMITTER
622-3917-001		RECEIVER TRANSMITTER
622-3917-002		RECEIVER TRANSMITTER
622-3918-001		RECEIVER TRANSMITTER
622-3918-002		RECEIVER TRANSMITTER
622-3919-001		RECEIVER TRANSMITTER
622-3919-002		RECEIVER TRANSMITTER
622-3920-001		RECEIVER TRANSMITTER
622-3920-002		RECEIVER TRANSMITTER
622-3921-001		RECEIVER TRANSMITTER
622-3921-002		RECEIVER TRANSMITTER
622-4938-001		RADIO MAG IND
622-4938-002		RADIO MAG IND
622-4938-003		RADIO MAG IND
622-4938-004		RADIO MAG IND
622-4938-005		RADIO MAG IND
622-4938-006		RADIO MAG IND
622-4938-007		RADIO MAG IND
622-4938-021		RADIO MAG IND





**WINGS AEROSPACE, LLC**  
**KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
622-4938-022		RADIO MAG IND
622-4938-023		RADIO MAG IND
622-4938-024		RADIO MAG IND
622-4938-025		RADIO MAG IND
622-4938-026		RADIO MAG IND
622-4938-027		RADIO MAG IND
622-6137-001		NAV RECEIVER
622-6137-201		NAV RECEIVER
622-6152-001		VHF COMM TRANS
622-6152-002		VHF COMM TRANS
622-6152-011		VHF COMM TRANS
622-6152-012		VHF COMM TRANS
622-6152-021		VHF COMM TRANS
622-6152-022		VHF COMM TRANS
622-6152-031		VHF COMM TRANS
622-6152-032		VHF COMM TRANS
622-6153-001		VHF COMM TRANS
622-6153-002		VHF COMM TRANS
622-6153-021		VHF COMM TRANS
622-6153-022		VHF COMM TRANS
622-6389-001		VHF COMM TRANS
622-6389-002		VHF COMM TRANS
622-6389-011		VHF COMM TRANS
622-6389-012		VHF COMM TRANS
622-6390-001		VHF COMM TRANS
622-6390-002		VHF COMM TRANS
630-1000		BLOWER ASSY
630-1001-1		BLOWER ASSY
640-1000		BLOWER ASSY
7001179-951		HSI
7001179-952		HSI
7001179-953		HSI
7001179-954		HSI
7001179-955		HSI
7001179-956		HSI
7001179-957		HSI
7001179-958		HSI
7001179-959		HSI



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
7001179-960		HSI
7001179-961		HSI
7001179-962		HSI
7001179-963		HSI
7001179-964		HSI
7001179-965		HSI
7001179-966		HSI
7001179-971		HSI
7001179-972		HSI
7001179-975		HSI
7001179-976		HSI
772-5410-001		FLIGHT MODE SEL
772-5410-002		FLIGHT MODE SEL
772-5410-003		FLIGHT MODE SEL
772-5410-004		FLIGHT MODE SEL
787-6385-001		COURSE IND
787-6385-002		COURSE IND
787-6385-003		COURSE IND
787-6385-004		COURSE IND
787-6385-005		COURSE IND
787-6385-006		COURSE IND
792-6356-002		COURSE IND
792-6356-003		COURSE IND
792-6356-004		COURSE IND
792-6470-001		FLIGHT MODE SEL
792-6470-002		FLIGHT MODE SEL
792-6470-003		FLIGHT MODE SEL
792-6470-004		FLIGHT MODE SEL
792-6657-001		VHF COMM TRANS
792-6657-003		VHF COMM TRANS
792-6657-004		VHF COMM TRANS
792-6669-001		FLIGHT MODE SEL
792-6669-002		FLIGHT MODE SEL
792-6669-003		FLIGHT MODE SEL
792-6669-004		FLIGHT MODE SEL
822-0400-001		NAV RECEIVER
822-1111-001		VHF COMM TRANS
822-1112-001		VHF COMM TRANS



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
822-1113-001		VHF COMM TRANS
822-1113-021		VHF COMM TRANS
822-1114-001		VHF COMM TRANS
822-1114-021		VHF COMM TRANS
8DJ81BLB4		TACH IND
8DJ81BLC4		TACH IND
8DJ81LAA4		TACH IND
8DJ81LCP4		TACH IND
8DJ81LCR4		TACH IND
8DJ81LCT4		TACH IND
8DJ81LSC4		TACH IND
8DJ81LSC4-U		TACH IND
8DJ81LVA4		TACH IND
8DJ81LVB4		TACH IND
8DJ81LVB4-U		TACH IND
8DJ81LVF4		TACH IND
8DJ81LVG4		TACH IND
8DJ81LVL4		TACH IND
8DJ81LVL4-U		TACH IND
8DJ81LWA4		TACH IND
8DJ81LWC4		TACH IND
8DJ81LWR4		TACH IND
8DJ81LWS4		TACH IND
8DJ81LWT4		TACH IND
8DJ81LWT4-U		TACH IND
8DJ81LWY4		TACH IND
8DJ81LWZ4		TACH IND
8DJ81LXF4		TACH IND
8DJ81LXF4-U		TACH IND
8DJ81LXG4		TACH IND
8DJ81LXG4-U		TACH IND
8DJ81LXH4		TACH IND
8DJ81LXH4-U		TACH IND
8DJ81LXK4		TACH IND
8DJ81LXT4		TACH IND
8DJ81LYP4		TACH IND
8DJ81LYT4		TACH IND
8DJ81LYT4-U		TACH IND



**WINGS AEROSPACE, LLC**  
**KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
8DJ81LYV4		TACH IND
8DJ81LYV4-U		TACH IND
8DJ81LYX4		TACH IND
8DJ81LZC4		TACH IND
8DJ81LZE4		TACH IND
8DJ81LZF4		TACH IND
8DJ81WAG4		TACH IND
8DJ81WAG4-U		TACH IND
8DJ81WAL4		TACH IND
8DJ81WAP4		TACH IND
8DJ81WAY4		TACH IND
8DJ81WBA4		TACH IND
8DJ81WBB4		TACH IND
8DJ81WBC4		TACH IND
8DJ81WBD4		TACH IND
8DJ81WBF4		TACH IND
8DJ81WBF4-U		TACH IND
8DJ81WBG4		TACH IND
8DJ81WBG4-U		TACH IND
8DJ81WBL4		TACH IND
8DJ81WBM4		TACH IND
8DJ81WBS4		TACH IND
8DJ81WBT4		TACH IND
8DJ81WCF4		TACH IND
8DJ81WCF4-U		TACH IND
8DJ81WCG4		TACH IND
8DJ81WCG4-U		TACH IND
8DJ81WCR4		TACH IND
8DJ81WCS4		TACH IND
8DJ81WCT4		TACH IND
8DJ81WCT4-U		TACH IND
8DJ81WCW4		TACH IND
8DJ81WCW4-U		TACH IND
8DJ81WCX4		TACH IND
8DJ81WDK4		TACH IND
8DJ81WDL4		TACH IND
8DJ81WDL4U		TACH IND
90-380000-3		REGULATING & RELIEF VALVE



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
90-380038-1		MLG BRAKE ASSY
90-384031-1		BLOWER ASSY
90-521024-1		FLAP ACTUATOR ASSY
90-521024-2		FLAP ACTUATOR ASSY
90-521024-6002		FLAP ACTUATOR ASSY
90-810018-1		MLG ACT
90-810036-1		MLG ACT
90-810039-1		MAIN LANDING GEAR ASSY
90-810039-2		MAIN LANDING GEAR ASSY
90-810040-1		MLG DRAG BRACE ASY
90-810040-2		MLG DRAG BRACE ASY
90-820020-13		NOSE GEAR DRAG BRACE ASSY
90-820020-15		NOSE LANDING GEAR ASSY
90-820020-9		NOSE GEAR DRAG BRACE ASSY
91-380002-3		LANDING GEAR MOTOR
91-810010-1		GEARBOX
91-810010-3		GEARBOX
91-810010-5		GEARBOX
91-810010-601		GEARBOX
91-810010-605		GEARBOX
91-810010-7		GEARBOX
9544061-1		BRAKE ASSY
9544397-1		BRAKE ASSY
95-824018		NLG ASSY
96-526000		RUDDER TRIM TAB ACT ASSY
96-526000-605		RUDDER TRIM TAB ACT
96-526000-609		RUDDER TRIM TAB ACT ASSY
97-820000-601		NOSE LANDING GEAR ASSY
97-820000-609		NOSE LANDING GEAR ASSY
97-820000-611		NOSE LANDING GEAR ASSY
97-820000-613		NOSE LANDING GEAR ASSY
97-820000-617		NOSE LANDING GEAR ASSY
97-820000-652		NOSE LANDING GEAR ASSY
97-820000-653		NOSE LANDING GEAR ASSY
97-820000-659		NOSE LANDING GEAR ASSY
97-820000-671		NOSE LANDING GEAR ASSY
99-8003-23		BRAKE ASSY
99-8003-5		BRAKE ASSY



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
99-8003-7		BRAKE ASSY
99-8004-3		BRAKE ASSY
99-810000-607		MLG ASSY
99-810000-608		MLG ASSY
99-810000-611		MLG ASSY
99-810000-612		MLG ASSY
99-810000-615		MLG ASSY
99-810000-616		MLG ASSY
99-810000-651		MLG ASSY
99-810000-652		MLG ASSY
99-810025-605		MLG ASSY
99-810027-11		MLG ASSY
99-810028-11		MLG ASSY
99-810028-15		MAIN LANDING GEAR ASSY
99-810028-23		MLG ASSY
99-810028-27		MAIN LANDING GEAR ASSY
99-810028-7		MLG ASSY
99-820100-5		NOSE LANDING GEAR ASSY
AI-BA128A-1		VANE AXIAL BLOWER ASSY
AI-BA128A-2		VANE AXIAL BLOWER ASSY
BA128A-1		VANE AXIAL BLOWER ASSY
BA128A-2		VANE AXIAL BLOWER ASSY
BA-141		BAROMETRIC ALT IND
BC89A-1		CENTRIFUGAL BLOWER ASSY
C180-559A1		CENTRIFUGAL FAN W/MOTOR
C241-500BB		CENTRIFUGAL FAN W/MOTOR
C308-559A		CENTRIFUGAL FAN
C316A		CENTRIFUGAL FAN
D1931		LANDING GEAR MOTOR
DME-40		RECEIVER TRANSMITTER
EM424-1		FUEL SHUTOFF VALVE
EM424-2		FUEL SHUTOFF VALVE
EM424-3		FUEL SHUTOFF VALVE
EM424-4		FUEL SHUTOFF VALVE
EM424-5		FUEL SHUTOFF VALVE
EM424-6		FUEL SHUTOFF VALVE
EM424-7		FUEL SHUTOFF VALVE
EM424-8		FUEL SHUTOFF VALVE



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
EM424-9		FUEL SHUTOFF VALVE
EM424-9P		FUEL SHUTOFF VALVE
EM450-1		ACTUATOR
EM450-2		ACTUATOR
EM450-3		ACTUATOR
EM450-4		ACTUATOR
EM450-5		ACTUATOR
EM450-6		ACTUATOR
EM450-7		ACTUATOR
EM603-5		BLOWER ASSY
EM603-7		BLOWER ASSY
EM603-9		BLOWER ASSY
EM609-1		BLOWER ASSY
EM609-3		BLOWER ASSY
EM609-4		BLOWER ASSY
EM609-5		BLOWER ASSY
EM609-6		BLOWER ASSY
EM609-6P		BLOWER ASSY
EM630		BLOWER ASSY
EM630-2		BLOWER ASSY
EM630-3		BLOWER ASSY
EM630-3P		BLOWER ASSY
EM640-1		BLOWER ASSY
EM640-2		BLOWER ASSY
IND-40		RECEIVER TRANSMITTER
IND-40A		RECEIVER TRANSMITTER
IND-40B		RECEIVER TRANSMITTER
IND-40C		RECEIVER TRANSMITTER
IND-41		RECEIVER TRANSMITTER
IND-41A		RECEIVER TRANSMITTER
IND-41B		RECEIVER TRANSMITTER
IND-41C		RECEIVER TRANSMITTER
M2620B		CENTRIFUGAL FAN
M2620BA		CENTRIFUGAL FAN
M3448B1		CENTRIFUGAL FAN W/MOTOR
M3524AB		CENTRIFUGAL FAN W/MOTOR
M7921C-1D		VANEAXIAL FAN W/MOTOR ASSY
PC-15		STATIC INVERTER



**WINGS AEROSPACE, LLC  
KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
PC-15A		STATIC INVERTER
PC-15B		STATIC INVERTER
PC-15B()		STATIC INVERTER
PC-15B(D)		STATIC INVERTER
PC-15B(E)		STATIC INVERTER
PC-15B(F)		STATIC INVERTER
PC-15B(G)		STATIC INVERTER
PC-15BC()		STATIC INVERTER
PC-15C		STATIC INVERTER
PC-15D		STATIC INVERTER
PC-15E		STATIC INVERTER
PC-15F		STATIC INVERTER
PC-15G		STATIC INVERTER
PC-17		STATIC INVERTERS
PC-17-1		STATIC INVERTERS
PC-17-2		STATIC INVERTERS
PC-17-3		STATIC INVERTERS
PC-17-3A		STATIC INVERTERS
PC-17-3B		STATIC INVERTERS
PC-250		STATIC INVERTER
PC-250-1A		STATIC INVERTER
PC-250-1B		STATIC INVERTER
PC-250-1C		STATIC INVERTER
PC-250-2A		STATIC INVERTER
RD-550		HSI
RD-550A		HSI
RD-550B		HSI
RD-550R		HSI
RMI-30		RADIO MAG IND
RZ-220		ROLL RATE MONITOR
VHF-20		VHF COMM TRANS
VHF-20A		VHF TRANSCEIVER
VHF-20B		VHF TRANSCEIVER
VHF-21A		VHF COMM TRANS
VHF-21B		VHF COMM TRANS
VHF-21C		VHF COMM TRANS
VHF-21D		VHF COMM TRANS
VHF-22A		VHF COMM TRANS





**WINGS AEROSPACE, LLC**  
**KINGAIR REPAIR CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
VHF-22B		VHF COMM TRANS
VHF-22C		VHF COMM TRANS
VHF-22D		VHF COMM TRANS
VIR-32		NAV RECEIVER
VIR-33		NAV RECEIVER
X702-287		AXIVANE FAN