

Ipalarm module

Instructions for setup are in the file named: **Ipalarm setup**

Panel connection info is in the file named: **Ipalarm connections**

Note:

On page 2, the password for the SSID “Ipalarmwifi” is replaced with a unique password for your device.

To retrieve the unique password for your iPAalarm module, SSID, login to your account and go to

“Settings”, the unique password is available there.