

Wireless Solar Post Cap Installation Guide



Step 1
Ensure post cap light is oriented correctly in the upright position with the solar collector exposed to light.



Step 3
Test the lights by covering the solar collector to ensure lights function correctly and turn on when not exposed to light.



Step 2
While holding the post cap upright, turn on the LED lights via the push switch inside the bottom of the post cap.



Step 4
Set post cap down onto
the post and attach to post
using 2 ea. self-drilling
screws provided.