



WINGS AEROSPACE, LLC

B-234 REPAIR CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
9899	3010-00-420-5226	ACTUATOR,ELECTRO-MECHANICAL,ROTARY
18590		VALVE, ISOLATION
114ES237	6680-00-183-0374	OIL PRESS TRANSDUCER
114ES237-2	6680-00-183-0374	TRANSDUCER,PRESSURE
114H6800-6M		AFT ROTOR BLADE DAMPER
114HS124-1	4820-00-739-2606	VALVE,LINEAR,DIRECTIONAL CONTROL
114PS205-2	3010-00-420-5226	ACTUATOR,ELECTRO-MECHANICAL,ROTARY
114R2050-31		ROTOR HUB
114R2050-32		AFT ROTOR HUB
114R2196-2	5315-00-871-7302	HORIZONTAL PIN
114R3433-5		AFT DRIVE ARM
114R3434-5		FWD DRIVE ARM
114R3438-9		FWD DRIVE COLLAR
114VS808-1		SIGNAL CONDITION UNIT
119262-3		IFF CONTROL PANEL
234D1200-4		FWD TRANSMISSION
234D3200-5		NO. 1 ENG. XMSN
234D6200-5		#2 ENG XMSN
234ES202-1		ENG MONITOR
234ES212-12		ENG & ROTOR TACH IND
234HS560-4		STICK BOOST ACTUATOR
234N0003-1	1560-01-117-1084	ABSORBER ASSEMBLY
234N0003-5	1560-01-117-1084	ABSORBER ASSY
234N0003-901		ABSORBER ASSEMBLY, DYNAMIC
234PS459-1	6620-01-128-4462	TRANSMITTER,RATE OF FLOW
234R2088-1		PITCH SHAFT
234V8036-2		FSTVA CONTROL UNIT
234VS100-7		AFCS UNIT
2995-01-236-9659	1650-00-034-3674	AGB MOTOR PUMP
384332-026		XMSN OIL PRESSURE SWITCH
4019286-903		VERTICAL GYRO
414C3004		AFT YOKE SHAFT ASSY
414C3042-1	1560-01-105-1495	YOKE, LONGITUDINAL
414C3043-6		AFT YOKE SHAFT ASSY
414C3056-2		FWD CONNECTING LINK
414C3056-3		AFT CONNECTING LINK CGI
414ES201-2	6130-01-121-5118	DUAL POWER SUPPLY, FUEL FLOW
414H7000		CYLINDER, ACTUATOR
414H7000-8		CYLINDER, ACTUATOR
414H7000-9		CYLINDER, ACTUATOR
414L2410-1	1620-01-350-4882	ARM ASSEMBLY,TORQUE, LANDING GEAR
414R3505-10		AFT SWASHPLATE
414R3505-9		FWD SWASHPLATE
41PD49-4	6680-00-183-0374	OIL PRESS TRANSDUCER
61401-03		DUAL FUEL TEMP INDICATOR
622-1270-001	5895-01-015-3810	TRANSPONDER, ATC
622-2551-002		AMPLIFIER COUPLER



WINGS AEROSPACE, LLC
B-234 REPAIR CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
622-2631-003		AMPLIFIER COUPLER
622-2819-001		RECEIVER, NAV
622-4524-087		CONTROL PANEL
622-4526-015	5826-01-309-9754	ADF CONTROL PANEL
622-4527-003		ATC TRANSPONDER
622-6324-002		V/UHF CONTROL PANEL
6280E38270		CONTROL PANEL IFF
64/66750		INDICATOR, STANDBY
7000166-945		ADI
7000466-945		ATTITUDE INDICATOR IND
7000839-901		INDICATOR, RADAR ALTIMETER
707909-2		RATION DETECTOR POWER SUPPLY
7801-3000-1		TACAN ARN-136
7801-4000-1		TACAN ARN-136
80-0490-15		CAUTION PANEL
86400-4166	6645-01-358-0523	CLOCK
B692/738		INTERPHONE CONTROL
BCH10-1	2995-01-236-9659	N1 CONTROL BOX
CG1106AA02		AFCS AXIS SHUTOFF PANEL
K310A054-01		DISPLAY UNIT, COMPUTER
K320A023-01		SIGNAL DATA PROCESSOR
SYLZ7561-5	6110-01-183-4852	N2 CONTROL BOX