



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
1010	6615-01-248-0835	GYROSCOPE RATE
1761	5996-01-468-8650	LOW NOISE FET AMPLIFIER
2100	6635-01-127-4653	TESTER, ULTRASONIC
2145	6610-01-160-6585	INDICATOR, VERTICAL VELOCITY
6504	6695-01-097-0441	TESTER, OXYGEN MASK
7220	5841-01-291-6174	TRANSMIT MICROWAVE ASSEMBLY
7276	5996-01-464-4836	LOW NOISE FET AMPLIFIER
8465	6685-01-311-5141	PRESSURE TRANSMITTER
10700	6610-00-181-2539	ACCELEROMETER
11352	6130-01-082-7817	POWER SUPPLY/ ION PUMP
11700	6615-01-059-7909	RATE GYRO
13930	4810-00-717-5076	VALVE, LINEAR
44143		PUMP FUEL METERING AND DISTRIBUT
47418	2925-01-206-5230	DUAL IGNITER EXCITER LH, RH
55113	4320-00-062-0511	HYDRAULIC PUMP
55331	4320-00-062-0511	HYD PUMP
56020		AUXILIARY AC MOTOR
57640	1620-01-054-0042	STEERING UNIT, A/C NOSE WHEEL
60642	6130-01-082-7817	POWER SUPPLY/ ION PUMP
60957	2915-01-041-4481	FUEL FLOW PROPORTION
101597	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
122000	6685-01-052-5353	SENSOR DIFFERENTIAL
122100	6685-01-052-5353	DIFFERENTIAL SENSOR
126460	6605-01-058-0975	IND HORIZONTAL SITUATION
126461		INDICATOR, HORIZONTAL
135070	6610-01-132-1898	INDICATOR, ATTITUDE
150620	5895-00-539-1911	APX 101 IFF RECEIVER TRANSMITTER
154000	5895-01-112-6380	RECEIVER-TRANSMITTER, RADIO
163300	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET
163350	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET
164750	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET
168940	*_*	POWER SUPPLY ASSEMBLY
168960	*_*	TRANSMITTER ASSEMBLY
202921	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
231364	6130-01-317-1497	LOW VOLTAGE POWER SUPPLY
231364	6130-01-316-3155	LOW VOLTAGE POWER SUPPLY
234755	4810-01-456-0377	VALVE, BUTTERFLY



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
301701	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
320135	4810-01-363-1952	VALVE, REGULATIN
323135	2995-01-227-0751	VALVE ASSEMBLY ANTI-ICING JET ENG.
327065	2995-01-364-7906	ANTI-ICE VALVE ASSY
329945	2995-01-467-1617	ANTI-ICE VALVE ASSY
330454	6130-01-362-0928	POWER SUPPLY
400240	6645-00-076-3050	CLOCK, MECH
424047	1650-01-056-8914	MOTOR-PUMP HYDRAULIC
441083	3040-01-071-8325	ACTUATOR MECHANICAL
441085	3040-01-071-5952	ACTUATOR MECHANICAL
441533	3040-01-277-4737	ACTUATOR
441614	3040-01-324-9089	ACTUATOR
442115	3040-01-478-8903	ACTUATOR
472740	6680-01-060-4248	INDICATOR LIQUID QUANTITY
472887	6680-01-060-4249	FUEL QTY IND (D)
484674	5998-01-071-4905	ASSEMBLY
503600	4810-01-050-5843	VALVE, SHUTOFF
535493	6130-01-256-2085	DC/DC POWER SUPPLY
759057	2915-01-206-0686	PUMP
851836	6130-01-082-7817	POWER SUPPLY/ ION PUMP
910094	6620-01-310-4916	LIGHT OFF DETECTOR
965832	5998-01-462-7275	CIRCUIT CARD ASSEMBLY
965837	5998-01-462-7274	CIRCUIT CARD ASSEMBLY
2113245	6130-01-084-8523	POWER SUPPLY
2585726	6605-00-833-5087	TRANSMITTER REMOTE COMPASS
3129307	6130-01-388-0266	POWER SUPPLY
4046015	2935-01-007-8381	COOLER, LUBRICATING
4062403	2840-01-205-7696	DUCT, FAN, OUTER REAR
4065899	2840-01-243-2471	DUCT, FAN, OUTER FRONT
4075527	6150-01-347-9288	CABLE ASSY
4076007	2840-01-386-8242	DUCT, FAN, OUTER FRONT
4080687	2925-01-408-1480	DUAL IGNITER EXCITER LH, RH
4080993	2840-01-387-2657	DUCT, FAN, OUTER REAR
4086982	6150-01-490-4096	CABLE ASSEMBLY
5187206	5998-01-497-3309	CIRCUIT CARD ASSEMBLY
9825434	5998-01-462-7293	FRONT PANEL/MOTHERBOARD ASSEMBLY
9825435	5998-01-462-7284	POWER SUPPLY ASSEMBLY
10059851	6615-01-527-9183	RATE INTEGRATING GYRO, AJ07
12604334	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
12607535	1280-01-126-0079	RADAR SET SUBASSEMBLY
12609185	1280-01-126-0079	RADAR SET SUBASSEMBLY
12609799	6625-01-0097WF	FREQ. SYNTHESIZER
14200000	4920-00-169-1698	INTERROGATOR TEST SET
26130010	4810-00-987-3948	VALVE, SHUTOFF



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
200101135	5865-01-088-1019	OSCILLATING GROUP (2A3)
240990001	5955-01-184-7924	NONCRYSTAL CONTROLLED OSCILLATOR
7461100001	5998-01-198-7508	RIGID/FLEXIBLE CIRCUIT CARD ASSEMBLY
7461402002	5998-01-256-3428	CIRCUIT CARD ASSEMBLY
01-01375-002	5985-01-294-9788	ANTENNA 1 ELECTRONICS ASSEMBLY
01-01375-002A	5985-01-294-9788	ANTENNA 1 ELECTRONICS ASSEMBLY
01-01375-003	5985-01-352-9699	ELECTRONIC UNIT, GLOBAL
0103190-07	1680-01-053-0071	REEL SHOULDER
02-1300	1610-01-052-0823	ACTUATOR, HYD, A/R
0871BW1	6340-00-173-9074	ICE DETECTOR
10-0020-0013		OXYGEN CONVERTER
10-01126-07	6130-01-914-2914	POWER SUPPLY- DED
10-01128-07		DISPLAY HEAD ASSY AND/OR DATA DISPLAY
1003001G-21	5895-01-443-9174	TRANSPONDER SET
1003050G-5	5998-01-447-3845	CIRCUIT CARD ASSEMBLY
1003098G3	5998-01-410-7407	PC BOARD
10055016-105	5998-01-083-8968	PITCH AXIS ELECTRONIC ASSEMBLY
10055016-106	5998-01-084-1331	YAW AXIS ELECTRONIC ASSEMBLY
10055016-108	5998-01-084-1331	YAW AXIS ELECTRONIC ASSEMBLY
10055016-109	5998-01-083-8968	PITCH AXIS ELECTRONIC ASSEMBLY
10055016-110	5998-01-084-1331	YAW AXIS ELECTRONIC ASSEMBLY
10055022-103	5999-01-087-8648	POWER SUPPLY ELECTRONIC ASSEMBLY
10059851-101	6615-01-071-6110	RATE INTEGRATING GYRO, AJ07
101-00169		BARFIELD PITOT STATIC TEST
102108-18-1	1660-01-052-6752	Regulator, Air Pressure
109700-1	6130-01-356-3740	HIGH VOLTAGE POWER SUPPLY
10C-0020-6	1660-00-327-7048	LIQUID OXYGEN CONVERTER
10C-0020-9	6130-00-327-7048	CONVERTER LOX
11144-4		MONITOR FREQUENCYS
11200-10	4810-01-178-0432	VALVE
11214-1	4810-01-135-1673	MODULATING VALVE
11216-1	4810-01-122-2572	VALVE ASSEMBLY
11217-1	1660-01-134-3020	SENSOR /CONTROLLER
11217-2	1660-01-196-5999	SENSOR /CONTROLLER
11221-1	1660-01-134-3021	ELECTRICAL CONTROL BOX
11221-4		EFCS
11221-4	1660-01-134-3021	ELECTRICAL CONTROL BOX
11221-5	1660-01-205-7602	SENSOR/CONTROLLER ASSEMBLY
11221-6	1660-01-212-9012	SENSOR/CONTROLLER ASSEMBLY
11221-7	1660-01-236-1136	ELECTRICAL CONTROL BOX
11224-4	6130-01-140-2238	POWER SUPPLY
11320-2	1660-01-315-2426	SENSOR/CONTROLLER ASSY
119415-4	5895-01-272-8047	RECEIVER TRANSMITTER



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
12-018-05	6615-01-078-4943	RATE SENSOR UNIT
1211176-002	1650-01-129-5004	CYLINDER ASSY,ACT
1211178-005	1650-01-042-3259	ACT SPD BRK LH
1211178-006	1650-01-040-8468	ACTUATOR
1211179-003	1650-01-417-8525	ACTUATORS HYD.NOSE GEAR DOOR
1211180-003	1620-01-125-1559	CYLINDER AND PIS
1211180-004	1650-01-417-9655	CYLINDER ASSEMBLY ACTUATING LINE
1211262-005		ACTUATOR MLG-RH DOOR UPLOCK
1211262-006	1650-01-417-8523	ACTUATOR MLG-LH DOOR UPLOCK
12117-000	2935-01-085-2864	HEAT EXCHANGE FUEL
1218-73-3	6685-01-231-2404	EPU INDICATOR
12604334-1	6625-01-124-0226	MULTIPLIER ELECTRICAL
12604334-2	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
12604334-3	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
12604334-4	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
1281B2	6685-01-042-7835	PNEUMATIC SENSOR ASSY
1325-1	6130-01-342-7708	POWER SUPPLY
135070-5	6610-01-550-7794	ATTITUDE INDICATOR
138C418A01	5996-01-037-6505	RADIO
1419000G1	6130-01-343-1930	POWER SUPPLY
1419000G1-1	6130-01-343-1930	POWER SUPPLY
1419000G4	6130-01-343-1930	POWER SUPPLY
1419000G4-1	6130-01-343-1930	POWER SUPPLY
14-43260-501	1650-01-003-0724	CYLINDER PITCH ACTUATOR
14-51100-1	1680-00-139-8020	GEARBOX ASSEMBLY, AIRCRAFT
1463-55F-B55-1		AIRSPD INDICATOR
1463-55F-B55-4		MACH METER
14950-40	1660-00-169-1888	OXY.REGULATOR
150-022-002	6620-01-247-7655	TRANSMITTER FUEL FLOW
160001-1100	2835-01-154-3533	JET FUEL STARTER ASSEMBLY
160001-1100A	2835-01-308-3769	ENGINE, GAS TURBINE, NONAIRCRAFT
160034-400		FUEL CONTROL UNIT, JFS
160333-10-01		SIG. ACQU. UNIT
162B202A	6685-00-553-4726	INDICATOR
163295-0002	*-*	RECEIVER ASSEMBLY
163295-0003	*-*	RECEIVER ASSEMBLY
164-1	6680-00-753-8932	LOX QUN. IND
164750-0002	5895-01-436-7592	AIFF APX-109
164750-0003	5895-01-476-8255	AIFF APX-109
1647T100-13	1680-01-148-4167	ACTUATOR CANOPY
165165-0002	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
165165-0003	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET
165585-0004	*_*	INTERROGATOR SIGNAL
168300-0002	*_*	FRONT END ASSEMBLY
1685T100-5	1680-01-085-4423	ACTUATOR ELECTRO-MECHANICAL LINE
16C0202-803	5998-01-113-9523	FCS MEMORY CIRCUIT CARD ASSEMBLY
16C0605-825	6615-01-127-3160	CONTROLLER ENGAGING AUTOMETIC
16C0610-821	5998-01-462-4550	DATA COMPARATOR CIRCUIT CARD ASSEMBLY
16C0650-801	6615-01-129-7445	PANEL, MANUAL TRIM
16C0705-3	6615-01-042-7834	GYROSCOPE
16C0715-1	6680-01-039-7817	ACCELEROMETER
16C0715-3	6610-01-039-7817	ACCELEROMETER
16C0851	5998-01-331-0671	CARD ASSEMBLY
16C0851-837	5998-01-123-0046	ELECTRONIC COMP.
16C0858-801	5998-01-090-2639	AIR DATA COMPUTATION, CIRCUIT CARD ASSEMBLY
16C0864-813	5998-01-331-0671	CARD ASSEMBLY
16C0864-815	5998-01-331-0671	CARD ASSEMBLY
16C0864-817	5998-01-331-0671	CARD ASSEMBLY
16C0894	5998-01-396-9211	MEMORY POWER SUPPLY CIRCUIT CARD ASSEMBLY
16C0894-803	5998-01-396-9211	MEMORY POWER SUPPLY CIRCUIT CARD ASSEMBLY
16C1072-801	1680-01-133-6874	GRIP ASSY, CONTROL
16C1072-805	1680-01-251-4634	GRIP ASSY
16C1072-809	1680-01-302-1387	GRIP ASSY
16C1090-1	1680-01-263-0648	AIRCRAFT CONTROL STICK GRIP ASSEMBLY
16E10016-829	5998-01-439-0670	ASSEMBLY
16E10105-807	1280-01-214-0033	INTERCONNECTING
16E10180-1	1290-01-224-8924	FIRE CONTROL INTERFACE UNIT
16E10180-3	1290-01-224-8924	FIRE CONTROL INTERFACE UNIT
16E10180-5	1290-01-224-8924	FIRE CONTROL INTERFACE UNIT
16E1039-667	6130-01-153-0481	BATTERY-CHASIS CONTROL ASSEMBLY
16E1039-683	6130-01-153-0481	BATTERY-CHASIS CONTROL ASSEMBLY
16E1039-687	6130-01-206-7808	BATTERY-CHASIS CONTROL ASSEMBLY
16E1039-689	6130-01-217-6548	BATTERY CONTROL ASSY
16E10681-805	6110-01-055-3507	AIR CONDITIONER CONTROL PANEL ASSEMBLY
16E1073-817	1680-01-104-2514	PANEL
16E1080-807	6110-01-137-4061	PANEL ASSY
16E1081	6110-01-055-3507	AIR CONDITIONER CONTROL PANEL ASSEMBLY
16E1081-3	6110-01-055-3507	AIR CONDITIONER CONTROL PANEL ASSEMBLY
16E1081-5	6110-01-055-3507	AIR CONDITIONER CONTROL PANEL ASSEMBLY
16E1081-801	6110-01-055-3507	PANEL, POWER DISTRIBUTION
16E1081-801	6110-01-055-3507	AIR CONDITIONER CONTROL PANEL ASSEMBLY
16E1081-803	6110-01-055-3507	AIR CONDITIONER CONTROL PANEL ASSEMBLY
16E1081-805	6110-01-055-3507	AIR CONDITIONER CONTROL PANEL ASSEMBLY
16E1082-3	6220-01-051-0952	CONTROL ELECTRIC LIGHT
16E1082-5	6220-01-049-8835	PANEL INDICATING LIGHT
16E1082-801	6220-01-051-0952	CONTROL,ELECTRIC LIGHT
16E1082-803		PANEL



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
16E1083-803	1680-01-051-3052	PANEL POWER
16E1085-801		PANEL
16E1085-811	1680-01-317-8385	PANEAL, CONTROL ELECTRICAL
16E1132-813		LANDING GEAR CONTROL PANEL
16E1132-821		LANDING GEAR CONTROL PANEL
16E1132-823	1680-01-088-9022	LANDING GEAR CONTROL PANEL
16E1132-825		LANDING GEAR CONTROL PANEL
16E1132-827		LANDING GEAR CONTROL PANEL
16E1132-831		LANDING GEAR CONTROL PANEL
16E1132-833		LANDING GEAR CONTROL PANEL
16E1132-835		LANDING GEAR CONTROL PANEL
16E1132-837	1680-01-135-4597	LANDING GEAR PNL (FWD)
16E1132-837	1680-01-135-4597	LANDING GEAR CONTROL PANEL ASSEMBLY
16E1156-85	6110-01-201-4072	PANEL POW DISTR
16E1163-853	1680-01-135-5211	LANDING GEAR PNL (AFT)
16E1208-5	5998-01-120-2059	CIRCUIT CARD ASSEMBLY
16E1223-809	5998-01-071-9729	JTSN REL INPUT/OUTPUT CIRCUIT CARD ASSEMBLY
16E130-25	5985-01-308-1819	ANTENNA
16E1361-277	5945-01-171-7231	MATRIX ASSEMBLY
16E1361-279	1680-01-195-4710	MATRIX ASSEMBLY
16E1361-281	6110-01-179-3649	MATRIX ASSEMBLY
16E1373-825	5945-01-228-3923	RELAY ASSEMBLY
16E2504-869	6110-01-440-4999	POWER DISTRIBUTOR PANEL
16E2505-839	6110-01-440-4997	POWER DISTRIBUTOR PANEL
16E2507-837	6110-01-292-8699	PANEL POW DISTR
16E2543-833	5945-01-181-9848	MATRIX ASSEMBLY
16E2545-145	6110-01-265-1080	POWER DISTRIBUTION PANEL
16E3131-11	6130-01-209-9062	POWER SUPPLY
16E4029-803	5945-01-408-5829	LEFT AFT INTERFACE MATRIX LRU ASSEMBLY
16F8415	1680-01-472-6990	NUCLEAR CONSENT/SECURE VOICE PANEL ASSEMBLY
16F8415-809	1680-01-472-6990	NUCLEAR CONSENT/SECURE VOICE PANEL ASSEMBLY
16F8469-801	1680-01-308-7090	PANEL ASSEMBLY
16H1904-801	1650-01-136-3407	MANIFOLD ASSY
16L202-21	1630-01-045-4508	BRAKE CONT VALVE
16L202-801	1630-01-084-8399	VALVE ASSEMBLY BRAKE
16L401-811	1680-01-399-7495	LANDING GEAR CONTROL ASSEMBLY
16M002-3	1650-01-041-0477	DRIVE UNIT HYD
16M002-5	1650-01-322-6311	DRIVE UNIT, HYDRAULIC
16M002-811	1650-01-322-6311	DRIVE UNIT, HYDRAULIC
16M002-819	1650-01-368-8214	DRIVE UNIT, HYDRAULIC
16P1873-813	1680-01-114-6248	GRIP ASSY
16P1873-815	1680-01-114-6249	GRIP ASSEMBLY
16P1873-833	1680-01-289-3013	GRIP ASSY
16P1873-863	1680-01-505-5328	GRIP ASSY
16P3141-805		SWITCH
16U164-809	5998-01-119-5508	ANALOG MEASUREMENT CIRCUIT CARD ASSEMBLY



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
16U164-815	5998-01-119-5508	ANALOG MEASUREMENT CIRCUIT CARD ASSEMBLY
16U178-807	5998-01-119-5506	CONTROL PANEL LOGIC CIRCUIT CARD ASSEMBLY
16U184-811	5998-01-122-6996	MISSILE TONE/TUNE CKT CIRCUIT CARD ASSEMBLY
16VC001001-4	6685-01-042-7835	TRANSMITTER PRESSURE (PSA)
16VC002-3	6610-01-222-6439	TRANSMITTER ANGLE OF ATTACK
16VE001001-2	6130-01-052-8225	POWER SUPPLY
16VE001001-3	6220-01-061-5713	LIGHT NAVIGATION
16VE002001-1	6680-01-060-4248	INDICATOR LIQUID QUANTITY
16VE002001-3	6680-01-060-4249	INDICATOR LIQUID QUANTITY
16VE002003-3	6680-01-074-9369	TRANSMITTER
16VE002004-2	6680-01-075-4853	TRANSMITTER LIQUID QUANTITY
16VE002010-3	6680-01-173-5315	TRANSMITTER LIQUID QUANTITY
16VE002010-5	6680-01-261-5242	TRANSMITTER, LIQUID
16VE003001-3	6680-01-072-2799	TRANSMITTER LIQUID QUANTITY
16VE009002-6	1270-01-093-2256	RADAR TRANSMITTER
16VE009005-1	1270-01-042-8489	RADAR CONTROL PANEL
16VE017005-5	6615-01-078-4943	RATE SENSOR UNIT
16VE038001-4	6220-01-071-8437	LIGHT ASSEMBLY INDICATOR
16VE038002	6220-01-188-9891	WARNING LIGHT
16VE038008-3	6220-01-257-4734	LIGHT ASSEMBLY INDICATOR
16VE038009-14	6220-01-477-9591	LIGHT ASSEMBLY INDICATOR
16VE237-21	6130-01-165-2055	POWER SUPPLY
16VE237-22	6130-01-209-9062	POWER SUPPLY
16VE311001-4	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET
16VE544	6130-01-343-1930	POWER SUPPLY
16VE544-1	6130-01-343-1930	POWER SUPPLY
16VE584025-4	6130-01-388-0266	POWER SUPPLY
16VF001-2	6610-01-044-1860	INDICATOR ATTITUDE
16VF002-1	6610-01-114-6817	INDICATOR ANGLE
16VF003-2	6620-01-129-7247	INDICATOR ELECTRICAL
16VH003001-10	2835-01-116-0006	POWER UNIT GAS TURB.
16VH003001-11	2835-01-263-9440	POWER UNIT GAS TURB.
16VH307-1	1650-00-404-0445	VALVE,LINEAR,DIRECTIONAL CONTROL
16VK013001-5	1680-01-249-2355	ACTUATOR ELECTRO CANOPY
16VK013001-6	1680-01-101-4436	ACTUATOR ELECTRO CANOPY
16VK013001-8	1680-01-148-4167	ACTUATOR ELECTRO-MECHANICAL ROTARY
16VK013002-2	1680-01-085-4423	ACTUATOR ELECTRO
16VK013002-4	1680-01-142-8095	ACTUATOR ELECTRO-MECH
16VK062-2	1660-01-473-2858	OXYGEN SYSTEM
16VK064-2	1660-01-473-3547	CONCENTRATOR,OXYGEN,AIRCRAFT
16VL014002-3	1630-01-217-3142	CONTROL UNIT ANTISKID
16VM003002-1	1680-01-048-8977	ACTUATOR ELECTRO-MECHANICAL
16VM003006-4	1680-01-168-9396	ACT. ELETRO MECHANICAL LINE
16VM0046	1680-01-040-8468	CYLINDER ASSEMBLY ACTUATING LINE
16VP005-4	2915-01-083-0431	FILTER FLUID
16VP006-3	2915-01-041-4481	PROPORTIONER FUEL PUMP



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
16VP100-119	2925-01-456-6010	CONTROLLER START
16VP100-58	2835-01-235-5249	ACCESSORY DRIVEGEARBOX
16VP100-76	2925-01-115-0306	CONTROLLER, JET FUEL
16VP106-2	2835-01-069-2883	TURBINE SHAFT
16VP123-2	2835-01-115-6111	SHAFT TURBINE
16VY007002-4	4810-01-153-0975	REGULATING VALVE
16VY010002-2	1660-01-196-5999	ECS SENSOR CONTROLLER
16VY010003-1	4810-01-122-2572	VALVE ASSEMBLY
16VY012001-7	1660-01-205-7602	SENSOR/CONTROLLER ASSEMBLY
16VY012001-8	1660-01-212-9012	SENSOR/CONTROLLER ASSEMBLY
16VY102001-2	1660-01-052-5355	VALVE ASSEMBLY ENVIRONMENTAL
16VY107-1	1660-01-042-8009	SEPARATOR WATER AIR
16VY12001-4	1660-01-134-3021	ELECTRICAL CONTROL BOX
16VZ001-16	5998-01-310-8718	DUAL MODE TRANSMITTER
16VZ001-17	1270-01-418-1960	GENERATOR, RADIO FREQUENCY
16Z1450-1	1680-01-115-8047	PANEL ASSEMBLY AVTR "TCI"
179250-0003	5865-01-451-2868	COUNTERMEASURES DISPENSER SWITCH
18-1704		HYDRAULIC PRESSURE TRANSMITTER
18-1935	6620-00-290-6505	PRESSURE TRANSMITTER
18-1937		POSITION TRANSMITTER
19E235-2A	2835-01-115-6111	SHAFT TURBINE
1D5745G2	5865-01-066-1671	BIT/HIV INPUT ASSEMBLY A6
1D5745G3	5865-01-066-1671	BIT/HIV INPUT ASSEMBLY A6
200-069-002	6620-01-060-3086	TACH INDICATOR
200-069-003	6620-01-178-7838	TACH INDICATOR
2006003-105	1620-01-071-4803	LANDING GEAR TENSION STRUT
2006003-107	1620-01-441-6911	LANDING GEAR TENSION STRUT
2006016-103	1650-01-158-1285	ACTUATOR, MLG RETRACT
2006100-105	1620-01-202-3255	MLG SHOCK STRUT
2006100-107	1620-01-195-1141	LANDING GEAR RETRACTABLE
2006100-111	1620-01-296-3911	SHOCK STRUT
2006100-123	1620-01-442-0946	LANDING GEAR RETRACTABLE
200610-107	1620-01-195-1141	MLG STRUT
2006106-105	1620-01-200-7131	PISTON, LANDING GEAR STRUT
2006106-109	1620-01-442-0167	PISTON LANDING GEAR STRUT
2006322-105	1620-01-071-4841	DRAG BRACE LANDING GEAR
2006500-111	1620-01-162-7542	DRAG BRACE LANDING GEAR
2006500-117	1620-01-240-4805	DRAG BRACE LANDING GEAR
2006600-147		NLG SHOCK/STRUT ASSY.
2006600-155	1620-01-162-7518	LG RETRACTABLE
2006629-105	1620-01-071-5592	APM.ASSY TORQUE
2006629-111	1620-01-124-9137	ARM. ASSY TORQUE L/G
2006907-105	1650-01-056-9655	CYLINDER ASSEMBLY ACTUATING LINE
2022032-1-1	1680-01-045-1019	PDU SERVO ACTUATOR
2022070-2-1	1650-01-143-0394	DRIVE UNIT, HYD
2022072-4-1	1680-01-168-9396	ACTUATOR BRAKE





**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
202487-001	5865-01-088-1019	OSCILLATING GROUP (2A3)
202919-306	5996-01-406-9088	INTERMEDIATE FREQUENCY AMPLIFIER
202921-303	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
208-013-002		FAN TIT INDICATOR
208-013-003		FAN TIT INDICATOR
208013-004		INDICATOR TEMPERATURE
208-013-004	6620-01-178-7651	FTIT INDICATOR
208-013-005	6620-01-276-9825	INDICATOR, TEMPERATURE
2094-6		ACCELEROMETER
2100756-3-1	6610-01-047-6627	COMPUTER AIR DATA
2101272-2-1		EPU CONTROLLER
2101272-4-2	1680-01-258-5608	POWER SUPPLY
2101382-3-1	6685-01-149-6398	TRANSMITTER PRESSURE (PSA)
21092A		CABIN PRESSURE ALTIMETER
2109-5	6685-01-112-9094	CABIN PRESS IND.
2113024-114	4920-01-108-1292	DISK DRIVE
2113245-103	6130-01-084-8523	POWER SUPPLY
2113245-123	6130-01-084-8523	POWER SUPPLY
2115060-101	5998-01-079-2200	ANALOG CHANNEL CIRCUIT CARD ASSEMBLY
2115060-102	5998-01-079-2200	ANALOG CHANNEL CIRCUIT CARD ASSEMBLY
2115080-101	5998-01-077-1445	ASSEMBLY
2115080-102	5998-01-077-1445	ASSEMBLY
2115080-303	5998-01-077-1445	ASSEMBLY
2115400-101	5998-01-078-0500	STRAY VOLTAGE CIRCUIT BOARD ASSEMBLY
2115400-103	5998-01-078-0500	STRAY VOLTAGE CIRCUIT BOARD ASSEMBLY
2115475-201	5998-01-266-7051	SMS DATA BUS CIRCUIT CARD ASSEMBLY
2115475-202	5998-01-266-7051	SMS DATA BUS CIRCUIT CARD ASSEMBLY
2115530-101	5998-01-078-1833	ASSEMBLY
2215190-001	5998-01-372-6652	MODULAR LOW POWER RF CIRCUIT CARD ASSEMBLY
2215190-002	5998-01-372-6652	MODULAR LOW POWER CIRCUIT CARD ASSEMBLY
2216150-001	5998-01-383-4960	ASSEMBLY
2231945-001	6625-01-246-1643	ELECTRONIC FREQUENCY SYNTHESIZER
2231945-003	6625-01-246-1643	ELECTRONIC FREQUENCY SYNTHESIZER
2231945-004	6625-01-246-1643	ELECTRONIC FREQUENCY SYNTHESIZER
226508-001	5865-00-477-5721	PRE-AMPLIFIER MIXER (5A3)
229-026256-05	5998-99-533-9125	CIRCUIT CARD ASSEMBLY
229-026256-11	5998-99-533-9125	CIRCUIT CARD ASSEMBLY
229-026256-12	5998-99-533-9125	CIRCUIT CARD ASSEMBLY
229-026257-03	6130-99-736-0409	POWER SUPPLY SUBASSEMBLY
229-026259-05	5998-99-771-4188	DEFLECTION PCB
229-029552-01	5820-99-783-4026	ELECTRICAL-ELECTRONIC EQUIPMENT CHASSIS
229185-4	4810-01-225-7171	VALVE, REGULATOR
2301420-1	5996-01-406-9088	INTERMEDIATE FREQUENCY AMPLIFIER
231364-001	6130-01-183-0457	LOW VOLTAGE POWER SUPPLY
231364-101	6130-01-316-3155	LOW VOLTAGE POWER SUPPLY
231364-201	6130-01-317-1497	LOW VOLTAGE POWER SUPPLY



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
231364-202	6130-01-389-8225	LOW VOLTAGE POWER SUPPLY
243057-000	5998-00-477-5938	YIG FILTER (ELECTRONIC COMPONENT)
243086-000	5895-00-477-5936	VOLTAGE CONTROLLED OSCILLATOR (VCO)
25730032-04	4810-00-730-2852	VALVE,SOLENOID
2616638-1	6130-01-272-8813	POWER SUPPLY
2616638-2	6130-01-272-8813	POWER SUPPLY
2750023-101	1660-01-052-5359	CONTROL,AIRCRAFT
2750024-101	1660-01-052-5354	CONTROL BOX ELECTRICAL/ELECTRONIC
2750514-6	1650-01-039-4984	ACCUMULATOR, HYDRAULIC
2750534M1	1650-01-064-0020	ACCUMULATOR HYD
2750534M3	1650-01-263-1604	ACCUMULATOR HYDRAULIC
2815262-1	5998-01-269-1206	DC/AC INPUT/MUX CIRCUIT CARD ASSEMBLY
2815262-2	5998-01-269-1206	DC/AC INPUT/MUX CIRCUIT CARD ASSEMBLY
2815265-1	5998-01-269-1209	COIL CURRENT CIRCUIT CARD ASSEMBLY
2815265-2	5998-01-269-1209	COIL CURRENT CIRCUIT CARD ASSEMBLY
2825131-3	5998-01-384-9455	PROGRAM MEMORY CIRCUIT CARD ASSEMBLY
28YBL100A-1	6130-00-314-0050	POWER SUPPLY
291-02-05711	5865-01-088-1019	OSCILLATING GROUP (2A3)
29270-10A-A1	1660-00-243-0393	OXYGEN DEMAND REGULATOR
29270-10A-B1	1660-00-243-0393	OXYGEN REGULATOR
29650-19A	6130-01-086-2340	POWER SUPPLY
30006-0000-03	6680-01-261-5242	TRANSMITTER LIQUID QUANTITY
31-032599-04	5985-01-154-9125	AMPLIFIER DETECTOR
31216-001		5KVA GENERATOR
3129307-1	6130-01-388-0266	POWER SUPPLY
3129307-4	6130-01-388-0266	POWER SUPPLY
318357-000	5998-01-236-3735	BACKPLANE ASSEMBLY
318427-001	5998-01-407-6121	CIRCUIT CARD ASSEMBLY
318476-901	5998-01-269-6978	VIDEO PROCESSOR NO. 1 CIRCUIT CARD ASSEMBLY
318557-000	5998-01-236-3735	BACKPLANE ASSEMBLY
319751-000	5996-01-230-8671	DELAY LINE AMPLIFIER ASSEMBLY
32-054528-02	5865-01-165-9375	RF ASSEMBLY (A5)
32-054542-01	5865-01-059-4560	IF FILTER
32-054576-01	6130-01-059-1470	POWER SUPPLY
3213722-5-1	4810-01-157-2583	VALVE, SHUTOFF
3214806-4-1	1660-01-445-9556	REGULATOR AIR PRESSURE
321502-4-1	4810-00-796-1672	VALVE, BUTTERFLY
3252001-0101	6610-00-086-3840	ALTIMETER SERVO CONTROL
3252022-0101	6610-01-035-0673	ALTIMETER,SERVO CONTROLLED,AUTOM
3260011-0101	1660-01-005-6318	OXYGEN REGULATOR
3260011-0701		REGULATOR, OXYGEN
3260060-0108	1660-01-383-6734	OXYGEN REGULATOR
3261130-0102	1660-01-473-2858	EMER OXY SYS
3300223-6001	4920-01-321-1839	TEST STAND DEMAND
3300223-6003	4920-01-521-3685	TEST STAND
330025G01	4320-01-162-6456	PUMP,HYDRAULIC



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
330454-102	6130-01-362-0927	POWER SUPPLY
330454-103	6130-01-362-0928	POWER SUPPLY
330454-104	6130-01-381-3231	POWER SUPPLY
330454-106	6130-01-408-3805	POWER SUPPLY
330625-101	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
330625-211	5955-01-435-5551	NONCRYSTAL CONTROLLED OSCILLATOR
3567762-3002	6620-00-290-6505	TRANSMITTER,PRESSURE
362-014-001	6610-01-040-4430	INDICATOR, ANGLE
362D637H01	5985-01-030-9462	DIPLEXER
363J100-1	1680-01-142-8095	ACTUATOR, ELECTRO-MECHANICAL
365000-3	2915-00-438-5854	PUMP FUEL METERING AND DISTRIBUT
371688-101	2910-00-907-7481	PUMP FUEL
37516-3	1560-01-054-2800	F1 BLADDER TANK
3833000-22	1650-01-165-7203	CYLINDER ASSEMBLY ACTUATING LINEAR
3834000-21	1650-01-106-1594	CYLINDER ASSEMBLY ACTUATING LINE
390000-1	2915-01-041-8639	DUAL FUEL PUMP
390-97-1001	5865-01-088-1019	OSCILLATING GROUP (2A3)
393084-11426	6680-00-078-3756	INDICATOR LIQUID QUANTITY
396308-1-1	4810-01-040-2372	VALVE, FLOW CONTROL
3HIL87-3	5998-01-462-7274	CIRCUIT CARD ASSEMBLY
3HIL87-8PC	6625-01-462-3659	SERIAL INTERFACE BOX
4025116-907	6610-01-308-1859	COMPUTER AIR DATA
40283D	4810-01-349-0405	ACTUATOR ELECTRO-MECHANICAL
4059194F	6620-00-290-6505	PRESSURE TRANSMITTER
4100050-2	1650-01-058-6259	MOTOR,HYDRAULIC
4-346-02	6130-01-316-3155	LOW VOLTAGE POWER SUPPLY
4-411-02	1270-99-735-6318	POWER SUPPLY
441294-3	2915-01-206-0654	CONTROLLER, FUEL PUMP
441991-11	2995-01-450-2816	CONTROL,EXHAUST NOZZLE,TURBINE E
452-512-5	*-*	VENUS HIGH VOLTAGE TRANSFORMER ASSEMBLY
452-575-2	*-*	MODULE
452-582-1	*-*	DIODE TRAY ASSEMBLY
452-700-3	6130-01-183-3927	HIGH VOLTAGE POWER SUPPLY
45731-1291		COOLER, LUBRICATING
45731-1411	2935-01-394-8316	COOLER, LUBRICATING
4-601-02	6130-01-381-3231	POWER SUPPLY
4-602-03	6130-01-408-3805	POWER SUPPLY
4-602-1	6130-01-362-0927	POWER SUPPLY
4-603-01	6130-01-362-0928	POWER SUPPLY
460700-14-01	6615-01-356-6851	COMPUTER FLIGHT CONTROL
460730-05-06	5998-01-430-2593	ROLL CIRCUIT CARD ASSEMBLY
472741-3	6680-01-074-9369	TRANSMITTER LIQUID QUANTITY
472741-3	6680-01-074-9369	TRANSMITTER
472742-1		TRANSMITTER
472854-2		TRANSMITTER
4800-000-00	1740-01-381-2919	TRAILER, GROUND HANDLING



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
5003599B	1650-010872863	MOTOR HYDRAULIC
5003599E	1650-01-087-2863	MOTOR,HYDRAULIC
5004314C	2925-01-115-0306	CONTROLLER, JET FUEL STARTER
5004451H	2835-01-235-5249	Gearbox, Accessory Drive
501-1027-01	6615-00-877-9343	GYROSCOPE RATE
501-1131-01	6610-00-200-8832	ATTITUDE INDICATOR
501-1131-02	6610-00-200-8742	ATTITUDE IND, STBY
5076-300	6620-01-321-6819	TACHOMETER
51516-001	6110-01-383-7195	CONTROL,GENERATOR (GCU)
5173100-002	6340-01-235-3351	ALARM SET, PILOT WARNING
52.0261.650.00	5865-01-059-4560	IF FILTER
532R795G01	6110-01-133-2884	RCP POWER SUPPLY ASSEMBLY
535493-1	6130-01-256-2085	DC/DC POWER SUPPLY
535493-801	6130-01-256-2085	DC/DC POWER SUPPLY
536R477G01	1270-01-132-2438	DETECTOR ASSEMBLY
55113-02	4320-01-152-8301	HYDRAULIC PUMP
55113A	4320-01-376-3868	PUMP HYDRAULIC RAM HAND DRIVEN
551R291G01	6130-01-310-4939	POWER SUPPLY
551R291G02	6130-01-310-4939	POWER SUPPLY
56870-4	4810-01-137-2476	VALVE SOLENOID
57240-11	4810-01-073-4200	VALVE
57730-5	1620-01-136-5173	ELEC COMP
578R568H02	5865-00-162-7967	DUAL MODULATOR COUPLER
578R611H01	5865-00-007-6950	COAXIAL MICROWAVE DRIVE CONTROL
578R611H04	5865-00-007-6950	COAXIAL MICROWAVE DRIVE CONTROL
581670-2-2	4810-01-099-6392	VALVE PACKAGE AND/OR VALVE, SOLENIOD
581750-10-1	2835-01-116-0006	POWER GAS TURBINE
581R152H02	5865-00-188-7082	DUAL FREQUENCY CONVERTER
581R481H01	5996-01-036-5639	SOLID STATE AMPLIFIER
581R481H04	5996-01-224-7914	AMPLIFIER ASSEMBLY
583R181H03	5865-01-082-0338	SIGNAL PROCESSOR
583R181H08	5865-01-224-2714	PROCESSOR, COUNTERMEASURES SIGNAL
583R290H01	1270-01-077-0718	MICROWAVE GUNN EFFECT FIXED OSCILLATOR
583R290H02	1270-01-077-0718	MICROWAVE GUNN EFFECT FIXED OSCILLATOR
583R292	1270-01-077-0714	VOLTAGE CONTROLLED OSCILLATOR
583R292H02	1270-01-077-0714	VOLTAGE CONTROLLED OSCILLATOR
583R496H01	1270-01-060-1083	WAVEGUIDE DUPLEXER
583R936H01	1270-01-096-7120	FREQUENCY MULTIPLIER
583R936H02	1270-01-096-7120	FREQUENCY MULTIPLIER
583R936H03	1270-01-222-3541	FREQUENCY MULTIPLIER
583R936H04	1270-01-096-7120	FREQUENCY MULTIPLIER
583R936H05	1270-01-343-8506	FREQUENCY MULTIPLIER
583R936H06	*-*	FREQUENCY MULTIPLIER
584R453H01	6130-01-082-7817	POWER SUPPLY/ ION PUMP
58500-3	4810-01-324-3564	VALVE,LINEAR,DIRECTIONAL CONTROL: F16
58500-6	4810-01-324-3564	VALVE LINEAR DIRECTIONAL CONTROL:F16C/D



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
585-AVU-8C/A		AIRSPED AND DIRECTION INDICATION
585R195H03	5996-01-224-8905	RADIO FREQUENCY AMPLIFIER
585R600	5996-01-153-8700	LOW NOISE FET AMPLIFIER
585R600H02	5996-01-153-8700	LOW NOISE FET AMPLIFIER
585R600H03	5996-01-153-8700	LOW NOISE FET AMPLIFIER
585R600H04	5996-01-153-8700	LOW NOISE FET AMPLIFIER
585R600H05	5996-01-153-8700	LOW NOISE FET AMPLIFIER
585R600H06	5996-01-153-8700	LOW NOISE FET AMPLIFIER
585R944H01	6130-01-192-6999	POWER SUPPLY
585R944H02	6130-01-361-0655	POWER SUPPLY
586R212	5841-01-203-4624	TRANSMIT MICROWAVE ASSEMBLY
586R212	5841-01-353-9263	TRANSMIT MICROWAVE ASSEMBLY
586R212H03	5841-01-203-4624	TRANSMIT MICROWAVE ASSEMBLY
586R212H05	5841-01-291-6174	TRANSMIT MICROWAVE ASSEMBLY
586R212H06	5841-01-353-9263	TRANSMIT MICROWAVE ASSEMBLY
586R212H07	5841-01-438-9423	TRANSMIT MICROWAVE ASSEMBLY
586R719H01	1270-01-173-4932	TRANSMIT MICROWAVE
586R719H02	1270-01-173-4932	TRANSMIT MICROWAVE
586R719H04	*_*	TRANSMIT MICROWAVE ASSEMBLY
588R881H01	6130-01-439-0638	MLOW POWER RF LOW VOLTAGE POWER SUPPLY
6002052-2	1630-01-071-2277	SENSOR, WHEEL SPEED
6002052-3	1630-01-217-3141	SENSOR,ANTI-LOCK BRAKE,AIRCRAFT
6002052-3	1630-01-217-3141	BRAKE,AIRC
601-4176-001	5998-01-086-8829	POWER CIRCUIT CARD ASSEMBLY
60-2805-3	6130-01-149-8915	POWER SUPPLY
60794-4	2915-01-179-3834	FILTER, FLUID
618-5710-001	5826-01-061-1870	MARKER BEACON ASSEMBLY
62-052748-01	5985-01-062-8035	RF SWITCH
622-0507-001	5826-01-012-1938	RCVR, XMTR TAC
622-2510-003		TACAN CONTROLLER
622-4038-001	5821-01-062-1019	R/T 1300 ARC186
622-4956-103	5821-01-258-7579	ARC 190 R/T 1341(V)3
622-8084-001	5985-01-228-9402	AMPLIFIER-CONVERTER
627076-2-1	1660-01-057-5182	SENSOR CONTROLLER
627076-3-1	1660-01-140-8406	CONTROL BOX ELECTRICAL/ELECTRONIC
638-9090-001	5821-01-077-4298	RECEIVER ASSY
643R510G01	1270-01-042-8489	RADAR CONTROL PANEL
643R531G01	5998-01-077-7497	COMPUTER DSP I/O BOARD ASSEMBLY
643R571G01	1270-01-077-7495	X/Y INTERPOLATER & CURSOR BOARD ASSEMBLY
643R647G01	5998-01-069-6483	SWITCH INTERFACE CIRCUIT CARD ASSEMBLY
646R430G01	5998-01-077-7483	CFAR NO. 0 BOARD ASSEMBLY
646R433G01	5998-01-077-7482	CFAR NO. 1 BOARD ASSEMBLY
646R436G01	5998-01-077-7481	CFAR NO. 2 BOARD ASSEMBLY
646R442G01	1270-01-165-7143	STC/MRF/SPM NO. 2 BOARD ASSEMBLY
646R445G01	5998-01-077-7485	AU SCRATCH CIRCUIT CARD ASSEMBLY
646R454G01	5998-01-078-3390	COMPRESSION BIT CIRCUIT CARD ASSEMBLY



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
646R460G01	1270-01-077-7478	CCC SQ BOARD ASSEMBLY
646R466G01	1270-01-077-7476	SYNC NO. 2 BOARD ASSEMBLY
646R488G01	1270-01-042-8489	RADAR CONTROL PANEL
646R561G01	5998-01-077-8165	I/O CT CIRCUIT CARD ASSEMBLY
646R666G01	1270-01-083-5926	GROUND DECK PULSER
646R851	5998-01-077-7487	AU OUTSIDE BOARD ASSEMBLY
646R851G01	5998-01-077-7487	AU OUTSIDE BOARD ASSEMBLY
646R861G01	1270-01-077-0710	RECEIVER ASSEMBLY
646R949G01	5998-01-077-7477	CARD ASSEMBLY
648R028G02	5995-01-057-0538	CABLE ASSEMBLY
648R195G01	5995-01-056-8526	CABLE ASSEMBLY, W7
67810-1	4810-01-259-0464	VALVE SOLENOID
681R061G01	1270-01-077-7494	SCAN CONVERTER I/P BOARD ASSEMBLY
681R112G01	6130-01-077-0836	POWER SUPPLY
681R135	5998-01-077-7486	AU CONTROL CIRCUIT CARD ASSEMBLY
681R135G01	5998-01-077-7486	AU CONTROL CIRCUIT CARD ASSEMBLY
681R145G01	5998-01-077-7480	CFAR NO. 3 CIRCUIT CARD ASSEMBLY
681R267G01	6130-01-080-1216	POWER SUPPLY - DIGITAL SIGNAL PROCESSOR
681R317G01	1270-01-086-0716	REFERENCE SOURCE ASSEMBLY
681R317G03	1270-01-075-9674	REFERENCE SOURCE ASSEMBLY
681R317G04	1270-01-077-0724	REFERENCE SOURCE ASSEMBLY
681R326G01	1270-01-089-7286	TRANSMITTER PEAK POWER DETECTOR
681R341G01	5998-01-079-5393	ZERO FREQUENCY DETECT BOARD ASSEMBLY
681R342G01	5998-01-079-5395	CLUMP & MISC BOARD ASSEMBLY
681R366G01	1270-01-083-0398	PRESSURE VESSEL ASSEMBLY
681R529G01	1270-01-079-5396	CT & SC ADDRESS BOARD ASSEMBLY
681R621G01	5998-01-099-3253	CONTROLLER NO. 1 BOARD ASSEMBLY
681R622G01	1270-01-102-2965	RADAR RECEIVER-GENERATOR
681R622G04	1270-01-102-2963	LOW POWER RADIO FREQUENCY ASSEMBLY
682R459G01	5998-01-103-5943	16K RAM CIRCUIT CARD ASSEMBLY
682R635G01	1270-01-095-0251	CONVERSION CONTROL BOARD ASSEMBLY
682R668G01	1270-01-097-6096	PEAK POWER DETECTOR
682R669G01	1270-01-093-2256	RADAR TRANSMITTER
682R676G01	1270-01-095-0253	A/A TARGET GENERATOR BOARD ASSEMBLY
682R717G01	5998-01-101-5290	CONTROLLER NO. 2 CIRCUIT CARD ASSEMBLY
682R727G01	1270-01-099-3206	LOW NOISE ASSEMBLY
682R741G01	1270-01-095-8033	SWITCH PANEL ASSEMBLY
682R742G01	1270-01-094-6872	RADAR CONTROL PANEL
682R752G01	1270-01-095-0252	A/A TARGET MEMORY BOARD ASSEMBLY
682R787G01	1270-01-095-0251	CONVERSION CONTROL BOARD ASSEMBLY
682R891G01	1270-01-098-3541	A/C SERIAL INTERFACE NO. 2 BOARD ASSEMBLY
682R975G01	6130-01-103-4551	POWER SUPPLY - RADAR COMPUTER
683R592G01	6130-01-090-0628	POWER SUPPLY
685R059G01	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
685R584	6130-01-191-9467	SWITCHING ASSEMBLY
685R584G01	6130-01-191-9467	SWITCHING ASSEMBLY



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
685R767	5998-01-191-9468	SWITCHING ASSEMBLY
685R767G01	5998-01-191-9468	SWITCHING ASSEMBLY
686R068G01	5865-01-107-0151	POWER SUPPLY SUBASSEMBLY
686R750G01	5998-01-192-2738	BAND 4/5 A10 BOARD ASSEMBLY
688R007G01	5998-01-115-3249	PROTECTION CB, CIRCUIT CARD ASSEMBLY
688R012G01	5998-01-107-0140	SAMPLED DATA CIRCUIT CARD ASSEMBLY
688R683G01	1270-01-132-2440	PHASE SHIFT DRIVER
691R748G01	5841-01-132-6867	NOISE REGULATOR ASSEMBLY
691R748G01	1270-01-132-6867	LOW NOISE ASSEMBLY
691R750G01	5895-01-193-7344	INTERMEDIATE FREQUENCY ASSEMBLY
70028-02	6130-01-082-7817	POWER SUPPLY/ ION PUMP
705365-7	6110-01-108-2690	INVERTER CONTROL
705365-8	6110-01-108-2690	INVERTER, CONTROL
705465-2	6220-01-070-0244	WARNING LIGHT BANK
705565-2	6130-01-051-7518	CHARGER,BATTERY
705580-1	6130-01-051-3918	CONVERTER 500VA
705906-804	5821-00-601-5131	RECIEVER, TRANSMITTER
706057-801	5821-00-509-2435	MOUNTING BASE
708500-2	2915-01-448-8506	MAIN FUEL GEAR PUMP
709290-1	6130-01-165-2055	POWER SUPPLY
709290-2	6130-01-209-9062	CONVERTER REGULATOR
7100B	1270-01-077-0714	VOLTAGE CONTROLLED OSCILLATOR
7125-9415	6615-01-178-0583	GYROSCOPE RATE
718372B	4810-01-058-3551	VALVE, REGULATING
727429B	1650-01-153-1225	DRIVE SPEED CONSTANT
727429E	1650-01-222-3790	DRIVE CONSTANT SPEED HYDRAULIC
7276-1	5996-01-464-4836	LOW NOISE FET AMPLIFIER
7506-00097	6130-99-735-6318	POWER SUPPLY
7506-00097	1270-99-735-6318	POWER SUPPLY
7506-00098	6130-99-741-9556WF	PSU LV
7506-00104	6130-99-776-6884WF	PSU LV
7506-00125	6130-99-371-0166	HV/LV POWER SUPPLY UNIT
750R440G01	1270-01-165-7143	STC/MRF/SPM NO. 2 BOARD ASSEMBLY
750R450G04	5841-01-203-4624	TRANSMIT MICROWAVE ASSEMBLY
750R820	1270-01-169-6289	RECEIVER-GENERATOR, RADAR
750R820G01	1270-01-169-6289	RECEIVER-GENERATOR, RADAR
750R821G01	1270-01-168-5002	STALO FREQUENCY SYNTHESIZER
750R824G01	1270-01-168-5004	FREQUENCY OSCILLATOR
7-511C10035-1	6615-00-137-6038	GYROSCOPE RATE
754R778G01	5998-01-193-8150	CIRCUIT CARD ASSEMBLY
75500000-1		INDICATOR,HORIZ
7567178-011	5999-01-222-3130	BCM CCA
756R222G01	5998-01-195-8634	CONTROLLER ANALOG CIRCUIT CARD ASSEMBLY
756R358G01	1270-01-213-3377	INTERFACE CONTROLLER
756R441G01	5998-01-194-4373	ASSEMBLY
757R501	6130-01-310-0809	LOW VOLTAGE POWER SUPPLY



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
757R501G02	6130-01-310-0809	LOW VOLTAGE POWER SUPPLY
758R117G01	5998-01-242-8035	DIGIBUS CIRCUIT CARD ASSEMBLY
758R139G01	1270-01-132-2440	PHASE SHIFT DRIVER
758R570G01	1270-01-208-8409	OSCILLATOR REFERENCE
758R791G01	5998-01-191-9468	SWITCHING ASSEMBLY
758R804G01	6130-01-243-3059	POWER SUPPLY
758R805G01	6130-01-243-3059	POWER SUPPLY
758R845G01	5998-01-191-9468	SWITCHING ASSEMBLY
758R846G01	6130-01-191-9467	SWITCHING ASSEMBLY
758R862G01	1270-01-223-5840	INTERMEDIATE FREQUENCY ASSEMBLY
758R875G01	1270-01-231-9800	RADAR TARGET DATA PROCESSOR
758R888G01	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
759R379G01	6130-01-211-8075	POWER SUPPLY CONTROL
759R379G02	6130-01-211-8075	POWER SUPPLY CONTROL
7609-37M5-2	6685-00-526-7864	PRESSURE TRANSMITTER
762R036G01	5998-01-419-0156	PHASE COMPENSATION BOARD ASSEMBLY
762R117G01	5998-01-242-8035	DIGIBUS CIRCUIT CARD ASSEMBLY
762R130	5998-01-435-8098	PHASE COMPENSATION CIRCUIT CARD ASSEMBLY
762R130G01	5998-01-435-8098	PHASE COMPENSATION CIRCUIT CARD ASSEMBLY
762R522G01	5998-01-429-5469	LIGHT PIPE RECEIVER CIRCUIT CARD ASSEMBLY
762R592G01	5998-01-356-4897	TRANSMITTER DIGIBUS CIRCUIT CARD ASSEMBLY
762R615G01	5998-01-307-5241	CONTROLLER CPU CIRCUIT CARD ASSEMBLY
762R829G01	5998-01-303-5871	RF MONITOR CIRCUIT CARD ASSEMBLY
762R978	5998-01-306-9224	ASSEMBLY
762R978G01	5998-01-306-9224	ASSEMBLY
764828-4	1660-01-107-2459	Turbine Aircraft Cooling
764967-5	1660-01-046-0943	HEAT EXCHANGER
764967-7	1660-01-331-0068	HEAT EXCHANGER
765592-12	4810-01-155-4943	VALVE, REGULATING, FLUID PRESSURE
765592-13	4810-01-154-3200	VALVE REGULATING FLUID PRESSURE
765R005G01	6130-01-257-2835	POWER SUPPLY
765R142	5998-01-310-8718	DUAL MODE TRANSMITTER
765R143G01	5998-01-310-8718	DUAL MODE TRANSMITTER
765R398G01	1270-01-274-0548	PRESSURE VESSEL ASSEMBLY
765R487G01	1270-01-274-0548	PRESSURE VESSEL ASSEMBLY
765R581G01	5998-01-280-8685	CONTROLLER BOARD NO. 1 BOARD ASSEMBLY
765R610G01	1270-01-413-5648	PROCESSOR SIGNAL
766R023G01	5998-01-246-1704	ANTENNA BOARD ASSEMBLY
767600-1	4810-01-282-7884	VALVE, REGULATOR
772R031	5998-01-319-5030	DIGITAL MODULE, PBMIF/PRF
772R031G01	5998-01-319-5030	DIGITAL MODULE, PBMIF/PRF
772R862G01	5998-01-326-0361	AUXILIARY CCA
772R876G01	5998-01-327-2983	SYNCHRONIZER CIRCUIT CARD ASSEMBLY
775178G01	1270-01-169-6289	RECEIVER-GENERATOR, RADAR
775R178G01	1270-01-418-1960	GENERATOR, RADIO FREQUENCY
77600000-3	6610-01-044-1860	INDICATOR, ATTITUDE





**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
77600000-4	6610-010929846	INDICATOR ATTITUDE
77D0069-1	6130-01-058-5927	POWER SUPPLY
78010-11175	6680-01-048-2998	INDICATOR LIQUID QU *TCI*
780110-11157	6680-01-048-2998	INDICATOR LIQUID QUANTITY
780R823	5985-01-410-9914	ANTENNA
780R823G01	5985-01-410-9914	ANTENNA
781R129G01	5841-01-398-7211	RADAR TRANSMITTER
781R130	1270-01-416-0085	GENERATOR RECEIVER
781R130	1270-01-416-0086	GENERATOR RECEIVER
781R130	1270-01-416-0083	GENERATOR RECEIVER
781R130	1270-01-410-9915	GENERATOR RECEIVER
781R130G01	1270-01-410-9915	GENERATOR RECEIVER
781R130G02	1270-01-416-0083	GENERATOR RECEIVER
781R130G03	1270-01-416-0086	GENERATOR RECEIVER
781R130G04	1270-01-416-0085	GENERATOR RECEIVER
781R749G01	5998-01-327-2983	SYNCHRONIZER CIRCUIT CARD ASSEMBLY
781R917G01	5998-01-407-4267	CIRCUIT CARD ASSEMBLY
781R925G01	5998-01-406-7787	CIRCUIT CARD ASSEMBLY
781R997G01	5998-01-327-2983	SYNCHRONIZERCIRCUIT CARD ASSEMBLY
782R650G01	1280-01-126-0079	RADAR SET SUBASSEMBLY
783R056G01	1270-01-407-6550	PRESSURE VESSEL ASSEMBLY
783R086G01	1270-01-132-2440	PHASE SHIFT DRIVER
783R209G01	5841-01-416-5187	RECEIVER ASSEMBLY
785R017G01	5998-01-332-9651	NON VOLATILE MEMORY CIRCUIT CARD ASSEMBLY
785R104G01	5998-01-327-2983	SYNCHRONIZER CIRCUIT CARD ASSEMBLY
785R114G01	5998-01-332-9651	NON VOLATILE MEMORY CIRCUIT CARD ASSEMBLY
785R116G01	5998-01-327-2983	SYNCHRONIZER CIRCUIT CARD ASSEMBLY
785R126G01	5998-01-406-7783	SYNCHRONIZER CIRCUIT CARD ASSEMBLY
785R128	5998-01-406-6815	AUXILIARY CIRCUIT CARD ASSEMBLY
785R128G01	5998-01-406-6815	AUXILIARY CIRCUIT CARD ASSEMBLY
785R130	5998-01-406-2944	MULTIPLEXER CIRCUIT CARD ASSEMBLY
785R130G01	5998-01-406-2944	MULTIPLEXER CIRCUIT CARD ASSEMBLY
785R161	5998-01-332-9651	NON VOLATILE MEMORY CIRCUIT CARD ASSEMBLY
785R161G01	5998-01-332-9651	NON VOLATILE CIRCUIT CARD ASSEMBLY
785R262G01	5998-01-303-5871	RF MONITOR CIRCUIT CARD ASSEMBLY
785R352G01	5998-01-435-8098	PHASE COMPENSATION CIRCUIT CARD ASSEMBLY
785R353G01	5998-01-419-0156	PHASE COMPENSATION BOARD ASSEMBLY
785R450G01	5998-01-406-6815	AUXILIARY CIRCUIT CARD ASSEMBLY
785R453	5998-01-406-2944	MULTIPLEXER CIRCUIT CARD ASSEMBLY
785R453G01	5998-01-406-2944	MULTIPLEXER CIRCUIT CARD ASSEMBLY
785R537G01	5998-01-303-5871	RF MONITOR CIRCUIT CARD ASSEMBLY
785R537G03	5998-01-303-5871	RF MONITOR CIRCUIT CARD ASSEMBLY
785R767G01	5998-01-423-6943	SYNCHRONIZER CIRCUIT CARD ASSEMBLY
785R789G01	5998-01-426-3528	NON VOLATILE MEMORY-DMA CONTROLLER
785R980G01	1270-01-429-6324	RADAR TARGET PROCESSOR
78600000-01	6620-01-051-2045	NOZZLE POSITION IND



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
78700000-01	6610-01-114-6817	IND, ANGLE
78R114G01	5998-01-332-9651	NON VOLATILE MEMORY CIRCUIT CARD ASSEMBLY
791130H05D09	6620-01-449-3101	DIAGNOSTIC UNIT,AIRCRAFT ENGINE (EDU)
791130H05D10	6620-01-449-3101	DIAGNOSTIC UNIT AIR
792R028G01	*_*	CIRCUIT CARD ASSEMBLY
792R086G01	5998-01-327-2983	SYNCHRONIZER CIRCUIT CARD ASSEMBLY
792R087G01	5998-01-332-9651	NON VOLATILE MEMORY CIRCUIT CARD ASSEMBLY
792R140G01	5998-01-406-7782	SAMPLED DATA CIRCUIT CARD ASSEMBLY
792R689G01	5998-01-465-7637	SAMPLE DATA CIRCUIT CARD ASSEMBLY
792R886G01	5998-01-406-7782	SAMPLED DATA CIRCUIT CARD ASSEMBLY
8001023-922	1260-01-220-4070	TV INTERFACE CIRCUIT CARD ASSEMBLY
8001294-921	5998-01-193-8900	HORIZONTAL DEFLECTION CIRCUIT CARD ASSEMBLY
8002287-930	6130-01-234-8700	POWER SUPPLY
8010000653-2	5841-01-221-8638	RECEIVER TRANSMITTER UNIT
810R206G01	5998-01-406-6815	AUXILIARY CIRCUIT CARD ASSEMBLY
810R794G01	5998-01-529-1748	SYNCHRONIZER
815132-801	5895-01-257-2496	ELECTRICAL FREQUENCY SYNTHESIZER
817R226G01	5841-01-486-1338	SUBASSEMBLY RADAR RECEIVER
81D0240-1	6130-01-192-6999	POWER SUPPLY
82-052759-01	5996-01-060-6746	LOG VIDEO AMPLIFIER
82-052760-01	5865-01-059-4571	IF DISCRIMINATOR
82-052795-01	6130-01-058-5927	POWER SUPPLY
822-0204-002	5826-01-387-0975	RECEIVER RADIO NAVIGATION
822-0204-002	5826-01-387-0975	RADIO NAVIGATION RECEIVER
822-0204-022	5826-01-387-0975	RECEIVER RADIO
822500-6	1680-01-110-4407	HALON RESERVOIR
825R860	5841-01-525-1534	RADAR TRANSMITTER
825R860G01	5841-01-525-1534	RADAR TRANSMITTER
83D0439-1	6130-01-192-6999	POWER SUPPLY
8517713-922	5998-01-436-0165	CIRCUIT CARD ASSEMBLY
851836-2	6130-01-082-7817	POWER SUPPLY/ ION PUMP
8526000-920	1280-01-481-5723	GENERATOR DISPLAY COLOR
85900000-02	5895-01-230-1284	CONVERTER, SIGNAL DATA
86400-3162	6645-01-122-2318	Clock
871BW	6340-00-173-9074	ICE DETECTOR
871BW1	6340-00-173-9074	ICE DETECTOR
8-8421-030-2	1650-01-043-7540	ACUM ASSEMBLY
88700000-05		VERTICAL VELOCITY INDICATOR
89D0834-1	6130-01-361-0655	POWER SUPPLY
8DJ113LWN1	6620-00-802-7164	RATE OF FLOW INDICATOR
8DJ179DBD3		FAN TURB. TEMP. IND.
8DJ179DBE1	6620-01-256-4307	INDICATOR TEMPERATURE
8DJ215WBA1	6620-01-129-7247	INDICATOR ELECTRICAL TACHOMETER
8DJ215WBR1	6620-01-270-7772	INDICATOR ELECTRICAL
8TJ62GBZ3	6620-01-020-1722	TRANSMITTER
900101-807		RECEIVER-TRANSMITTER,RADIO



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
912408-805	5821-01-059-1344	SWITCHING GROUP
914691-823	5998-01-481-3710	MODULE
918476-000	5998-01-269-6978	CIRCUIT CARD ASSEMBLY
9246250-10	1630-01-417-1493	CONTROL UNIT, ANTISK
947F310-1	6110-01-038-5065	CONTROL GENERATOR
948F463-5	6115-01-246-5622	ALTERNATOR, GENERATOR
965852-10	6625-01-462-3659	SERIAL INTERFACE BOX
975138-9	1650-01-084-1570	SERVOVALVE, HYDRAULIC
977J024-4	6115-01-141-5801	GENERATOR
977J330-2	6115-01-236-8434	GEN, ALTERNATING
977J330-3		GENERATOR 60KVA
979198-11	1660-01-052-5356	ALVE CONTROL CABIN
979290-4-1	4810-01-073-3810	VALVE, REGULATING, FL
A2850-1	6615-00-857-0828	RATE GYROSCOPE
A2850-5	6615-00-869-0825	GYROSCOPE RATE
A30645	5865-01-088-1019	OSCILLATING GROUP (2A3)
A4132210003	6610-00-179-5086	ALTIMETER
A4132210015	6610-01-016-1583	ALTIMETER SERVO CONTROLLED AUT
A536A379-02	6605-01-075-4770	SERVO & ELEC
A81-6	5895-00-623-2912	AMPLIFIER
AAU18A	6610-00-078-5694	INDICATOR VERTICAL VELOCITY
AAU19A	6610-00-179-5086	ALTIMETER SERVO
AAU19AA	6610-00-086-3840	ALTIMETER SERVO
AAU-34/A	6610-01-035-0673	ALTIMETER, SERVO
AAU-3A/A	6685-00-226-5700	CABIN PRESSURE ALTIMETER
AAU3AA	6685-00-725-9117	CABIN PRESS IND.
ABU-4A/A	6610-01-049-8747	ACCELEROMETER
ADTS405-1-8398-MO	4920-01-432-3906	TEST SET FLIGHT
AF AVIONICS S/P IL	5985-01-294-9788	ANTENNA CONTROL SUBASSEMBLY
AM-6639/ALR	5985-01-154-9125	AMPLIFIER DETECTOR
AM-7314/URN	5985-01-228-9402	AMPLIFIER-CONVERTER
ARU-42/A-1	6610-00-200-8832	ATTITUDE INDICATOR
ARU42A1	6610-00-200-8773	ATTITUDE INDICATOR
ARU-50/A		FLIGHT ATTITUDE INDICATOR
AS-3820A/AR	5985-01-294-9788	ANTENNA CONTROL SUBASSEMBLY
ASC1561583	5985-01-228-9402	AMPLIFIER-CONVERTER
AV18A1117	4820-01-058-3205	VALVE BUTTERFLY
AV19E1003-1	4810-01-123-7254	VALVE PRESSURE VENT
AVU-8B/A		AIRSPEED INDICATOR
AVU-8C/A		AIRSPEED INDICATOR
AX1006-00	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
B2888-01	6615-00-857-0828	RATE GYRO TRANSMITTER
B2888-02	6615-00-869-0825	RATE GYROSCOPE
B405501	1660-01-407-8855	REGULATOR, OXYGEN
C12413-1	1270-01-083-5926	GROUND DECK PULSER
C2893410007		MB-1A ALTIMETER



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
C3435210005		AIRSPPEED INDICATOR; AVU-8C/A
C3435210006	6610-01-046-4844	INDICATOR AIR SPEED MACH NO
C7901-1	1650-01-056-7136	ACCUMULATOR
C7902-2	1650-01-043-7540	ACCUMULATOR
C8884-2	6685-01-052-5353	DIFFERENTIAL SENSOR
CB2125-5	6605-00-815-1903	STANDBY COMPASS
CB-2125-5	6605-00-815-1903	COMPASS
CB2125T5	6605-00-815-1903	COMPASS MAGNETIC
CP-1-AAU-3/A-12	6685-00-226-5700	ALTIMETER
CP1AAU3A12	6685-00-226-5700	CABIN PRESS IND.
D2817-A103	6130-01-084-8523	POWER SUPPLY
D2817-A123	6130-01-084-8523	POWER SUPPLY
DM001-302	5895-01-426-5318	MODEM COMMUNICATIONS:F/F-16 ACFT
DSL-647	6680-00-139-0002	INDICATOR LIQUID QUANTITY
DSL647-2	6680-01-310-3235	INDICATOR LIQUID QUANTITY
EFU-22A/A-7	6620-01-060-6418	INDICATOR RATE OF FLOW
EHU-49/A	6620-01-180-5183	INDICATOR TEMPERATURE
ERU-6/A	6620-00-684-1952	INDICATOR, ELEC
FS-2370-1	1270-01-077-0718	MICROWAVE GUNN EFFECT FIXED OSCILLATOR
FS-2470-1	1270-01-077-0714	VOLTAGE CONTROLLED OSCILLATOR
FS-9082	1270-01-222-3541	FREQUENCY MULTIPLIER
FS9179A	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
FS-9506B-4	5955-01-435-5551	NONCRYSTAL CONTROLLED OSCILLATOR
G254084-1	6130-01-183-3927	HIGH VOLTAGE POWER SUPPLY
G254084-1V1	6130-01-183-3927	HIGH VOLTAGE POWER SUPPLY
G254084-1V2	6130-01-356-3740	HIGH VOLTAGE POWER SUPPLY
G254084-1V3	6130-01-411-4286	HIGH VOLTAGE POWER SUPPLY
G385200-1	6130-01-411-4286	HIGH VOLTAGE POWER SUPPLY
GD4937		IFF CONTROLLER C-6280A
GG1500BA03	6615-01-078-4943	RATE SENSOR UNIT
GG2479AA01	6615-00-169-1564	GYROSCOPE RATE
GG2479AB01	6615-00-137-6038	XMTR, RATE GYRO
GMU37A	6680-00-753-8932	INDICATOR LIQUID QUANTITY
GMU-37A	6680-00-976-3923	LIQUID OXYGEN IND
HP1141100-3	1650-00-404-0445	VALVE LINEAR DIRECTIONAL CONTROL
J115103-517	1680-01-055-3451	ACTUATOR ELECTRO-MECHANICAL LINE
J115140-505	1680-01-004-5337	CONTROL ASSEMBLY PITCH STAB
M00X221	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
M00X224	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
M00X224-A	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
M02X222B	1270-01-096-7120	FREQUENCY MULTIPLIER
M124	6130-01-439-0638	MLOW POWER RF LOW VOLTAGE POWER SUPPLY
M3500-5		MD-1B TURN & SLIP IND
MIL-C-19328	1660-010414494	CONVERTER LIQUID OXYGEN
MPS 259	5865-00-477-5721	PRE AMPLIFIER MIXER (5A3)
MPS-112	6130-01-317-1497	LOW VOLTAGE POWER SUPPLY



**WINGS AEROSPACE, LLC**  
**F-16 REPAIR/OVERHAUL CAPABILITIES LIST**

<b>PARTNO</b>	<b>NSN</b>	<b>ITEM_NAME</b>
MPS-112-1	6130-01-389-8225	LOW VOLTAGE POWER SUPPLY
MPS162A	5865-00-007-6950	COAXIAL MICROWAVE DRIVE CONTROL
MPS259-2	5865-00-477-5721	PRE AMPLIFIER MIXER (5A3)
MPS-334	6130-01-256-2085	DC/DC POWER SUPPLY
MS23009-1	6610-00-910-4284	ACCELEROMETER
MS23009-2		ACCELEROMETER
MS28005-8	6685-00-526-7864	TRANSMITTER,PRESSURE 0-4000 PSI
MS28500-8T		TRANSMITTER PRESSURE
MS3370-1	6130-00-314-0050	CONVERTER
PS101167	6130-01-183-3927	HIGH VOLTAGE POWER SUPPLY
PWA57495	4920-01-361-0044	HEATER, AIRCRAFT ENGINE
R-2514A/U	5826-01-387-0975	RADIO NAVIGATION RECEIVER
RC-60-AAU/18/A	6610-00-781-5787	INDICATOR VERTICAL VELOCITY
RC-60-AAU-18/A	6610-00-781-5787	IND, VERTICAL VELOCITY
RCS-60-AAU-18/A		INDICATOR, VERTICAL VELOCITY AAU-18A
S85-AVI-8C/A		AIRSPEED & DIRECTION INDICATOR
S85-AVU-8C/A		INDICATOR,AIRSPEED AND DIRECTION
S-85-AVU-8C/A	6610-01-263-2409	IND MACHMETER
SA-2061A/ARC-164	5821-01-059-1344	SWITCHING GROUP
SCD7288	5895-01-421-6495	ELECTRONIC NOISE LIMITER
SLZ7317-1		TRANSMITTER AOA
SLZ9695-2	6610-01-052-5584	TRANSMITTER, ANGLE OF ATTACK
SLZ9695-3	6610-01-222-6439	TRANSMITTER, ANGLE
ST207A		SYNCHRO STYLE HYD PRESS TX
TRU-2A/A	6615-00-857-0828	GYROSCOPE RATE
TRU63/A3	6620-01-167-0874	TRANSMITTER RATE OF FLOW
VLX1720	5895-01-421-6495	ELECTRONIC NOISE LIMITER
WJ2854-15A	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
WJ2854-31A	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR