

// Retail Price List & Product Info Guide

ALTA
WINDOW FASHIONS

**PORTER
PRESTON**
Quality Wholesale Window Coverings
Contract • Hospitality • Residential



DUAL SHADES

Effective February 3, 2020

design simplified™

TABLE OF CONTENTS

Product Overview

- Features & Benefits 3
- Collection Information 4-5
- Color Chart 6

Pricing Groups

- Pricing Group 1-5 7-8
- Motorization Surcharges and Options 9

Product Specifications

- Product Specifications 10
- Finished Dimensions. 11
- Simplicity Rechargeable Motorization 12
- PowerWand Motorization 13
- RemoteLift™ Motorization. 14-15
- Quick Motorization Programming Guide 16-17
- Product Components. 18-20

FEATURES & BENEFITS



- A soft shade that combines the light control of a blind with the soft beauty of a fabric shade.
- Uniquely designed fabric has alternating bands of sheer or mesh fabric with translucent or room darkening solid fabric within the same shade.
- The bands of fabric can be aligned or offset providing total light and privacy control as well as UV protection.
- Large selection of decorative styles in a wide ranging color palette to blend with any décor.
- A matching fabric insert in the headrail is standard and provides a finished look.
- Innovative bottomrail allows the fabric to slide through for precise positioning.
- Continuous cord loop is standard.
- Choose from three motorization options:
 - Simplicity Rechargeable – great option for those hard to reach places. Rechargeable battery eliminates the external battery wand.
 - PowerWand – low cost, rechargeable motorized system raises and lowers at the touch of a button on the wand.
 - RemoteLift – trouble free operation at the touch of a button.
- Smoove 1 RTS surface mounted wall switch option now available.
- myLink RTS Interface now available.
- Limited Lifetime Warranty ensures your customers' satisfaction.

COLLECTION INFORMATION

	Continuous Cord Loop
Minimum Width (NET)	15"
Minimum Height	24"

	Simplicity Rechargeable
Minimum Width (NET)	19"
Minimum Height	20"

	RemoteLift
Minimum Width (NET)	18"
Minimum Height	24"

	PowerWand
Minimum Width (NET)	21"
Minimum Height	20"

Maximum widths and heights for continuous cord loop and battery operated motorization noted below.

Pattern Name	Family Code	Band Height	Fabric Composition	Opacity	Maximum Width	Maximum Height	Price Group
Advance	DS1	3"	100% Woven Polyester	Translucent	94"	120"	4
Anastasia	DS2	3"	100% Polyester	Translucent	100"	120"	4
Beaumont	DS3	3"	100% Polyester	Translucent	96"	120"	1
Cinema	DS4	2.75"	85% Polyester / 15% Linen	Translucent	92"	120"	3
Definition	DS6	3"	100% Polyester	Room Darkening	90"	120"	5
Diversion	DS21	4.625"	100% Polyester	Room Darkening	102"	120"	5
Epicure	DS7	3"	100% Polyester	Translucent	100"	120"	3
Extravagance	DS8	5.5"	100% Polyester	Translucent	100"	120"	4
Glorious	DS18	4.75"	100% Polyester	Translucent	90"	120"	2
Humber	DS19	3"	100% Polyester	Translucent	102"	120"	2
Impulse	DS20	3"	100% Polyester	Translucent	90"	96"	2
Luxury	DS10	3"	100% Polyester	Translucent	100"	120"	4
Nomad	DS12	3"	100% Polyester	Translucent	102"	100"	3
Obscure	DS13	4"	100% Polyester	Room Darkening	96"	100"	5
Palladian	DS14	3"	100% Polyester	Translucent	100"	120"	3
Reveal	DS15	2.75"	100% Polyester	Translucent	102"	120"	2
Strande	DS16	2.75"	100% Polyester	Translucent	100"	120"	2
Sublime	DS17	3"	100% Polyester	Translucent	90"	100"	2

SIDE-BY-SIDE VANE ALIGNMENT

When Dual Shades are installed side by side, vane alignment can be guaranteed within 3/8" only if:

- Shades are ordered at the same time and are identical style, color and height.
- Shades that need to be aligned are specified on the order form (a note must be included in Special Instructions).

ORDERING NOTE

- Finished blind height will always be in the full privacy position – with bands offset
- When you align bands to the view through position, the bottom rail will raise slightly off the window sill – the gap between the sill and bottomrail is approximately 1/2 the band width.

COLLECTION INFORMATION – 2 ON 1 HEADRAIL

Minimum Width Per Panel:

- Continuous Cord Loop – 15" NET
- 2 on 1 is not available with any Motorization System
- Center Gap – 1/2"

Minimum Height:

- All Styles – 24"

Minimum widths and heights for continuous cord loop noted below.

Pattern Name	Family Code	Minimum Width per panel	Maximum Overall Width	Maximum Height
Advance	DS1	15" Net	94"	90"
Anastasia	DS2	15" Net	106"	90"
Beaumont	DS3	15" Net	96"	90"
Cinema	DS4	15" Net	92"	90"
Definition	DS6	15" Net	106"	90"
Diversion	DS21	15" Net	106"	90"
Epicure	DS7	15" Net	106"	90"
Extravagance	DS8	15" Net	108"	90"
Glorious	DS18	15" Net	106"	90"
Humber	DS19	15" Net	106"	90"
Impulse	DS20	15" Net	106"	90"
Luxury	DS10	15" Net	108"	90"
Nomad	DS12	15" Net	106"	90"
Obscure	DS13	15" Net	96"	90"
Palladian	DS14	15" Net	106"	90"
Reveal	DS15	15" Net	108"	90"
Strande	DS16	15" Net	106"	90"
Sublime	DS17	15" Net	108"	90"

2-on-1 is not available with RemoteLift, Simplicity Rechargeable, or PowerWand motorization

SIDE-BY-SIDE VANE ALIGNMENT

When Dual Shades are installed side by side, vane alignment can be guaranteed within 3/8" only if:

- Shades are ordered at the same time and are identical style, color and height.
- Shades that need to be aligned are specified on the order form (a note must be included in Special Instructions).

ORDERING NOTE

- Finished blind height will always be in the full privacy position – with bands offset
- When you align bands to the view through position, the bottom rail will raise slightly off the window sill – the gap between the sill and bottomrail is approximately 1/2 the band width.

COLOR CHART

Material Name	Color Name	Color #	Cassette Color
Advance	Anthracite	DS1-3310	Black
Advance	Cognac	DS1-3308	Dark Brown
Advance	Haze	DS1-3305	Black
Advance	Mist	DS1-3301	Silver
Anastasia	Cream	DS2-2302	Beige
Anastasia	Honey	DS2-2303	Beige
Anastasia	Ice	DS2-2301	White
Beaumont	Black	DS3-2413	Black
Beaumont	Bone	DS3-2402	Beige
Beaumont	Café	DS3-2420	Dark Brown
Beaumont	Eggplant	DS3-2429	Black
Beaumont	Linen	DS3-2412	Beige
Beaumont	Mushroom	DS3-2419	Dark Brown
Beaumont	Pewter	DS3-2407	Silver
Beaumont	Raffia	DS3-2423	Beige
Beaumont	Silver	DS3-2416	Silver
Beaumont	Steel	DS3-2414	Black
Beaumont	White	DS3-2401	White
Cinema	Bamboo	DS4-5104	Beige
Cinema	Ecru	DS4-5103	Beige
Cinema	Granite	DS4-5125	Silver
Cinema	Linen	DS4-5122	Beige
Cinema	Mesa	DS4-5124	Dark Brown
Definition	Arctic	DS6-2550	Silver
Definition	Charcoal	DS6-2505	Black
Definition	Dusk	DS6-2503	Silver
Definition	Fawn	DS6-2501	Beige
Definition	Gunmetal	DS6-2504	Silver
Definition	Sable	DS6-2502	Dark Brown
Diversion	Arctic	DS21-6520	Silver
Diversion	Ivory	DS21-6521	Silver
Diversion	Fawn	DS21-6522	Beige
Diversion	Sable	DS21-6523	Dark Brown
Diversion	Dusk	DS21-6524	Silver
Diversion	Gunmetal	DS21-6525	Silver
Diversion	Charcoal	DS21-6526	Black
Epicure	Coffee	DS7-9708	Dark Brown
Epicure	Opal	DS7-9702	White
Epicure	Quartz	DS7-9701	White
Epicure	Sambuca	DS7-9713	Black
Epicure	Storm	DS7-9710	Silver
Epicure	Taupe	DS7-9704	Dark Brown

Material Name	Color Name	Color #	Cassette Color
Extravagance	Caraway	DS8-2605	Beige
Extravagance	Dove	DS8-2603	Silver
Extravagance	Horizon	DS8-2606	White
Extravagance	Opal	DS8-2602	Beige
Extravagance	Quartz	DS8-2601	White
Glorious	Snow	DS18-6210	White
Glorious	Canvas	DS18-6211	Beige
Glorious	Malt	DS18-6212	Dark Brown
Glorious	Greystone	DS18-6213	Silver
Glorious	Sable	DS18-6214	Dark Brown
Humber	Glacier	DS19-6300	Silver
Humber	Barley	DS19-6301	Beige
Humber	Pewter	DS19-6302	Black
Humber	Midnight	DS19-6304	Black
Impulse	Aztec	DS20-6411	Dark Brown
Impulse	Onyx	DS20-6413	Black
Luxury	Caraway	DS10-2805	Beige
Luxury	Dove	DS10-2803	Silver
Luxury	Honey	DS10-2804	Beige
Luxury	Horizon	DS10-2806	White
Luxury	Opal	DS10-2802	Beige
Luxury	Quartz	DS10-2801	White
Nomad	Coffee	DS12-5104	Dark Brown
Nomad	Flannel	DS12-5101	Silver
Nomad	Midnight	DS12-5103	Black
Nomad	Stucco	DS12-5102	White
Obscure	Acorn	DS13-2902	Dark Brown
Obscure	Barley	DS13-2907	Beige
Obscure	Bleach	DS13-2901	White
Obscure	Hickory	DS13-2905	Dark Brown
Obscure	Truffle	DS13-2909	Dark Brown
Palladian	Cognac	DS14-0908	Dark Brown
Palladian	Fawn	DS14-0904	Dark Brown
Palladian	Glacier	DS14-0901	White
Palladian	Ivory	DS14-0902	White
Palladian	Shadow	DS14-0910	Silver
Reveal	Beeswax	DS15-8601	Dark Brown
Reveal	Espresso	DS15-8608	Dark Brown
Reveal	Natural	DS15-8602	Beige
Reveal	Sand	DS15-8604	Beige
Reveal	Teak	DS15-8607	Dark Brown
Strande	Canyon	DS16-3102	Beige
Strande	Coconut	DS16-3101	White
Strande	Espresso	DS16-3104	Dark Brown
Strande	Java	DS16-3103	Dark Brown
Sublime	Ice	DS17-6100	White
Sublime	Opal	DS17-6101	Beige
Sublime	Silver	DS17-6102	Silver
Sublime	Charcoal	DS17-6103	Black
Sublime	Coffee	DS17-6104	Dark Brown
Sublime	Raven	DS17-6105	Black

GROUP 1

• Beaumont (96")

WIDTH TO:	24"	30"	36"	42"	48"	54"	60"	66"	72"	76"	84"	90"	96"
HEIGHT TO:													
40"	\$257	285	319	345	374	402	435	462	497	533	557	584	641
50"	267	297	331	360	391	422	458	486	524	562	586	618	678
60"	275	309	345	377	409	442	478	511	552	592	620	652	714
70"	283	319	357	393	427	461	502	536	578	622	651	686	751
80"	293	331	370	408	445	483	525	561	606	651	684	720	787
90"	301	342	384	423	462	502	547	586	633	679	716	754	823
100"	310	352	398	439	482	524	570	611	660	711	745	787	859
110"	319	365	411	456	500	543	594	636	687	740	779	823	895
120"	327	375	425	472	517	564	616	661	714	769	810	856	932

GROUP 2

• Glorious (90") • Humber (102") • Impulse (90") • Reveal (102") • Strande (100") • Sublime (90")

WIDTH TO:	24"	30"	36"	42"	48"	54"	60"	66"	72"	76"	84"	90"	96"	102"
HEIGHT TO:														
40"	\$303	342	381	418	453	490	532	567	612	656	688	724	791	815
50"	318	359	402	442	482	521	567	606	654	703	737	777	849	876
60"	332	376	424	467	511	554	603	645	697	749	787	829	905	935
70"	345	394	444	491	538	585	638	686	739	796	837	883	963	995
80"	360	411	466	517	567	618	674	725	782	843	887	938	1022	1054
90"	373	429	486	541	595	651	710	762	825	888	938	991	1078	1114
100"	388	447	508	566	623	681	746	804	868	935	989	1046	1137	1174
110"	401	464	529	590	653	713	781	841	911	980	1038	1099	1193	1234
120"	415	482	550	614	680	745	815	880	953	1028	1088	1151	1250	1293

GROUP 3

• Cinema (92") • Epicure (100") • Nomad (102") • Palladian (100")

WIDTH TO:	24"	30"	36"	42"	48"	54"	60"	66"	72"	76"	84"	90"	96"	102"
HEIGHT TO:														
40"	\$315	356	398	436	477	515	561	600	645	694	729	766	838	863
50"	332	376	423	466	509	554	603	644	695	749	787	829	905	934
60"	348	396	448	494	543	590	643	690	746	804	846	893	972	1003
70"	363	416	472	524	577	627	686	736	796	857	904	955	1039	1073
80"	380	436	498	554	609	664	728	783	846	911	961	1018	1106	1143
90"	396	457	521	581	642	702	770	829	896	965	1020	1080	1174	1214
100"	413	479	546	611	676	739	811	875	946	1020	1080	1143	1240	1282
110"	429	499	570	639	708	778	851	921	997	1074	1139	1205	1307	1352
120"	444	519	595	669	740	814	894	965	1046	1128	1197	1269	1373	1422

OPTIONS: NO CHARGE – SPECIFY ON ORDER

- 2 on 1 Headrail (price as two separate shades)
- Non-wrapped bottomrail option (fabric-wrapped bottomrail standard)
- Hold-Down Brackets
- Metal Bead Chain Option

(Please note: when metal bead chain option is selected, the tensioner color will coordinate with the cassette headrail color. If the cassette headrail is silver, the tensioner will be white)

See page 9 for motorization surcharges

GROUP 4

• Advance (94") • Anastasia (100") • Extravagance (100") • Luxury (100")

WIDTH TO:	24"	30"	36"	42"	48"	54"	60"	66"	72"	76"	84"	90"	96"	100"
HEIGHT TO:														
40"	\$339	386	436	480	526	570	621	668	719	774	814	859	938	969
50"	360	411	467	518	568	619	677	728	786	846	892	942	1025	1057
60"	381	439	499	555	612	669	731	787	850	917	969	1024	1113	1149
70"	402	465	532	593	655	717	786	846	917	987	1045	1105	1200	1240
80"	424	492	563	631	698	766	840	907	981	1057	1121	1188	1289	1332
90"	444	519	595	669	740	814	894	968	1047	1129	1197	1270	1374	1423
100"	466	545	629	707	786	863	949	1027	1113	1200	1273	1352	1463	1515
110"	487	571	660	744	829	913	1002	1087	1177	1272	1349	1433	1551	1607
120"	508	600	693	782	871	961	1056	1146	1243	1342	1425	1516	1637	1697

GROUP 5

• Definition (90") • Diversion (102") • Obscure (96")

WIDTH TO:	24"	30"	36"	42"	48"	54"	60"	66"	72"	76"	84"	90"	96"	102"
HEIGHT TO:														
40"	\$369	421	478	529	581	632	690	740	800	861	906	956	1044	1077
50"	394	453	515	572	632	690	754	812	877	945	998	1055	1147	1186
60"	420	486	554	619	684	748	819	883	955	1030	1089	1153	1252	1295
70"	445	518	593	664	736	807	885	954	1033	1114	1180	1250	1356	1404
80"	470	549	632	709	787	865	949	1026	1111	1199	1272	1349	1461	1512
90"	495	581	670	754	838	922	1014	1098	1190	1284	1363	1446	1565	1621
100"	521	612	709	798	891	982	1080	1170	1268	1369	1454	1544	1670	1731
110"	546	645	747	845	943	1040	1143	1240	1347	1453	1545	1642	1775	1839
120"	571	677	786	890	993	1098	1208	1311	1423	1537	1635	1740	1879	1948

OPTIONS: NO CHARGE – SPECIFY ON ORDER

- 2 on 1 Headrail (price as two separate shades)
- Non-wrapped bottomrail option (fabric-wrapped bottomrail standard)
- Hold-Down Brackets
- Metal Bead Chain Option

(Please note: when metal bead chain option is selected, the tensioner color will coordinate with the cassette headrail color. If the cassette headrail is silver, the tensioner will be white)

See page 9 for motorization surcharges

**SIMPLICITY RECHARGEABLE AND POWERWAND OPTIONS:
EXTRA CHARGE – SPECIFY ON ORDER
USE APPROPRIATE DUAL SHADE GRID FOR SHADE PRICE, THEN ADD EXTRA CHARGE(S) BELOW.**

- Simplicity Rechargeable Motoradd \$322 per shading
 - 5 Channel Remote Control (Black or White).....(Black Part #CS5138 or White Part #CS5138W).....add \$50 each
 - Solar Paneladd \$175 each
 ***Motor is only available on the right side for Simplicity Rechargeable
- PowerWandadd \$134 per shading
 - PowerWand Options (must be specified):
 - 1) Control Side (Left or Right)
 - 2) Wand Color (Black or White)
 - 3) Wand Length:
 - 1 foot (12")
 - 2 feet (24")
 - 3 feet (36")
 - 4 feet (48")
 - 5 feet (60")
- Plug-in Charger (Can be used for both Simplicity Rechargeable and PowerWand).....add \$36 each

**REMOTELIFT OPTIONS: EXTRA CHARGE – SPECIFY ON ORDER (Must select RemoteLift power source* when ordering)
USE APPROPRIATE DUAL SHADE GRID FOR SHADE PRICE, THEN ADD REMOTELIFT EXTRA CHARGE(S) BELOW.**

***MOTOR IS ONLY AVAILABLE ON THE RIGHT SIDE FOR REMOTELIFT.

- Radio Frequency (RF) RemoteLift Motorization Upgrade add \$373 per shade
- Radio Frequency (RF) Remote Control – 1 Channel Part #RC445069 add \$118 each
- Radio Frequency (RF) Remote Control – 5 Channel Part #RC445079 add \$151 each
- Radio Frequency (RF) Remote Control – 16 Channel ** available as a separate part order only**..... Part #1811081..... add \$540 each
- Radio Frequency (RF) Remote Control – Telis Modulis 1 Channel Part #1811234..... add \$224 each
- Radio Frequency (RF) Remote Control – Telis Modulis 5 Channel Part #1811235..... add \$253 each
- Radio Frequency (RF) Wireless Wall Switch – 1 Channel Part #1810897 add \$298 each
- Radio Frequency (RF) Wireless Wall Switch – 5 Channel Part #1810813 add \$298 each
- Radio Frequency (RF) Programmable Timer – 1 Channel Part #1805237A add \$474 each
- RTS – Smoove 1 RTS..... Part #1811533 add \$154 each
- RTS – myLink RTS interface..... Part #1811403 add \$442 each
- Radio Frequency (RF) Reloadable Single Battery Wand** Part #RC445268 add \$159 each
- Radio Frequency (RF) Reloadable Dual Battery Wand** Part #RC445268 add \$322 each
- Dual Wand Y Harness (required)..... Part #9018625 add \$13 each
- Radio Frequency (RF) Transformer Part #1822445 add \$160 each
- Radio Frequency (RF) Battery Wand Extension Wire – 10"..... Part #9018686A add \$12 each
- Radio Frequency (RF) Battery Wand Extension Wire – 48"..... Part #9016736 add \$17 each
- Radio Frequency (RF) Battery Wand Extension Wire – 96"..... Part #9018624 add \$22 each
- Radio Frequency (RF) Lithium Batteries (Reloadable Wand – 8 each) Part #9014834 add \$53 each
- Solar Recharge Kit (**batteries NOT included**)Part #9019034.....add \$293 each
(Includes solar panel, 10" Y harness, 12v reloadable battery tube, tube mounting clips, glass mount adhesive tape, solar panel mounting brackets – 4 qty.)
- NiMh Rechargeable Batteries (quantity of 10).....Part #9018621.....add \$83 each
- Plug-in AC Battery Rapid Charger (for solar recharge kit only) (includes 12" cable).....Part #9018620.....add \$290 each
- 48" Extension Cable for Y HarnessPart #9016374.....add \$19 each

Notes: * RemoteLift power source options: Reloadable Single Battery Wand, Reloadable Dual Battery Wand, and Transformer (plugs into standard wall outlet)


** Each Reloadable Battery Wand comes with a set of 8 AA lithium batteries on initial shade orders. The part numbers above reference the battery wands only. The part # for replacement pack of 8 AA lithium batteries is #9014834.

When ordering multiple motorized shades/remotes, please provide programming instructions. Otherwise, all shades will be programmed to one remote.

PRODUCT SPECIFICATIONS

Cassette Measurement

- 3-5/8" wide x 3" high



Mounting Requirements

Inside Mount

- Minimum shallow mounting surface: 1-1/2"
- Minimum flush inside mounting including brackets for cassette: 3-3/4"

Outside Mount

- Minimum outside mount surface: 1-1/2"

Hardware Colors

Cassette available in white, beige, black, dark brown and anodized silver.

- A matching fabric insert in headrail is a standard feature
Please Note: on certain fabrics with narrower bands, the fabric insert will feature both the solid fabric and the sheer.
- Fabric-wrapped bottomrail is a standard feature (non-wrapped bottomrail optional)
- Universal metal bracket will be supplied
- Cord loops and tensioners are color-coordinated


Metal Bead Chain Option

- Metal Chain optional in the following colors: White, Black, Antique Brass, Oil Rubbed Bronze, Stainless Steel, and Nickel
(Please note: when metal bead chain option is selected, the tensioner color will coordinate with the cassette headrail color. If the cassette headrail is silver, the tensioner will be white)

Cord Loop, Metal Beaded Chain Lengths

SHADE HEIGHT	LOOP DROP
24" - 39 7/8"	24" loop
40" - 59 7/8"	36" loop
60" - 83 7/8"	48" loop
84" - 107 7/8"	60" loop
108" - 120"	72" loop

Please Note: Environmental conditions, such as heat, humidity, etc., may result in light bowing, puckering and dimpling of the fabric which is considered normal. Some fabrics may lightly fray which is considered normal and within specifications.



FINISHED DIMENSIONS

	Continuous Cord Loop	RemoteLift	Simplicity Rechargeable	PowerWand
	INSIDE MOUNT			
Cassette width	minus 1/4"	minus 1/4"	minus 1/8"	minus 1/8"
Tube Width	minus 1-1/8"	minus 1-1/8"	minus 1"	minus 1"
Fabric width	minus 1-1/4"	minus 1-1/4"	minus 1-1/8"	minus 1-1/8"
Bottom rail outer width	minus 1-3/16"	minus 1-3/16"	minus 1-1/16"	minus 1-1/16"
Bottom rail inner width	minus 1-3/8"	minus 1-3/8"	minus 1-1/4"	minus 1-1/4"

Deductions noted are taken from **Ordered Width**

	Continuous Cord Loop	RemoteLift	Simplicity Rechargeable	PowerWand
	OUTSIDE MOUNT			
Cassette width	ordered width	ordered width	ordered width	ordered width
Tube Width	minus 7/8"	minus 7/8"	minus 7/8"	minus 7/8"
Fabric width	minus 1"	minus 1"	minus 1"	minus 1"
Bottom rail outer width	minus 5/16"	minus 5/16"	minus 5/16"	minus 5/16"
Bottom rail inner width	minus 1-1/8"	minus 1-1/8"	minus 1-1/8"	minus 1-1/8"

Deductions noted are taken from **Ordered Width**


For IB and OB, Shade Height is **Ordered Height**

	Continuous Cord Loop	RemoteLift	Simplicity Rechargeable	PowerWand
Minimum Width (NET)	15"	18"	19"	21"
Minimum Height	24"	24"	20"	20"

SIMPLICITY RECHARGEABLE MOTORIZATION: OVERVIEW

Simplicity Rechargeable

- The Rechargeable Simplicity motor program features an integrated rechargeable lithium ion battery in the motor casing and is fully concealed by the inner tube.
- Rechargeable battery is included with the motor. The average battery charge will last 6-12 months based on an average sized shade raised and lowered once per day. The life of the battery charge will vary based on the type of window covering selected, the size and weight of the window covering and the number of times the shade is operated on a daily basis. The battery can be recharged up to 500 times. It takes approximately 5 hours to recharge the motor when fully depleted.



Battery Charger

- An 8.4 Volt charger requires a standard power outlet to recharge the battery. The charger must be specified when ordering Simplicity Rechargeable Motorized shade option. The charger plugs into the charging port of the motor. The charger is black and comes with a 156" wire. The dimensions are 1" wide x 2-1/2" length x 1-3/4" deep. Sold separately.



Solar Panel Recharge Option

- Plugs in to any Simplicity Rechargeable motorized shading (does not work with PowerWand). Provides constant trickle charge to 7.4v Li-ION Rechargeable battery packs. Does not require direct sunlight, but performs best in regular direct sunlight applications. Will prolong the life of the charge of the 7.4v rechargeable battery packs, and in some applications will maintain charge indefinitely.
- Life of charge is subject to application variables such as, size and weight of shade, frequency of use, amount of direct sunlight exposure, etc.



5 Channel Remote

- The remote can operate up to five shadings simultaneously, individually or in groups. Remotes and holders are available in white or black. The remote comes with a holder which can be mounted to a wall for easy storage. The range of the remote is approximately 80 feet.



Please Note:

- Motor is only available on the right side.
- Not all motors run at the same rate of speed.
- Simplicity motors have a "Favorites" position setting. To set a "Favorites" position, follow instructions provided in the installation instructions.

POWERWAND MOTORIZATION: OVERVIEW

PowerWand™ Motorization


- Dual Shades can be fabricated with the PowerWand Rechargeable Push Button Control option. The PowerWand Rechargeable option is an easy, cord free motorized operation for the budget savvy homeowner. PowerWand Rechargeable uses Simplicity motors and components.

PowerWand Rechargeable Shades Operation

- Press the up or down button on the pendant to raise or lower the shading to your desired position. No programming is required with PowerWand as upper and lower limits are set at the factory. If desired, upper and lower limits can be adjusted in the field.
- Please refer to the installation instructions for instructions on resetting the upper and lower limits and setting a favorites position can be programmed on-site.

PowerWand Appearance

- The PowerWand Rechargeable wand and pendant is attached to the head rail and requires no additional mounting.
- The wand and pendant hangs down the front of the shades from the head rail.
- Pendant is 2-1/2" long.
- The pendant does not need to be mounted to the wall to operate the shade.



PowerWand Options

- Wand is available in Black or White (there is no default)
- Wand is available in 1 foot increments from 1 to 5 feet (there is no default)
- Wand is available on either the right or left side of the shade (there is no default)



PowerWand Battery Life

- The battery life will vary based on the type of window covering selected, the size and weight of the window covering and the number of times you operate the blind on a daily basis.

Battery Charger

- 8.4 Volt charger requires a standard power outlet to recharge the battery. The charger must be specified when ordering the PowerWand motorization option. The charger plugs into the charger port on the side of the pendant. The charger is black and comes with a 156" wire. The dimensions are 1" wide x 2-1/2" length x 1-3/4" deep.



REMOTELIFT™ MOTORIZATION: OVERVIEW

With RemoteLift™ motorized shades, enjoy a better quality of life and have more time to enjoy life's daily pleasures. At the touch of a button, window coverings can be instantly adjusted to changing activities or the varying sun conditions.



An ideal solution is to manage glare with a RemoteLift hand-held remote control. At the simple touch of a button, shades will open or close to adjust to the changing sunlight in a room.



RemoteLift Radio Frequency (RF) motorized shades provide ultra-quiet operation. The system can operate shades from virtually anywhere in the house without direct line of sight. Similar to how a garage door opener operates, radio signals travel through walls and make it possible to control multiple coverings throughout the home alone or as a group. The RF system is also available in a 5-channel version. The multi-channel RF system allows for independent control of individual shades and/or group control.

RemoteLift motorization systems provide many benefits, such as improving energy efficiency, providing easily controllable privacy and also enhancing home security.



The RemoteLift RF timer allows users to program specific times of the day to automatically adjust shades in different areas of the house, protecting interiors from the fading effects of direct sunlight. This feature provides added security to an unoccupied home by creating a lived in look even while homeowners are away on vacation.



The battery powered RemoteLift RF wireless wall switch allows shades to be controlled when entering or exiting a room, just like the lights. The switch may be seamlessly installed without wiring next to any light switch or stand alone, and is never misplaced. This one touch privacy helps create the ideal environment whether preparing for a bath, relaxing in bed or enjoying time with the family at home.



The Smooove® 1 RTS surface-mounted wall switch avoids cutting into drywall. This single channel, battery-operated solution is easy to install, and doesn't require an electrician. It's an intuitive, surface mount control.



The myLink™ RTS Smartphone and Tablet Interface is a WiFi to Radio Technology Somfy® (RTS) bridge that can control up to 5 channels of RTS motorized products using the Somfy myLink apps for iOS and Android devices. Through the app, users can send immediate RTS commands, create scenes (a group of motorized products working together) and schedules (timed events). Users may access their myLinks from anywhere with the app's remote access feature. Though the myLink is a single-zone controller, multiple myLinks can be joined within the same system for multi-zone control.

RemoteLift motorized shades are powered by Somfy, an industry leader in automated window coverings. All motorized products are backed by a 5 year warranty.



REMOTELIFT™ MOTORIZATION: FEATURES & OPTIONS



RADIO FREQUENCY (RF) MOTORIZATION FEATURES:

- Highest quality patent protected design by Somfy
- Advanced motor, capable of lifting shades up to 12 LBS.
- Quiet operation
- Motor is fully enclosed within the headrail
- Installs with standard installation hardware
- RF motor is programmable

Note: The power source must be selected when ordering. The options are: reloadable single or dual battery wand, and the plug-in transformer.




 Radio Frequency (RF) RemoteLift Motor Motor (Part #1240292) Crown (Part #9018588A) Drive (Part #9018477)	• Fully concealed motor unit • Adjustable speed (10-28 rpms) • Soft Stop, Soft Start • Sleep Mode option available • Motor is only available on the right side
 Radio Frequency (RF) Remote Control (must order separately) Color: 2 tone white and gray 2 Types: programmable 1-channel and programmable 5-channel (1-Channel: Part #RC445069) (5-Channel: Part #RC445079) (Telis Modulis 5-Channel: Part #1811235) (16-Channel: Part #1811081 – available as a separate part order only)	• Controls shade operation • Programmable features • Easy shade positioning up to 90 feet away • 5-channel remote allows for multiple and independent shade operation • 5-channel remote programming can be done by special request prior to shipping. Contact customer service with your programming instructions otherwise all shades will be programmed on channel 1.
 Single Battery Wand (reloadable) and Installation Clips Wand (Part #RC445268) Clips (Part #9013263) 8 AA Lithium Batteries (not shown) (Part #9014834)	• On initial shade orders, the reloadable wand comes with 8 AA lithium batteries • Comes with mounting installation clips • For parts ordering the reloadable wand INCLUDING 8 AA lithium batteries, order both part #s • Replacement 8 AA lithium batteries may also be ordered separately
 Optional, Dual Battery Wand (reloadable) and Installation Clips (Part #RC445268) (Clips: Part #9013263) (Y-Harness: Part #9018625) (Y-Harness Ext. Cable: Part #9016374)	• On initial shade orders, the reloadable wands come with 16 AA lithium batteries • Combines (reloadable) Single Battery Wands for added lifting capacity and/or extended life • Comes with mounting installation clips
 Transformer 10' Cable (Part #1822445)	• Plug-in operation, no batteries required • Works in standard wall outlet (10' wire length)
 Battery Wand Extension Cables Color: White (10" Cable: Part #9018686A) (48" Cable: Part #9016736) (96" Cable: Part #9018624)	• Available in 10", 48" and 96" • Allows battery wand installation away from headrail
 Wireless Wall Switch Color: white 2 Types: programmable 1-channel and 5-channel (1 Channel: Part #1810897) (5 Channel: Part #1810813)	• Control wireless operation from the wall up to 90 feet away • Works like turning a light on/off
 Programmable Timer 1 Type: programmable 1-channel (Part #1805176)	• Program operation based on pre-set times • Excellent home security feature
 Smoove 1 RTS – single channel surface mount control Color: Pure (Part #1811533)	• Battery operated • Tactile buttons for UP/DOWN/MY/STOP control • LED for visual feedback
 myLink Interface Color: White (Part #1811403)	• Smartphone and Tablet Interface 120V AC • App Control • Remote Access • Compatible and controls all Radio Technology Somfy RTS products. • Can control up to 5 channels of RTS motorized products using myLink apps for iOS and android devices.
WireFree™ Solar Pack Kit – Batteries NOT included (Part #9019034) Photovoltaic Panel  "Y" Harness (Part #9018625)  Battery + Battery Tube (Part #9018621)  Accessories Plug-in AC battery (Part #9018620) rapid charger (required for charging battery prior to installation) 	• Uses sunlight to power a motorized shade. • Easy to install. Low profile, easy to conceal. • Solar Recharge Kit (batteries NOT included) (Part #9019034) – Includes solar panel, 10" Y harness, 12v reloadable battery tube, tube mounting clips, glass mount adhesive tape, solar panel mounting brackets – 4 qty.) • NiMH Rechargeable Batteries (quantity of 10) (Part #9018621) • Plug-in AC Battery Rapid Charger (for solar recharge kit only) (includes 12" cable) (Part #9018620) • 48" Extension Cable for Y Harness (Part #9016736)

REMOTELIFT™ ROLL-UP 28 WIREFREE™ RTS QUICK PROGRAMMING GUIDE

BEFORE YOU BEGIN: Check if you have a paired remote with the following directions:

- 1) Supply power to the motor by connecting the power source to the power cable on the motor.
- 2) If a remote was ordered, press a directional button (UP or DOWN) and see if the shade operates. If a multi-channel remote was ordered, select the channel the shade should be programmed under then operate the shade.
 - a) If the shade operates - the shade is already programmed.
 - b) If the shade does not operate - choose the channel on which you would like to control the shade. **PRESS & HOLD** the **PROGRAMMING BUTTON on the motor** until it jogs once. Then **BRIEFLY PRESS** the **PROGRAMMING BUTTON on the remote**. The shade will jog once. The shade is now programmed.

NOTE: Upper and lower limits are set at the factory. In the event limit setting is required, please follow steps under Initial Programming and Limit Setting.



INITIAL PROGRAMMING AND LIMIT SETTING

NOTE: Motor will exit programming mode after 2 minutes of inactivity. While in **programming mode**, the shade only operates when UP or DOWN buttons are continuously pressed.


Step 1: To initiate programming **PRESS & HOLD** the **UP and DOWN** buttons at the same time until the shade jogs.



Step 2: Check the direction of operation. Press the **DOWN** button and confirm the shade lowers.



If the shade raises instead of closing, change the direction - **PRESS & HOLD** the **MY/STOP** button until the shade jogs. Confirm correct direction of operation before proceeding.




Step 3: Bring the shade to your desired upper limit. **PRESS & HOLD** both the **MY/STOP** and **DOWN** buttons until the shade begins to move down, then release. Stop the shade at the desired lower limit, adjust by pressing the **UP** or **DOWN**.




Step 4: **PRESS & HOLD** the **UP** and **MY/STOP** buttons until the shade begins to move up. The shade will stop at the original upper limit. Adjust if necessary.

Step 5: **PRESS & HOLD** the **MY/STOP** button until the shade jogs to confirm both limit settings.



Step 6: To finalize **BRIEFLY PRESS** the **PROGRAMMING BUTTON** on the back of the control. The shade will jog and will now operate in **user mode**. A brief press of the UP or DOWN button will send the shade to the respective limit.



ADJUSTING THE LIMITS IN USER MODE

UPPER LIMIT

LOWER LIMIT

Step 1: Move the shade to the current limit position you wish to adjust and let it stop.



Step 2: **PRESS & HOLD** both **UP and DOWN** buttons simultaneously until the shade jogs, then release.



Step 3: Adjust to a new limit position using the **UP** or **DOWN** buttons.



Step 4: **PRESS & HOLD** the **MY/STOP** button until the shade jogs, then release. Check the new limit.



REMOTELIFT™ ROLL-UP 28 WIREFREE™ RTS QUICK PROGRAMMING GUIDE

ADD OR DELETE A CONTROL

a) **PRESS & HOLD** the **PROGRAMMING BUTTON** on the back of Control 1 until the shade jogs.



CONTROL 1:
Previously programmed control - single channel or the channel (1-5) of a multi-channel remote.

b) **BRIEFLY PRESS** the **PROGRAMMING BUTTON** on the back of Control 2. The shade jogs.



CONTROL 2:
Second control to be added or deleted - single channel or the channel (1-5) of a multi-channel remote.


The procedure to delete an RTS sensor is the same.

ENABLING SLEEP MODE


The shade must be programmed.

This feature temporarily prevents the motor from responding to any previously programmed remote commands.

1) **PRESS & HOLD** the motor head **PROGRAMMING BUTTON** until the shade jogs.




2) **BRIEFLY PRESS** the motor head **PROGRAMMING BUTTON**, the shade jogs twice. Sleep Mode is activated.



DISABLING SLEEP MODE

3) Press the motor head **PROGRAMMING BUTTON**.

The shade jogs and the remote commands are enabled.



NOTE: If step 3 is not performed, Sleep Mode will automatically disable after approximately 10 minutes.

RESETTING THE MOTOR TO FACTORY MODE

PRESS & HOLD the **PROGRAMMING BUTTON** on the motor (shown below) for approximately 12 seconds during which the shade will jog 3 separate times.



Programming Button



All programmed remotes and limit settings will be erased. Motor is now reset to **factory mode**. Motor limits will need to be re-established.

SETTING INTERMEDIATE "MY" POSITION

1) Move the shade to the desired position and press **MY/STOP** button to stop the shade.



2) **PRESS & HOLD** the **MY/STOP** button until the shade jogs. The "my" favorite position is set.




3) To set a NEW "my" position, repeat steps 1 and 2.


To delete: First send the shade to the current "my" position, then **PRESS & HOLD** the **MY/STOP** button for 5 seconds. The shade will jog to confirm deletion.

USING THE INTERMEDIATE "MY" POSITION

While the shade is stationary, a simple press of the **MY/STOP** button will move the shade to the "my" intermediate position from any shade position.



If the shade is in motion, first stop it by pressing **MY/STOP** and then **MY/STOP** again to send it to the "my" position.



ADJUSTING THE SPEED

LED blinks alternately in green and yellow during the adjustment.

1) Move the shade away from the end limits. **PRESS & HOLD** the **UP, MY/STOP and DOWN** buttons simultaneously, until the shade jogs. The shade will move up and down automatically in ten second cycles.




2) To increase the speed, **PRESS & HOLD** the **UP** button until the shade jogs. Repeat as needed.

Maximum speed is achieved when the shade no longer jogs when the UP button is pressed.


3) To decrease the speed, **PRESS & HOLD** the **DOWN** button until the shade jogs. Repeat as needed.

Minimum speed is achieved when the shade no longer jogs when the DOWN button is pressed.


4) To confirm the new speed, **PRESS & HOLD** the **MY/STOP** button until the shade jogs.



PRODUCT COMPONENTS – STANDARD



PRODUCT COMPONENTS – SIMPLICITY RECHARGEABLE MOTORIZATION



PRODUCT COMPONENTS – POWERWAND MOTORIZATION

