



Q: *What maintenance is necessary with the AIM Fuel Purifier?*

A: Because an AIM Purifier has no moving parts or replaceable filter element, it is essentially maintenance free. The optional water/'algae' sensor will indicate when the contaminants have reached a certain level in the sump. Because the Purifier has such a large sump capacity, it will continue to remove contaminants for a long time after that level has been reached. Draining the sump is a very simple process. Just open the valve on the bottom of the purifier and stop when you see a stream of clean fuel.

In comparison to changing a fiber type filter, it is apparent that the AIM Purifier takes only a few seconds to purge while changing a filter cartridge will obviously take much longer and invariably involve getting covered in fuel.