

FAQ: How do I turn off the water supply to my house in the event of a break in my plumbing or a repair?

You can interrupt the flow of water to your home by turning off your house valve. House valves are usually located beneath a faucet outside the home, most typically near the faucet for the garden hose. If you cannot find your house valve, please contact the office at 760-524-2037 or the after-hours emergency line at 760-524-2037 for assistance.