



DPDIMMERWP Remote Programming Instructions

1. Make sure the dimmer is plugged into the transformer and that the light plugged into the dimmer are on.
2. With the lights still on unplug the transformer from the outlet.
3. Allow the lights to shut off
4. Press and hold the up and down arrow buttons on the remote.
5. While holding those buttons plug the transformer back into the outlet.
6. The lights will flash quickly once.
7. Release the up and down arrow buttons.
8. Press the power button on the remote once.
9. The lights should shut off. If the lights shut off after pressing the power button press the power button a few more times to confirm that the lights turn on and off. Your remote is programmed enjoy.
10. If the lights do not shut off after pressing the power button repeat steps 1 through 8.
11. If after repeating steps 1 through 8 and pressing the power button on the remote does not shut off the lights, try replacing the battery and repeating steps 1 through 8.
12. If after replacing the battery and repeating steps 1 through 8 and the remote still does not turn the lights off contact DekPro.